T4TREAM FPSC18ST-NO

T4TREAM Fluted Nightstand with Charging Station

User Manual

Product Overview

The T4TREAM Fluted Nightstand with Charging Station is a versatile and stylish furniture piece designed to enhance your bedroom or living space. It features a distinctive waveform fluted panel, a faux marble top, and integrated charging capabilities, making it both aesthetically pleasing and highly functional. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure optimal use of your nightstand.



Figure 1: T4TREAM Fluted Nightstand with Charging Station in Natural Oak finish.

Safety Information

Please read and understand all safety instructions before assembling or using the nightstand. Failure to follow these instructions may result in injury or damage to the product.

- Ensure the nightstand is placed on a stable, level surface to prevent tipping.
- Exercise caution during assembly, as some components may have sharp edges or pinch points.
- Do not use the nightstand for purposes other than its intended use as a bedside, side, or end table.
- Adhere to all electrical safety guidelines when using the integrated charging station. Do not overload outlets.
- Keep liquids away from the charging station to prevent electrical hazards.

Setup and Assembly

The T4TREAM Fluted Nightstand is designed for straightforward assembly. All necessary hardware and instructions are

included. It is recommended that two adults assemble the unit, which typically takes 40-50 minutes.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components are present by comparing them with the included parts list. Each component is meticulously labeled with serial numbers.
2. **Prepare Workspace:** Choose a clean, flat, and spacious area for assembly to prevent scratching or damaging the furniture.
3. **Follow Instructions:** Refer to the detailed, user-friendly instructions provided in the package. Assemble the nightstand step-by-step, ensuring all screws and fasteners are securely tightened.
4. **Install Charging Station:** Integrate the charging station into the designated slot on the top surface as per the instructions. Ensure the power cord is routed safely.
5. **Final Check:** Once assembled, gently shake the nightstand to ensure stability. Adjust any components as needed to ensure proper alignment.

A pack of spare parts is supplied in case of loss of hardware during assembly.



Figure 2: All components and hardware are clearly labeled for easy identification.



Figure 3: Step-by-step assembly process for the nightstand.

Operating Instructions

The T4TREAM Fluted Nightstand features a convenient integrated charging station to power your electronic devices.

- **Power Connection:** Plug the 4.9-foot power cord from the nightstand into a standard 120V AC wall outlet.
- **AC Outlets:** The charging station includes 2 standard 125V/12A AC outlets for plugging in lamps, laptops, or other small appliances.
- **USB Ports:** Two 5V/2.1A USB ports are provided for charging smartphones, tablets, and other USB-powered devices.
- **Cord Management:** Utilize the cord cutout in the semi-open top cubby to neatly route charging cables and keep your space organized.



Figure 4: Integrated charging station with AC outlets and USB ports.

Maintenance

Proper care will help maintain the appearance and longevity of your T4TREAM Fluted Nightstand.

- **Cleaning:** Wipe the nightstand surfaces with a dry cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** The faux marble top is made of melamine veneer, offering water resistance. Wipe up spills immediately with a soft, dry cloth to prevent staining.
- **Drawer Maintenance:** The drawers feature smooth-glide metal rails. Periodically check and clean the rails to ensure continued smooth operation.
- **Structural Integrity:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain the table's stability.

Troubleshooting

If you encounter issues with your T4TREAM Fluted Nightstand, refer to the following common solutions:

Problem	Possible Cause	Solution
Nightstand is wobbly or unstable.	Loose fasteners or uneven placement.	Ensure all screws and bolts are fully tightened. Place the nightstand on a flat, level surface.
Drawers do not slide smoothly.	Rails are dirty or misaligned.	Clean the drawer rails. Check that the rails are correctly installed and aligned.
Charging station not working.	Not plugged in, power outage, or device issue.	Verify the nightstand's power cord is securely plugged into a live outlet. Test the outlet with another device. Ensure your device's charging cable is functional.
Assembly holes do not align.	Component orientation or initial loose tightening.	Double-check the orientation of the components against the instructions. Sometimes, leaving screws slightly loose until all parts are in place allows for minor adjustments before final tightening.

Specifications

Key specifications for the T4TREAM Fluted Nightstand with Charging Station:

Model Name: FPSC18ST-NO

Product Dimensions: 18"D x 18"W x 24"H

Item Weight: 46.3 Pounds

Color: Natural Oak

Frame Material: Engineered Wood

Top Material: Faux Marble (Melamine Veneer)

Base Material: Metal

Number of Drawers: 2

Electrical Outlets: 2 AC Outlets (125V/12A)

USB Ports: 2 USB Ports (5V/2.1A)

Power Cord Length: 4.9 feet

Included Components: Hardware, Instructions, Repair stickers

Recommended Use: Bedroom, Living Room (Nightstand, Side Table, End Table)

Care Instructions: Wipe with Dry Cloth



Figure 5: Detailed product dimensions.

Warranty and Support

T4TREAM products come with a standard warranty. For specific warranty details or if you have any questions, concerns, or require assistance with your nightstand, please contact T4TREAM customer support. Our team is dedicated to assisting you.

Please refer to the contact information provided on the product packaging or the official T4TREAM website for the most up-to-date support channels.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question