Ricoh RICOH GR IIIx HDF

RICOH GR IIIx HDF Digital Compact Camera User Manual

Model: RICOH GR IIIx HDF (01283)

Brand: Ricoh

1. Introduction

The RICOH GR IIIx HDF is a premium digital compact camera designed for exceptional image quality and portability. It features a built-in Highlight Diffusion Filter (HDF) for creative expression, a 24MP APS-C size CMOS sensor, and a 40mmF2.8 GR Lens (35mm equivalent). This manual provides essential information for setting up, operating, maintaining, and troubleshooting your camera.



Figure 1.1: Front view of the RICOH GR IIIx HDF camera, showcasing its compact design and prominent lens.

2. Setup

2.1 Unboxing and Initial Inspection

Carefully unpack all components from the box. Verify that all items listed below are present and undamaged.

- RICOH GR IIIx HDF Camera Body
- Rechargeable Lithium-Ion Battery
- USB Power Adapter
- USB Cable
- Hand Strap
- Instruction Manual (this document)

2.2 Charging the Battery

Before first use, fully charge the camera battery. Insert the battery into the camera, then connect the camera to the USB power adapter using the supplied USB cable. The charging indicator light will illuminate during charging and turn off when complete.

2.3 Inserting a Memory Card

The camera supports SD, SDHC, and SDXC memory cards. Open the battery/card compartment cover, insert the memory card with the contacts facing the correct direction until it clicks into place. Close the cover securely.

2.4 Attaching the Hand Strap

Attach the hand strap to the designated strap lug on the camera body to prevent accidental drops.

3. Operating Instructions

3.1 Powering On/Off

Press the **ON/OFF** button located on the top of the camera to power it on or off.



Figure 3.1: Top view of the camera, highlighting the ON/OFF button and various controls.

3.2 Basic Shooting Modes

Rotate the mode dial on the top of the camera to select your desired shooting mode:

- **P (Program AE)**: The camera automatically sets aperture and shutter speed for optimal exposure.
- **Av (Aperture-Priority AE)**: You set the aperture, and the camera sets the shutter speed.
- **Tv (Shutter-Priority AE)**: You set the shutter speed, and the camera sets the aperture.
- **M (Manual Exposure)**: You control both aperture and shutter speed.
- **U1/U2/U3 (User Modes)**: Save and recall your preferred camera settings for quick access.

3.3 Using the Highlight Diffusion Filter (HDF)

The GR IIIx HDF features a built-in Highlight Diffusion Filter. This filter diffuses highlights for softer light, creating more expressive images with a sense of depth and emotion, reminiscent of film photography. To activate or deactivate the HDF, press the dedicated **HDF** button located on the rear of the camera.



Figure 3.2: Rear controls with the HDF button clearly visible.

3.4 Touch Panel LCD Monitor

The 3-inch LCD monitor is a touch panel, allowing for intuitive operation. You can:

- Touch and slide to move the AF frame.
- Access menu options by tapping.
- Pinch in and out during playback to change magnification.
- Flick to view previous and next images.
- Double-tap to return to the center of the image during playback.



Figure 3.3: Demonstrating touch screen functionality for focus and menu navigation.

3.5 Smartphone Connection (Wi-Fi/Bluetooth)

The camera supports wireless LAN (Wi-Fi) and Bluetooth connectivity for seamless integration with your smartphone. Use the dedicated app to:

- Transfer images to your smartphone.
- Control the camera remotely (Live View remote shooting).
- Synchronize location information and time.




Figure 3.4: Connectivity options for smartphone integration.

4. Maintenance

4.1 Cleaning the Camera Body

Wipe the camera body with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild cleaning solution. Avoid using strong solvents or abrasive materials.

4.2 Cleaning the Lens

Use a lens brush or a blower to remove dust from the lens surface. For smudges or fingerprints, use a specialized lens cleaning cloth and lens cleaning fluid. Do not touch the lens surface with your fingers.

4.3 Battery Care

Store batteries in a cool, dry place when not in use. Avoid fully discharging the battery frequently, as this can reduce its lifespan. If storing for extended periods, charge the battery to about 50% capacity.

4.4 Storage

When storing the camera for a long time, remove the battery and memory card. Store the camera in a dry, well-ventilated area, away from direct sunlight, high temperatures, and humidity. Consider using a desiccant to prevent mold and mildew.

5. Troubleshooting

This section addresses common issues you might encounter with your RICOH GR IIIx HDF camera. If the problem persists after trying these solutions, please contact customer support.

Problem	Possible Cause	Solution
Camera does not power on.	Battery is depleted or not inserted correctly.	Charge the battery fully. Ensure the battery is inserted with correct orientation.
Images are blurry.	Camera shake, incorrect focus, or dirty lens.	Hold the camera steady. Ensure autofocus is engaged. Clean the lens. Check shutter speed.
Memory card error.	Card not inserted correctly, card is full, or card is corrupted.	Reinsert the card. Delete unnecessary files or use a new card. Format the card (this will erase all data).
Cannot connect to smartphone via Wi-Fi.	Wi-Fi is off, incorrect password, or app issue.	Ensure Wi-Fi is enabled on camera and phone. Verify password. Restart camera and phone. Reinstall the app.

6. Specifications

Detailed technical specifications for the RICOH GR IIIx HDF camera.

Feature	Specification
Model Name	RICOH GR IIIx HDF
Photo Sensor Resolution	24 MP
Photo Sensor Size	APS-C
Lens Type	Wide Angle lens, 40mm focal length (35mm equivalent), f/2.8 aperture
Image Stabilization	Digital, Optical (3-axis, 4-step Shake Reduction)
Supported File Format	JPEG, RAW
Display Type	LCD Touch Screen (3 Inches)
Connectivity Technology	Wi-Fi, Bluetooth
Video Resolution	1080p (30 FPS)
ISO Range (Expanded)	Up to 102400
Item Weight	9.12 ounces
Battery Type	Lithium Ion (1 included)
Water Resistance Level	Not Water Resistant

7. Warranty and Support

7.1 Warranty Information

The RICOH GR IIIx HDF camera comes with a**1-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full terms and conditions, refer to the warranty card included with your product or visit the official Ricoh website.

7.2 Customer Support

For technical assistance, service, or further inquiries, please visit the official Ricoh support website or contact their customer service department. You can find contact information on the Ricoh website or in the documentation provided with your camera.

Ricoh Official Website: www.ricoh-imaging.co.jp/english/

© 2025 Ricoh Imaging Company, Ltd. All rights reserved.
Product specifications and design are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question