Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Famiworths M

Famiworths Single Serve Coffee Maker with Milk Frother

Model: M
Brand: Famiworths

1. Introduction

Thank you for choosing the Famiworths Single Serve Coffee Maker with Milk Frother. This versatile appliance is designed to provide you with a convenient and enjoyable coffee experience, allowing you to brew both hot and iced coffee using K-cups or ground coffee. It also includes a portable milk frother for creating delicious coffee beverages. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or coffee maker in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been dropped or damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.

- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycle.

3. Product Overview

Components

- Famiworths Single Serve Coffee Maker
- K-Cup Pod Holder
- Reusable Ground Coffee Basket (25g capacity)
- Portable Milk Frother
- Water Reservoir

Key Features

- **Dual Brewing Styles:** Brew hot or iced coffee.
- **Versatile Coffee Options:** Compatible with K-cup pods and ground coffee.
- **Rapid Heating:** Heats water in approximately 2 minutes.
- **One-Touch Operation:** Simple button controls for brewing and frothing.
- **Descaling Reminder:** Indicator lights alert when descaling is needed.
- **Self-Cleaning Function:** Automated cleaning process for convenience.
- **Compact Design:** Space-saving footprint, ideal for limited counter space.
- **Portable Milk Frother:** Easy-to-use frother for lattes, cappuccinos, and more.



Figure 3.1: Famiworths Single Serve Coffee Maker with its accessories.



Figure 3.2: The coffee maker supports both hot and iced coffee brewing.



Figure 3.3: Detailed view of the K-pod holder and reusable ground coffee basket.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash the reusable ground coffee basket, K-cup pod holder, and milk frother with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the coffee maker with a damp cloth.

3. **Placement:** Place the coffee maker on a stable, flat, heat-resistant surface near an electrical outlet. Ensure there is adequate clearance around the unit for ventilation.
4. **First Brew Cycle (Cleaning):** Fill the water reservoir with clean water. Place an empty mug on the drip tray. Run a brew cycle without coffee to flush the internal system. Discard the water. Repeat this process once more.

5. Operating Instructions

General Brewing Steps

1. Ensure the coffee maker is plugged into a grounded electrical outlet.
2. Lift the lid of the water reservoir and fill it with fresh, cold water. Do not exceed the MAX fill line.
3. Choose your preferred brewing method: K-cup pod or ground coffee.
4. Place your mug or cup on the drip tray. Ensure your cup size is appropriate for the brew volume (18-414ml). Note: Some 20oz cups may not fit.

Brewing Hot Coffee

1. Follow General Brewing Steps 1-4.
2. If using a K-cup pod, insert it into the K-cup pod holder. If using ground coffee, fill the reusable ground coffee basket with up to 25g (0.88oz) of ground coffee and place it in the brewing chamber.
3. Close the lid firmly until it clicks.
4. Press the **REGULAR** button. The button will illuminate, and brewing will begin shortly.
5. Once brewing is complete, the light will turn off. Carefully remove your hot coffee.

Brewing Iced Coffee

1. Follow General Brewing Steps 1-4.
2. Fill your serving cup with ice cubes.
3. If using a K-cup pod, insert it into the K-cup pod holder. If using ground coffee, fill the reusable ground coffee basket with up to 25g (0.88oz) of ground coffee and place it in the brewing chamber.
4. Close the lid firmly until it clicks.
5. Press the **OVER ICE** button. The button will illuminate, and brewing will begin shortly.
6. Once brewing is complete, the light will turn off. Your iced coffee is ready.

Using the Portable Milk Frother

1. Pour cold milk into a mug or frothing pitcher.
2. Insert the whisk end of the portable milk frother into the milk.
3. Press and hold the button on the frother handle to activate.
4. Move the frother up and down in the milk until desired froth consistency is achieved.
5. Release the button to turn off.
6. Rinse the whisk end immediately after use.



Figure 5.1: Easy one-button operation for brewing.



Figure 5.2: The compact design fits well in various spaces.

6. Maintenance

Cleaning

- Always unplug the coffee maker before cleaning and allow it to cool.
- **Removable Parts:** The K-cup pod holder and reusable ground coffee basket are dishwasher safe (top rack only) or

can be hand-washed with warm, soapy water.

- **Exterior:** Wipe the exterior of the coffee maker with a damp, soft cloth. Do not use abrasive cleaners or scouring pads.
- **Drip Tray:** The drip tray and its cover can be removed for cleaning. Wash with warm, soapy water.
- **Milk Frother:** Rinse the whisk end of the milk frother immediately after each use. The handle can be wiped with a damp cloth. Do not immerse the handle in water.

Descaling (Self-Cleaning Function)

Mineral deposits from water can build up in your coffee maker over time, affecting performance. The Famiworths coffee maker features a descaling reminder and self-cleaning function.

- **Descaling Reminder:** When the **REGULAR** and **OVER ICE** lights flash alternately red, it indicates that descaling is necessary.
- **Descaling Process:**

    a. Ensure the coffee maker is empty of coffee grounds or pods.

    b. Fill the water reservoir with approximately 14 ounces of descaling solution (e.g., white vinegar or a commercial descaling agent mixed according to product instructions).

    c. Place a large empty mug or container on the drip tray to collect the descaling solution.

    d. Press and hold both the **REGULAR** and **OVER ICE** buttons simultaneously for 2 seconds to start the self-cleaning/descaling process.

    e. The machine will run a cycle to clean itself. This process may take several minutes.

    f. Once the cycle is complete, discard the descaling solution.

    g. Rinse the water reservoir thoroughly with fresh water.

    h. Run 2-3 full cycles with fresh water only to rinse out any remaining descaling solution. Discard the water after each cycle.



Figure 6.1: Descaling reminder and self-cleaning process.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Coffee maker does not turn on.	Not plugged in; power outlet issue; machine malfunction.	Ensure the power cord is securely plugged into a working outlet. Try a different outlet. If problem persists, contact customer support.
Coffee is not brewing or brewing slowly.	Water reservoir empty; machine needs descaling; K-pod/ground basket clogged.	Fill water reservoir. Check if descaling lights are flashing (see Maintenance section). Clean the K-pod holder or ground basket, ensuring no blockages.
Lights are flashing alternately red.	Machine needs descaling.	Perform the descaling process as described in the Maintenance section.
Coffee tastes weak or watery.	Insufficient coffee grounds/pod; too much water; machine needs descaling.	Ensure you are using the correct amount of coffee for your desired strength. Check water level. Perform descaling if necessary.
K-pod spike gets clogged.	Coffee grounds or residue blocking the needle.	Carefully remove the K-pod holder and inspect the needle. Use a paperclip or similar thin tool to gently clear any blockages. Be cautious as the needle is sharp.
Milk frother is not frothing milk effectively.	Low battery; whisk is dirty; milk type/temperature.	Replace batteries. Clean the whisk thoroughly. Ensure milk is cold for best frothing results. Some milk types froth better than others.

8. Specifications

Attribute	Value
Brand	Famiworths
Model Number	M
Color	Matte Black
Dimensions (L x W x H)	30.48 x 12.7 x 20.32 cm (12 x 5 x 8 inches)
Weight	1.88 Kilograms (4.14 lbs)
Capacity	14 Ounces (approx. 414 ml)
Power	1000 Watts
Voltage	1000 Volts (This value seems unusually high for a household appliance. Please refer to the product label for accurate voltage.)
Material	Plastic and Stainless Steel
Special Feature	Automatic Cleaning Function

9. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product at the time of purchase or visit the official Famiworths website. Typically, warranty details cover manufacturing defects for a specified period from the date of purchase.

If you encounter any issues not covered in the troubleshooting section, or require further assistance, please contact Famiworths customer service directly. Have your model number (M) and purchase information ready when contacting support.

© 2025 Famiworths. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CX1BMBX7

More documents and user manuals: **https://manuals.plus/**