Beelicious Pro USLPRn-YTOVS6612X

Beelicious Pro Automatic Food Vacuum Sealer Machine Instruction Manual

Model: USLPRn-YTOVS6612X

Introduction

Thank you for choosing the Beelicious Pro Automatic Food Vacuum Sealer Machine. This manual provides essential information for the safe and efficient operation of your new appliance. Please read it thoroughly before first use and retain it for future reference.

Safety Information

- Always ensure the appliance is unplugged before cleaning or maintenance.
- Do not immerse the appliance in water or other liquids.
- Keep out of reach of children.
- Use only Beelicious Pro approved vacuum sealer bags and accessories.
- Do not operate if the power cord or plug is damaged.
- Avoid sealing objects with sharp edges that could puncture the bag.

Product Overview

The Beelicious Pro Automatic Food Vacuum Sealer is designed to preserve food freshness by removing air and sealing bags. It features intuitive controls and multiple modes for various food types.



Image: Front view of the Beelicious Pro Automatic Food Vacuum Sealer Machine, highlighting its sleek design and control panel.

Key Components:

- **Control Panel:** Buttons for various functions (Food Mode, Seal, Vac Seal, Stop/Pulse).
- **Sealing Strip:** Heats to create an airtight seal.
- **Vacuum Channel:** Area where air is removed from the bag.
- **Lid Latches:** Secure the lid during operation.
- **Bag Cutter:** Integrated cutter for custom bag sizes.
- **External Vacuum Port:** For use with external vacuum containers (accessories sold separately).

Setup

Before using your vacuum sealer, ensure it is placed on a flat, stable surface and plugged into a grounded electrical outlet (120V AC).

First Use Preparation:

1. Unpack the vacuum sealer and all accessories.
2. Wipe down the exterior of the unit with a damp cloth.
3. Ensure the sealing strip and vacuum channel are clean and free of debris.
4. Familiarize yourself with the control panel buttons.

Operating Instructions

Follow these steps for effective vacuum sealing:

1. Preparing the Bag:

- Use Beelicious Pro vacuum sealer bags. Ensure the bag is clean and dry.
- Leave at least 80mm (approximately 3 inches) of empty space at the top of the bag to allow for proper sealing.
- For moist foods, wipe any excess liquid from the inside of the bag near the sealing area to ensure a strong seal.



Image: Illustration of leaving adequate space at the top of the bag for sealing.

2. Vacuum Sealing Process:

1. Place the open end of the bag into the vacuum channel, ensuring it is flat and smooth.
2. Close the lid firmly until both side latches "click" into place.
3. Select the appropriate food mode:
    - **Dry Mode:** For solid, dry foods.
    - **Moist Mode:** For foods with some moisture, such as marinated meats or fruits.
4. Press the **VAC SEAL** button. The machine will automatically remove air and then seal the bag. Indicator lights will show the progress.
5. Once the process is complete and the indicator lights turn off, press the release buttons on both sides to open the lid.
6. Remove the sealed bag and inspect the seal for completeness.



Images: Steps for placing the bag and closing the lid.





Images: Steps for initiating vacuum seal and checking the result.

3. Seal Only Function:

Use the **SEAL** button to create a seal without vacuuming. This is useful for sealing bags that do not require vacuuming, or for creating custom-sized bags from a roll.

1. Place the open end of the bag onto the sealing strip.
2. Close the lid firmly until both side latches "click" into place.
3. Press the **SEAL** button. The machine will heat and seal the bag.
4. Once the indicator light turns off, open the lid and remove the sealed bag.

4. Pulse Function:

The **STOP/PULSE** button allows for manual control over the vacuum process, ideal for delicate items like bread or chips that could be crushed by full vacuum pressure.

1. Place the bag as described in step 2.
2. Close the lid firmly.
3. Press and hold the **STOP/PULSE** button to start vacuuming.
4. Release the button when the desired vacuum level is reached.
5. Immediately press the **SEAL** button to seal the bag.
6. Open the lid and remove the sealed bag.



Image: Demonstrating the use of the Stop/Pulse button for controlled vacuuming.

5. Using the External Vacuum Port:

The external vacuum port allows you to vacuum seal canisters and other compatible accessories.

1. Connect one end of the accessory hose to the external vacuum port on the sealer.
2. Connect the other end of the hose to the port on your vacuum-sealable container.
3. Press the **VAC SEAL** button. The machine will automatically remove air from the container.
4. Once vacuuming is complete, the machine will stop. Remove the hose.

Food Preservation Guide

Vacuum sealing significantly extends the shelf life of various foods. The following table provides approximate preservation times:




Image: A comparative table illustrating how vacuum sealing extends the freshness of different food types.

Approximate Food Preservation Times

Food Type	Room Temperature (Unsealed)	Refrigerator (Unsealed)	Vacuum Sealed (Refrigerator)	Vacuum Sealed (Freezer)
Meat	2-3 Days	2-3 Days	8-9 Days	12 Months
Seafood	1-3 Days	1-3 Days	4-6 Days	12 Months
Vegetables	3-5 Days	3-5 Days	7-10 Days	12-40 Days
Fruit	5-7 Days	5-7 Days	10-16 Days	40-56 Days
Nuts	6 Months	6 Months	1-3 Years	N/A

Note: Preservation times are approximate and can vary based on food quality, preparation, and storage conditions. Always follow food safety guidelines.

Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your vacuum sealer.

Cleaning:

1. Always unplug the appliance before cleaning.
2. Wipe the exterior with a damp cloth and mild soap. Do not use abrasive cleaners.
3. Clean the vacuum channel and sealing strip with a damp cloth. Ensure no food particles are left behind, as this can affect sealing performance.
4. Dry all parts thoroughly before storing or next use.



Image: Demonstrating how to clean the sealing area of the vacuum sealer.

Storage:

Store the vacuum sealer in a dry place with the lid unlatched to prevent compression of the sealing gaskets, which can lead to poor seals over time.

Troubleshooting

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outlet issue.	Ensure the power cord is securely plugged into a working outlet.
Bag does not vacuum properly.	Bag not positioned correctly; lid not latched; vacuum gasket dirty/damaged.	Reposition the bag; ensure lid clicks shut; clean or replace vacuum gaskets.
Bag does not seal.	Sealing strip dirty/damaged; bag too wet near seal area; incorrect bag type.	Clean sealing strip; dry bag edges; use only Beelicious Pro vacuum sealer bags.
Air leaks into sealed bag.	Improper seal; bag puncture; food with sharp edges.	Re-seal the bag; check for punctures; pad sharp food items before sealing.

Specifications

- **Brand:** Beelicious Pro
- **Model Number:** USLPRn-YTOVS6612X
- **Material:** Stainless Steel
- **Color:** Blue
- **Power Source:** Corded Electric
- **Operation Mode:** Automatic
- **Wattage:** 110 watts
- **Voltage:** 120 Volts (AC)

Warranty and Support

Beelicious Pro products are manufactured to high-quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided with your purchase or visit the official Beelicious Pro website.
Please retain your proof of purchase for any warranty claims.

© 2024 Beelicious Pro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question