Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Blaze Grills BLZ-4LTE3-NG

Blaze LTE Plus 4-Burner Natural Gas Grill (32") Model BLZ-4LTE3-NG Instruction Manual

1. Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Blaze LTE Plus 4-Burner Natural Gas Grill, Model BLZ-4LTE3-NG. This grill is designed for outdoor use and features durable stainless steel construction, four main burners, and integrated lighting for enhanced grilling experiences. Please read this manual thoroughly before assembly or operation.



Figure 1: Blaze LTE Plus 4-Burner Natural Gas Grill with lid closed, showcasing its stainless steel exterior.

2. Important Safety Information

Always adhere to local codes and regulations when installing and operating this natural gas grill. Failure to follow these instructions could result in property damage, bodily injury, or death.

- **Outdoor Use Only:** This grill is designed for outdoor use only. Do not operate indoors or in enclosed spaces.
- **Gas Leaks:** Check for gas leaks before each use. Never use an open flame to check for leaks. Use a soapy water solution.
- **Clearance:** Maintain adequate clearance from combustible materials. Refer to installation instructions for specific distances.
- **Ventilation:** Ensure proper ventilation around the grill. Do not obstruct airflow.
- **Children and Pets:** Keep children and pets away from the grill during operation and while it is cooling down.
- **Hot Surfaces:** Grill surfaces become extremely hot during use. Use heat-resistant gloves and appropriate tools.
- **Proposition 65 Warning:** This product can expose you to chemicals including carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

3. Setup and Installation

The Blaze LTE Plus grill requires assembly and is designed for built-in installation into an outdoor kitchen island or suitable enclosure. Professional installation by a qualified technician is recommended for natural gas connections.

- **Unpacking:** Carefully remove all packaging materials and inspect the grill for any damage. Report any damage to your retailer immediately.
- **Location:** Choose a level, stable surface for installation, away from windows, doors, and ventilation openings. Ensure adequate clearance from combustible materials as specified in the full installation guide.
- **Gas Connection:** Connect the grill to a natural gas supply line according to local codes and the manufacturer's instructions. Ensure all connections are tight and leak-free.
- **Electrical Connection:** The grill's lights require a 110V electrical connection. Ensure this is installed by a qualified electrician.



Figure 2: The Blaze LTE Plus grill integrated into an outdoor kitchen island, demonstrating a typical built-in installation.

4. Operating Instructions

This section outlines the basic steps for lighting and operating your Blaze LTE Plus grill.

4.1. Lighting the Main Burners

1. Ensure the grill lid is open.
2. Turn on the gas supply to the grill.
3. Push in and slowly turn a control knob counter-clockwise to the HIGH position. You should hear an ignition click.
4. If the burner does not light within 5 seconds, turn the knob to OFF, wait 5 minutes, and repeat the process.
5. Once lit, adjust the flame to your desired cooking temperature.

4.2. Using the Integrated Lights

The Blaze LTE Plus grill features internal cooking lights and illuminated control knobs for visibility and aesthetic

appeal.

- **Internal Lights:** A dedicated switch typically controls the internal cooking lights, allowing you to illuminate the cooking surface.
- **Control Knob Lights:** The control knobs feature LED illumination. These lights often change color to indicate the burner status (e.g., blue for off/low, red for high).



Figure 3: The grill with its lid open, showcasing the four main burners and the internal cooking lights.



Figure 4: A close-up view of the grill's control panel, showing the individual burner knobs.



Figure 5: A control knob illuminated with a blue LED, indicating a specific operational status.



Figure 6: A control knob illuminated with a red LED, indicating a different operational status, such as high heat.

5. Maintenance and Cleaning

Regular maintenance ensures the longevity and optimal performance of your grill. Always allow the grill to cool completely before cleaning.

- **Exterior Cleaning:** The stainless steel exterior should be cleaned with a mild soap and water solution, then wiped dry with a soft cloth to prevent water spots. Avoid abrasive cleaners or steel wool.
- **Cooking Grates:** Clean cooking grates after each use with a grill brush. For stubborn residue, remove grates and wash with warm soapy water.
- **Burners:** Periodically inspect burner ports for blockages. Clean with a wire brush if necessary.
- **Grease Tray:** Regularly empty and clean the grease tray to prevent flare-ups and maintain hygiene.
- **Grill Cover:** Utilize the included grill cover to protect the unit from weather elements when not in use.

6. Troubleshooting

This section addresses common issues you might encounter with your grill.

- **Burner Not Lighting:** Check if the gas supply is open. Ensure the igniter is sparking. Clean burner ports if clogged.
- **Low Flame:** Verify adequate gas pressure. Check for blockages in the gas line or burner tubes.
- **Uneven Heating:** Clean burners and heat diffusers. Ensure proper placement of cooking grates.
- **Flare-ups:** Reduce fat content in food. Clean grease tray and cooking surfaces regularly.
- **Lights Not Working:** Check electrical connection and ensure the switch is on. Inspect for loose wiring or blown fuses.

For issues not resolved by these steps, contact customer support.

7. Product Specifications

Feature	Specification
Brand	Blaze Grills
Model Name	BLZ-4LTE3-NG
Fuel Type	Natural Gas
Main Burner Count	4
Grill Configuration	4 main burners + 1 rotisserie burner
Cooking Surface Area	715 Square Inches
Material	Stainless Steel
Installation Type	Built-In
Product Dimensions	24"D x 30"W x 48"H
Item Weight	114 Pounds
Voltage	110 Volts
Wattage	110 watts
Special Feature	Adjustable Air Vent, Integrated Lights
Included Components	Grill Cover
UPC	840351728624

8. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or visit the official Blaze Grills website. For technical assistance, replacement parts, or any other inquiries, please contact Blaze Grills customer support.

Contact information can typically be found on the manufacturer's website or in your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CX3JGXF2

More documents and user manuals: **https://manuals.plus/**