Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit Replacement Remote Control for Sylvania/Funai TV/VCR Combos

ZdalaMit Replacement Remote Control User Manual

For Sylvania/Funai TV/VCR Combo Models

1. Introduction

This manual provides instructions for the ZdalaMit Replacement Remote Control, designed for use with various Sylvania and Funai TV/VCR Combo models. This remote control requires no programming and is ready for use after battery installation.

2. Product Overview

The ZdalaMit Replacement Remote Control is a direct replacement for original remote controls of specific Sylvania and Funai TV/VCR Combo units. It features a standard layout for easy navigation and control of your TV/VCR functions.





Image 2.1: Front view of the ZdalaMit Replacement Remote Control. This image displays the full button layout, including the power button (red, top left), record button (red, top right), channel and volume controls, and the numeric keypad.

Key Features:

- **No Programming Required:** Functions immediately upon battery installation.
- **Direct Replacement:** Designed to replicate the functionality of original remotes for compatible models.
- **Ergonomic Design:** Comfortable to hold and operate.

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.

2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA 1.5V Alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

Note: *Batteries are not included with the remote control. Always use new alkaline batteries for optimal performance.*

4. Operating Instructions

Once batteries are installed, the remote control is ready for immediate use with compatible Sylvania/Funai TV/VCR Combo models. Point the remote control directly at your TV/VCR unit and press the desired function button.



Image 4.1: Remote control in use, demonstrating typical operation. The image shows a user holding the remote and pointing it towards a TV, indicating the line-of-sight requirement for infrared remote controls.

4.1 Compatible Models:

This replacement remote control is compatible with the following Sylvania/Funai TV/VCR Combo models:

- F3809A
- F3809B
- F313CA
- F313CB
- F319CB
- F3809C
- F3809U

- F313CC
- F319CC
- F3809D

If your model is not listed, please verify compatibility with the seller before use.

5. Maintenance

5.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops functioning. Follow the battery installation steps in Section 3.1.

5.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's finish or internal components.

6. Troubleshooting

- **Remote not responding:**
  - Ensure new AAA alkaline batteries are correctly installed with proper polarity.
  - Check if the remote control is pointed directly at the TV/VCR Combo's infrared receiver.
  - Remove any obstructions between the remote and the TV/VCR Combo.
  - Verify that the TV/VCR Combo is powered on.
- **Specific buttons not working:**
  - This remote is a replacement and may not support all advanced functions of every original remote. Refer to your TV/VCR Combo's original manual for specific function details.
  - Ensure the remote is compatible with your exact TV/VCR Combo model (refer to Section 4.1).

7. Specifications

Feature	Detail
Brand	ZdalaMit
Compatible Devices	Sylvania/Funai TV/VCR Combo (Specific models listed in Section 4.1)
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	5.9 x 1.57 x 0.55 inches (approximately)
Item Weight	1.41 ounces (without batteries)
Color	Black


POWER
RECORD
EJECT
WAKE-UP /SLEEP
T-PROG CLEAR
CHANNEL RETURN
COUNTER RESET
TIMER SEARCH
MUTE
TV/FM
MENU
DISPLAY
GAME
SPEED
CHANNEL
PLAY
REW
PAUSE /STILL II
F.FWD
STOP
VOLUME
1
2
3
4
5
6
7
8
9
+100
0
SLOW
6.14 inch
1.85 inch
0.7 inch

Image 7.1: Dimensions of the ZdalaMit Replacement Remote Control. This image provides a visual representation of the remote's length, width, and thickness, with measurements indicated.

8. Warranty and Support

Specific warranty details for this ZdalaMit Replacement Remote Control are not provided in this manual. For warranty information, technical support, or further assistance, please contact the seller directly through your purchase platform. For information regarding your Sylvania/Funai TV/VCR Combo unit, please refer to its original user manual or contact the manufacturer of your TV/VCR Combo.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CX42G5BR

More documents and user manuals: **https://manuals.plus/**