Aigostar B30202Y16

Aigostar 2-Slice Retro Toaster Instruction Manual

Model: B30202Y16 | Brand: Aigostar

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before operating the toaster.
- Do not touch hot surfaces. Always use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or toaster in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The toaster features a **Cool Touch Exterior** to prevent scalding hands during use.
- The **High Lift Lever** design helps to avoid the risk of burns when removing smaller items.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Do not use appliance for other than intended use.
- Do not attempt to dislodge food when toaster is plugged in.
- Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may involve a risk of fire or electric shock.
- A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not leave toaster unattended when in use.

2. Product Overview and Components

The Aigostar 2-Slice Retro Toaster combines vintage aesthetics with modern functionality, featuring a

durable stainless steel body and extra-wide slots.



Main Product View: The Aigostar 2-Slice Retro Toaster in Aqua Green, showcasing its sleek design and control panel.



4-in-1 Toasting Functions: Close-up of the control panel highlighting the Cancel, Bagel/Muffin, Reheat, and Defrost buttons.



6 Shade Settings: Visual guide demonstrating the different browning levels from light (level 1) to dark (level 6) for toast and bagels.



Extra Wide Slots: An overhead view showing the 1.6-inch wide slots, suitable for various bread types, and the partially pulled out crumb tray.



High Lift Lever: A hand demonstrating the high lift lever, which raises smaller items for easy and safe retrieval.



Removable Crumb Tray & Wire Wrap Storage: Images showing the easy-to-clean removable crumb tray and the convenient cord storage area on the bottom of the toaster.

3. Setup

1. **Unpack:** Carefully remove the toaster and all packaging materials.
2. **Clean:** Wipe the exterior of the toaster with a damp cloth. Ensure the crumb tray is properly inserted.
3. **Placement:** Place the toaster on a stable, heat-resistant surface, away from flammable materials.
4. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet. The toaster features a 3-foot cord with convenient wire wrap storage underneath the base.
5. **First Use (Burn-off):** Before toasting food for the first time, operate the toaster without bread on the highest browning setting (Level 6) in a well-ventilated area. This will burn off any manufacturing residues and eliminate initial odors.

4. Operating Instructions

1. **Insert Bread:** Place up to two slices of bread, bagels, muffins, or waffles into the extra-wide slots. The 1.6-inch wide slots accommodate various thicknesses.
2. **Select Browning Level:** Turn the browning control knob to your desired shade, from 1 (lightest) to 6 (darkest).
3. **Lower Lever:** Push the toast lever down until it locks into place. The toaster will begin the toasting cycle. The internal guides will center the bread for even toasting.
4. **Use Special Functions (Optional):**
    - **Cancel:** Press the 'Cancel' button at any time to stop the toasting cycle and eject the bread.
    - **Bagel/Muffin:** Press the 'Bagel/Muffin' button after lowering the lever. This function toasts the cut side of bagels or muffins while gently warming the other side.

- **Reheat:** Press the 'Reheat' button after lowering the lever. This warms previously toasted bread without further browning.
- **Defrost:** Press the 'Defrost' button after lowering the lever. This function thaws and then toasts frozen bread.

5. **Ejection:** Once the selected browning cycle is complete, the toast will automatically pop up. Use the **High Lift Lever** to raise smaller items higher for easy and safe removal without touching hot surfaces.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster.

1. **Unplug and Cool:** Always unplug the toaster from the power outlet and allow it to cool completely before cleaning.
2. **Remove Crumb Tray:** Pull out the removable crumb tray located at the bottom of the toaster.
3. **Empty Crumb Tray:** Discard accumulated crumbs. The tray can be rinsed with warm, soapy water if needed. Ensure it is completely dry before reinserting.
4. **Clean Exterior:** Wipe the exterior of the toaster with a soft, damp cloth. For stubborn stains, a mild non-abrasive cleaner can be used. The food-grade stainless steel design is easy to clean and resists rusting.
5. **Never Immerse:** Never immerse the toaster body in water or any other liquid.
6. **Storage:** When not in use, store the toaster in a clean, dry place. Utilize the convenient wire wrap storage under the base to keep the cord tidy.

6. Troubleshooting

If you encounter issues with your Aigostar toaster, refer to the following common problems and solutions:

- **Toaster does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the circuit breaker has tripped.
  - Make sure the toast lever is fully pushed down and locked into place.
- **Bread is not toasting evenly:**
  - Ensure the bread is centered in the slots. The toaster has internal guides for this.
  - Adjust the browning control setting. Lighter settings may result in less even browning depending on bread type.
  - Clean the crumb tray and check for any lodged crumbs or debris in the slots.
- **Smoke coming from the toaster:**
  - Immediately press the 'Cancel' button and unplug the toaster.
  - This is usually caused by crumbs or food pieces stuck inside. Allow the toaster to cool completely, then remove and clean the crumb tray. Gently shake the toaster upside down over a sink to dislodge any remaining debris.
  - Avoid using excessive butter or toppings on bread before toasting, as these can drip and burn.
- **Toast is stuck:**
  - Unplug the toaster.

- Carefully use a non-metallic utensil (like wooden tongs) to remove the stuck bread. Never use metal utensils.

7. Specifications

Brand	Aigostar
Model Number	B30202Y16
Color	Aqua Green
Material	Stainless Steel
Product Dimensions	7"D x 11"W x 7"H
Specific Uses	Bagel, Bread, Grilled Cheese Sandwich, Muffin
Wattage	800 watts
Number of Slices	2
Special Features	Cool Touch Exterior, Defrost Bagel Cancel Reheat Mode, High Lift Carriage, Removable Crumb Tray, Retractable Power Cord
Display Type	LED
Item Weight	2.8 Pounds
Voltage	120V
Number of Browning Settings	6
Number of Programs	4
UPC	850027654300
Date First Available	June 26, 2024

8. Warranty and Support

For warranty information, please refer to the documentation included with your product packaging or visit the official Aigostar website. Aigostar is committed to providing high-quality products and customer satisfaction.
If you require further assistance, have questions about your toaster, or need to report an issue, please contact Aigostar customer service through their official channels. Contact information can typically be found on the product packaging or the Aigostar website.

© 2024 Aigostar. All rights reserved.