Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit BF21

ZdalaMit BF21 Replacement Remote Control User Manual

For Nakamichi Soundbar BF21 38" 2.1 Channel Sound Bar

1. Introduction

This manual provides instructions for the ZdalaMit BF21 Replacement Remote Control. This remote is designed to be compatible with the Nakamichi Soundbar BF21 38" 2.1 Channel Sound Bar. It offers direct functionality without requiring additional programming.

2. Product Overview

The BF21 Replacement Remote Control features a standard layout for controlling your Nakamichi Soundbar. Familiarize yourself with the button functions described below.





Image 1: Front view of the ZdalaMit BF21 Replacement Remote Control. It is black with red and white button labels. Key buttons include Power, Mute, Volume Up/Down, Play/Pause/Pair, Skip Forward/Backward, AUX, Movie, Optical, Music, BT (Bluetooth), News, Source, and EQ.

Button Functions:

- **Power (⏻):** Turns the soundbar on or off.
- **MUTE:** Mutes or unmutes the sound.
- **VOL+** / **VOL-:** Increases or decreases the volume level.
- **◀◀ / ▶▶:** Skip to the previous or next track (for Bluetooth or USB modes, if supported by soundbar).
- **⏯ / PAIR:** Play/Pause media playback. Long press to initiate Bluetooth pairing mode.
- **AUX:** Selects Auxiliary input source.

- **MOVIE:** Activates Movie sound mode.
- **OPTICAL:** Selects Optical input source.
- **MUSIC:** Activates Music sound mode.
- **BT:** Selects Bluetooth input source.
- **NEWS:** Activates News sound mode.
- **SOURCE:** Cycles through available input sources.
- **EQ:** Cycles through equalizer presets (if supported by soundbar).

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert 1 AAA battery, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery cover securely.

Note: This remote control does not require programming. It is designed to work directly with the specified Nakamichi Soundbar BF21 model once batteries are installed.

4. Operating Instructions

To operate your Nakamichi Soundbar BF21 using this remote control, ensure the soundbar is powered on and within direct line of sight of the remote.



Image 2: A hand holding the ZdalaMit BF21 remote control, pointing it towards a soundbar and television setup in a living room. This

illustrates the typical use of the remote control.

Basic Functions:

- **Power On/Off:** Press the Power button once.
- **Adjust Volume:** Press **VOL+** to increase volume, **VOL-** to decrease volume.
- **Mute/Unmute:** Press the **MUTE** button.

Changing Input Sources:

You can select your desired audio input source using the dedicated buttons or the SOURCE button:

- Press **AUX** for auxiliary input.
- Press **OPTICAL** for optical input.
- Press **BT** for Bluetooth input.
- Alternatively, press the **SOURCE** button repeatedly to cycle through available inputs.

Sound Modes:

Enhance your listening experience by selecting different sound modes:

- Press **MOVIE** for a cinematic audio experience.
- Press **MUSIC** for optimized music playback.
- Press **NEWS** for clear dialogue.
- Press **EQ** to cycle through other equalizer presets (if available on your soundbar).

Bluetooth Pairing:

To pair your soundbar with a Bluetooth device using the remote:

1. Ensure your soundbar is in Bluetooth mode (press **BT**).
2. Long press the ▶❚❚ / **PAIR** button on the remote. The soundbar should enter pairing mode (refer to your soundbar's manual for specific indicators).
3. On your Bluetooth device (e.g., smartphone, tablet), search for and select your Nakamichi Soundbar from the list of available devices.
4. Once connected, the soundbar will indicate successful pairing.

5. Maintenance

Cleaning:

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these may damage the remote's surface or internal components.

Battery Replacement:

Replace batteries when the remote's range decreases or it becomes unresponsive. Always replace all batteries at the same time with new ones of the same type (AAA). Do not mix old and new batteries, or different types of batteries.


Storage:

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

6. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed with the correct polarity.
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote and the soundbar's sensor.
  - Ensure you are within the effective range of the soundbar's IR receiver.
- **Specific buttons not working:**
  - Some functions (e.g., track skip, EQ presets) may depend on the soundbar's capabilities and the current input source. Refer to your Nakamichi Soundbar's manual for full compatibility details.

7. Specifications






Image 3: The ZdalaMit BF21 remote control shown with its approximate dimensions: 5.75 inches in length and 1.5 inches in width.

Feature	Detail
Model	BF21
Compatibility	Nakamichi Soundbar BF21 38" 2.1 Channel Sound Bar
Power Source	1 x AAA Battery (not included)
Dimensions (L x W x H)	5.9 x 1.57 x 0.55 inches (approx. 15 x 4 x 1.4 cm)
Weight	1.41 ounces (approx. 40 grams)
Color	Black

8. Warranty and Support

This product is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the documentation provided with your purchase or contact the seller directly.
For technical support or inquiries, please contact your retailer or the manufacturer, ZdalaMit, through their official support channels.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CX48MMZG

More documents and user manuals: **https://manuals.plus/**