Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOSEN MUSIC MS-X81

MOSEN MS-X81 88 Keys Portable Piano Keyboard Instruction Manual

Model: MS-X81 | Brand: MOSEN MUSIC

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your MOSEN MS-X81 88 Keys Portable Piano Keyboard. Please read this manual thoroughly before using the instrument to ensure proper function and longevity.

Package Contents

Verify that all items listed below are included in your package:

- 88 Keys Full-Size Semi-Weighted Keyboard Piano
- Microphone
- Music Stand
- Piano Key Stickers
- USB-C Cable
- Power Adapter



Image: The MOSEN MS-X81 88 Keys Portable Piano Keyboard shown with its included accessories: microphone, music stand, piano key stickers, USB-C cable, and power adapter.

Setup Instructions

1. **Unfolding the Keyboard:** Carefully unfold the 88-key piano. Ensure the two halves lock securely into place. The design allows for 180-degree folding for portability.



Image: Close-up of the single-button folding mechanism on the MOSEN MS-X81 keyboard, illustrating how to fold and unfold the instrument.

2. **Power Connection:** Connect the provided power adapter to the DC IN port on the keyboard and then to a power outlet. Alternatively, the keyboard can operate on its internal battery for up to 10 hours.



Image: The MOSEN MS-X81 keyboard displaying its control panel and indicating its 10-hour battery life, suitable for portable use.

3. **Music Stand Attachment:** Insert the music stand into the designated slots on the top panel of the keyboard.
4. **Microphone Connection:** Plug the microphone into the microphone input port.
5. **Applying Key Stickers (Optional):** For beginners, apply the included piano key stickers to help identify notes.
6. **Connecting External Devices:**
    - **Headphones:** Connect headphones to the headphone jack for private practice.
    - **Sustain Pedal:** Connect a sustain pedal (not included in all packages) to the sustain pedal input for extended note duration.
    - **MIDI/USB:** Use the USB-C port for MIDI connectivity with compatible software or devices.
    - **Audio Input/Output:** Connect external audio sources or output to amplifiers using the respective audio ports.



Image: A detailed view of the versatile interface ports on the MOSEN MS-X81 keyboard, including connections for MP3, MIDI, microphone, audio output, sustain pedal, audio input, and power source.

Operating Instructions

Power On/Off

Press the **POWER** button to turn the keyboard on or off. The LED display will illuminate upon power-on.

Adjusting Volume

Use the **VOLUME +/-** buttons to increase or decrease the overall sound level.

Selecting Tones (Voices)

The MS-X81 features 190 different tones. Press the **TONE** button, then use the number keys or **+/-** buttons to select your desired instrument voice.

Your browser does not support the video tag.

Video: A demonstration of the MOSEN MS-X81 digital piano, highlighting its compact design and various functions, including tone selection and adjustable rhythm. This video shows the keyboard being played and various controls being pressed.

Selecting Rhythms

The keyboard includes 191 rhythms. Press the **RHYTHM** button, then use the number keys or **+/-** buttons to choose a rhythm. Press **START/STOP** to begin or end the rhythm playback.

Demo Songs

Access 80 built-in demo songs by pressing the **DEMO** button. Use the **+/-** buttons to navigate through the songs.

Recording and Playback

To record your performance, press the **RECORD** button. Play your desired piece. Press **PLAY** to listen to your recorded performance.

Teaching Functions

The keyboard features teaching modes to assist with learning. Refer to the specific teaching function buttons on the control panel for detailed usage.

Metronome

Activate the metronome by pressing the **METRONOME** button to assist with timing and rhythm practice.

Transpose Function

Use the **TRANSPOSE** function to shift the pitch of the keyboard up or down in semitone steps without changing your finger positions.

Features Overview

- **88 Semi-Weighted Keys:** Provides a realistic piano feel suitable for beginners and intermediate players.
- **Portable and Foldable Design:** Weighs 7.8 lbs and folds to 25.2 inches for easy transport and storage.
- **Extensive Sound Library:** 191 rhythms, 190 tones, and 80 demo songs for diverse musical exploration.
- **Learning Tools:** Dual keyboard mode, metronome, and teaching functions enhance practice.
- **Long Battery Life:** Up to 10 hours of playing time on a single charge.
- **Connectivity:** USB-C for MIDI, headphone output, microphone input, audio input/output, and Bluetooth.
- **Built-in Speaker:** Integrated speakers for immediate sound output.



Image: An infographic summarizing key features of the MOSEN MS-X81, including 88 standard keys, dual keyboard, LED display, portability, 180-degree foldable design, headphone connection, Bluetooth, app teaching, metronome, 190 rhythms, 190 tones, 80 demo songs, record/play function, top-tier chip, and microphone.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the surface of the keyboard. Avoid abrasive cleaners or solvents.
- **Storage:** When not in use, fold the keyboard and store it in a dry, cool place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge it regularly.
- **Handling:** Handle the keyboard with care, especially when folding and unfolding, to prevent damage to the hinges and keys.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Keyboard does not power on.	Low battery or power adapter not connected properly.	Charge the battery or ensure the power adapter is securely connected.
No sound from speakers.	Volume too low, headphones connected, or speaker malfunction.	Increase volume, disconnect headphones, or contact support if problem persists.
Keys feel too stiff or unresponsive.	This model features semi-weighted keys, which naturally have more resistance than unweighted keys.	This is normal for semi-weighted keys. Continued practice will adapt finger strength.
Sustain pedal not working.	Pedal not connected correctly or incompatible pedal.	Ensure the pedal is fully inserted into the correct port. Verify pedal compatibility.
MIDI connection issues.	Incorrect cable, driver issues, or software settings.	Use the correct USB-C cable. Check computer drivers and MIDI software settings.

Specifications

Feature	Detail
Model Name	MS-X81
Number of Keys	88
Key Type	Semi-Weighted
Dimensions (Folded)	Approximately 25.2 inches (length)
Item Weight	7.8 lbs
Rhythms	191
Tones	190
Demo Songs	80
Connectivity	USB Type C, AC power, MIDI (including USB-MIDI), Bluetooth
Power Source	AC adapter, Internal Rechargeable Battery
Battery Life	Up to 10 hours
Special Feature	Built-In Speaker

Warranty and Support

For warranty information and customer support, please refer to the contact details provided with your purchase documentation or visit the official MOSEN MUSIC website. Keep your proof of purchase for any warranty claims.

© 2025 MOSEN MUSIC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CX59KGH1

More documents and user manuals: **https://manuals.plus/**