vhbw MWD 4823GC

vhbw Glass Turntable Plate for Alaska MWD 4823GC Microwave - 27 cm

Instruction Manual

Product Overview

This manual provides instructions for the vhbw replacement glass turntable plate, specifically designed for the Alaska MWD 4823GC microwave oven. This turntable ensures even heating of food, facilitating efficient food preparation. It is a direct replacement part for a damaged or missing original turntable.



This image shows the top surface of the vhbw glass turntable plate, featuring a smooth, transparent finish and the central Y-shaped support visible through the glass.

Setup and Installation

The turntable plate is designed for easy installation. It features a Y-shaped support on its underside, which fits directly onto the rotating element in the microwave.

Important Note:

The rotating ring, coupler, and drive mechanism are not included with this glass plate. These components are part of your microwave oven and must be present and functional for the turntable to operate correctly.

Installation Steps:

1. Ensure your microwave oven is unplugged from the power outlet before installation to prevent electrical hazards.
2. Place the existing rotating ring (if applicable) and coupler (if applicable) inside the microwave cavity. These components typically sit on the bottom of the microwave.
3. Align the Y-shaped support on the underside of the vhbw glass turntable plate with the microwave's drive mechanism, which is usually a small spindle in the center of the microwave floor.
4. Gently lower the glass plate until it rests securely on the rotating ring and engages with the drive mechanism.
5. Verify that the plate rotates freely by hand. If it does not, re-adjust its position.



This image displays the underside of the vhbw glass turntable plate, highlighting the three small feet and the central Y-shaped

support designed to engage with the microwave's drive mechanism.

Operation

Once installed, the vhbw glass turntable operates automatically with your microwave oven. Place food items centrally on the plate for optimal and even heating. Ensure the plate is clean before each use to prevent food residue from affecting rotation or heating efficiency.

Maintenance

Regular cleaning of the glass turntable plate is recommended to maintain hygiene and performance.

Cleaning Instructions:

1. To clean, carefully remove the plate from the microwave oven.
2. Wash the plate with warm, soapy water. It is also dishwasher safe.
3. Rinse thoroughly to remove all soap residue and dry completely before placing it back into the microwave.
4. Avoid using abrasive cleaners, metal scouring pads, or sharp objects, as these can scratch or damage the glass surface.

Inspect the plate periodically for any chips, cracks, or damage. A damaged plate should be replaced immediately to ensure safe operation and prevent potential hazards.

Troubleshooting

Common Issues and Solutions:

- **Plate does not rotate:**
  - Check if the plate is correctly seated on the rotating ring and engaged with the drive mechanism. Refer to the 'Setup/Installation' section.
  - Ensure there is no obstruction (e.g., food debris) beneath the plate or around its edges that might impede rotation.
  - Verify that the microwave's rotating ring and coupler are present and undamaged. These are essential components of your microwave and are not included with the vhbw plate.
- **Uneven heating:**
  - Ensure food is placed centrally on the turntable for optimal heat distribution.
  - Check if the plate is rotating smoothly. If not, refer to the 'Plate does not rotate' troubleshooting steps.
  - Clean the plate and microwave interior to remove any food debris that might impede rotation or heat distribution.
- **Plate is chipped or cracked:**
  - Discontinue use immediately. A damaged glass plate can be a safety hazard and may break further during operation.
  - Replace with a new vhbw glass turntable plate to ensure safe and proper microwave function.

Specifications

Brand:	vhbw
Model Compatibility:	Alaska MWD 4823GC
Diameter:	27 cm
Material:	Glass
Special Feature:	Y-shaped support
Product Dimensions (L x W x H):	27 x 27 x 1.7 cm
Weight:	647 grams

Warranty and Support

Information regarding warranty terms and customer support for this specific vhbw glass turntable plate is not provided in the available product documentation. For details on warranty coverage, return policies, or technical assistance, please refer to the vhbw official website or contact your original retailer.

© 2024 vhbw. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question