Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Raymate R5

Raymate R5 Bluetooth Speaker User Manual

Model: R5

Introduction

Thank you for choosing the Raymate R5 Bluetooth Speaker. This portable, waterproof speaker is designed to deliver high-fidelity stereo sound for various environments, including home, outdoor activities, and parties. This manual provides essential information on setting up, operating, and maintaining your speaker to ensure optimal performance and longevity.



The Raymate R5 Bluetooth Speaker, showcasing its IPX7 waterproof design with water splashing around it.

Package Contents

Please check the box for the following items:

- Raymate R5 Bluetooth Speaker
- USB-C Charging Cable
- AUX Audio Cable
- Instruction Manual



The Raymate R5 Bluetooth Speaker and its retail packaging.

Product Overview

Controls and Ports

Familiarize yourself with the speaker's buttons and connection ports:



Top panel controls and a diagram of the speaker's features.

- **Power Button ( )**: Press and hold to power on/off. Short press to check battery status.
- **Volume Down** / **Previous Track (-)**: Short press for volume down. Long press for previous track.
- **Play** / **Pause** / **Answer Call (▶)**: Short press to play/pause music. Short press to answer/end calls. Long press to reject calls.
- **Volume Up** / **Next Track (+)**: Short press for volume up. Long press for next track.
- **Mode Button (M)**: Short press to switch between Bluetooth, TF Card, and AUX modes.



Side panel ports and their corresponding icons.

- **USB-C Charging Port**: For charging the speaker.
- **TF Card Slot**: Insert a Micro SD card for MP3 playback.
- **AUX-in Port**: Connect external audio devices via the 3.5mm AUX cable.
- **Carabiner Clip**: Located on the side for easy portability.

Setup

1. Charging the Speaker

1. Connect the provided USB-C charging cable to the speaker's USB-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will illuminate during charging and turn off when fully charged. A full charge takes approximately 3 hours.

2. Bluetooth Pairing

1. Ensure the speaker is fully charged.
2. Press and hold the Power button ( ) for 2-3 seconds to turn on the speaker. The LED indicator will flash blue, indicating it's in pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Raymate R5" from the list of devices.
5. Once paired, the LED indicator will turn solid blue, and you will hear a confirmation tone.

3. True Wireless Stereo (TWS) Pairing

To enjoy enhanced stereo sound, you can pair two Raymate R5 speakers together:

1. Ensure both speakers are powered off and fully charged.
2. Turn on both speakers. They will automatically enter Bluetooth pairing mode (blue LED flashing).
3. On one of the speakers (this will be your primary speaker), double-press the Mode button (M). The speakers will attempt to connect to each other.
4. Once successfully paired, you will hear a confirmation tone, and the LED indicator on the primary speaker will flash blue, while the secondary speaker's LED will turn solid blue.
5. Now, connect your device to the primary speaker ("Raymate R5") via Bluetooth as described in step 2.

Operating Instructions

Basic Functions

- **Power On/Off**: Press and hold the Power button ( ) for 2-3 seconds.
- **Play/Pause**: Short press the Play/Pause button (▶).
- **Volume Adjustment**: Short press the Volume Up (**+**) or Volume Down (**-**) buttons.
- **Skip Track**: Long press the Volume Up (**+**) button for the next track. Long press the Volume Down (**-**) button for the previous track.

Call Management

When connected via Bluetooth, the speaker's built-in microphone allows for hands-free calling:

- **Answer/End Call**: Short press the Play/Pause button (▶) during an incoming call.
- **Reject Call**: Long press the Play/Pause button (▶) during an incoming call.

Mode Switching

Short press the Mode button (M) to cycle through available input modes:

- **Bluetooth Mode**: For wireless audio streaming.
- **TF Card Mode**: For playing MP3 files directly from a Micro SD card.
- **AUX Mode**: For wired connection to audio devices using the 3.5mm AUX cable.

Key Features

IPX7 Waterproof Rating

The Raymate R5 speaker is designed with IPX7 waterproofing, offering protection against immersion in water up to 1 meter for 30 minutes. This makes it suitable for use in various environments, including by the pool, at the beach, or in the bathroom.



The speaker's IPX7 waterproof design and integrated carabiner clip for portability.

Portable Design

Its compact and lightweight design, coupled with a convenient carabiner clip, allows for easy transport. Attach it to your bag or other belongings for music on the go.

Extended Playtime

Equipped with a 3600mAh high-capacity battery, the speaker provides over 15 hours of continuous playtime on a single charge, ensuring your music lasts throughout your activities.

HiFi Stereo Sound

Experience clear, balanced, and powerful audio with 20W output and HiFi stereo sound. The speaker is engineered for an immersive listening experience.

Official Product Video

Your browser does not support the video tag.

An official product video demonstrating the Raymate R5 Bluetooth Speaker's features, including unboxing, controls, charging, and waterproof capabilities.

Maintenance

- Keep the speaker away from extreme temperatures and direct sunlight.
- Clean the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.

- Ensure the port cover is securely closed when using the speaker near water to maintain its waterproof integrity.
- Store the speaker in a cool, dry place when not in use for extended periods.

Troubleshooting

Problem	Solution
Speaker does not turn on.	Ensure the speaker is charged. Connect it to a power source using the USB-C cable.
Cannot pair via Bluetooth.	◦ Ensure the speaker is in pairing mode (flashing blue LED). ◦ Make sure Bluetooth is enabled on your device. ◦ Move the speaker closer to your device (within 10 meters). ◦ Forget "Raymate R5" from your device's Bluetooth list and try pairing again.
No sound.	◦ Check the volume levels on both the speaker and your connected device. ◦ Ensure the speaker is in the correct mode (Bluetooth, TF Card, or AUX). ◦ If using AUX, ensure the cable is fully inserted and functional.
TWS pairing failed.	◦ Ensure both speakers are powered off before starting TWS pairing. ◦ Follow the TWS pairing steps carefully, double-pressing the Mode button on only one speaker. ◦ Make sure no other Bluetooth devices are connected to either speaker during TWS pairing.

Specifications

Feature	Detail
Brand	Raymate
Model Name	R5
Connectivity Technology	Bluetooth V5.0
Speaker Maximum Output Power	20 Watts
Audio Output Mode	Stereo
Water Resistance Level	IPX7 (Waterproof)
Battery Capacity	3600 mAh (Approx.)
Playtime	Up to 1000 minutes (approx. 16.6 hours)
Charging Time	3 Hours
Wireless Range	Up to 10 meters (33 feet)
Control Method	Touch Buttons
Material	Acrylonitrile Butadiene Styrene (ABS), Thermoplastic Polyurethane (TPU)
Product Dimensions	2.76"D x 2.76"W x 5.91"H

Feature	Detail
Item Weight	0.62 Kilograms (1.37 pounds)
Compatible Devices	Smartphones, Tablets, MP3 Players, Laptops, Desktops, Televisions, Projectors

Warranty and Support

The Raymate R5 Bluetooth Speaker comes with a limited warranty. For detailed warranty information, product support, or technical assistance, please refer to the contact information provided with your purchase or visit the official Raymate website.

© 2024 Raymate. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CY1YF7SX

More documents and user manuals: **https://manuals.plus/**