Ariete 4633

Ariete 4633 4L Air Fryer Instruction Manual

Model: 4633

1. Introduction

Thank you for choosing the Ariete 4633 4L Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods, using hot air circulation to achieve crispy results with minimal oil. This manual provides comprehensive instructions for the safe and efficient use, maintenance, and troubleshooting of your new air fryer. Please read it thoroughly before first use and keep it for future reference.



Image: The Ariete 4633 4L Air Fryer, showcasing its compact design and digital control panel.

2. Important Safety Instructions

- Read all instructions carefully before operating the appliance.
- Do not immerse the main unit, cord, or plug in water or any other liquid to prevent electric shock.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep the appliance and its cord out of reach of children.
- Ensure the appliance is placed on a stable, level, and heat-resistant surface, away from walls or other appliances to allow adequate air circulation.

- Do not block the air inlet or outlet vents during operation.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool completely before handling or cleaning.
- Do not touch hot surfaces. Use oven mitts or handles.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use accessories not recommended by the manufacturer, as this may cause injuries.

3. Product Components and Controls

The Ariete 4633 Air Fryer consists of a main unit, a removable frying basket, and a digital touch control panel. Familiarize yourself with these components for optimal use.

3.1 Main Unit and Basket



Image: This image displays the Ariete 4633 Air Fryer, highlighting its 4L capacity, hot air cooking technology, digital touch screen panel, and the ability to fry with just one spoon of oil. Various views of the appliance are shown, including the basket and control panel.

3.2 Digital Touch Control Panel

The intuitive digital touch control panel allows for easy operation and program selection.



Image: This image illustrates the digital control panel of the Ariete 4633 Air Fryer, detailing the 9 preset programs available for different food types such as fries, fresh potatoes, red meat, fish, chicken, pizza, desserts, and defrosting. The temperature and timer display are also visible.

- **Power Button:** Turns the appliance on/off.
- **Temperature Control:** Adjusts cooking temperature (up to 200°C).
- **Timer Control:** Sets cooking time.
- **Preset Program Selection:** Cycles through 9 pre-programmed cooking settings.
- **Grill Function:** Activates the grilling mode.
- **Shake Reminder:** Indicates when to shake the basket for even cooking.

- **Start/Pause Button:** Initiates or pauses the cooking process.

4. Before First Use / Setup

1. Unpack the air fryer and all its accessories. Remove any packaging materials, stickers, or labels.
2. Clean the frying basket and pan thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse well and dry completely.
3. Wipe the interior and exterior of the main unit with a damp cloth. Do not use abrasive cleaners.
4. Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm of free space around the back and sides of the appliance for proper ventilation.
5. Plug the power cord into a grounded wall outlet. The appliance is now ready for use.

5. Operating Instructions

5.1 Basic Operation

1. Place the food you wish to cook into the frying basket. Do not overfill the basket beyond the MAX indication.
2. Slide the frying basket back into the main unit until it clicks securely into place.
3. Press the **Power Button** to turn on the appliance. The digital display will illuminate.
4. Adjust the desired cooking temperature and time using the respective control buttons.
5. Press the **Start/Pause Button** to begin the cooking process.
6. During cooking, hot air circulates within the appliance.



Image: This diagram illustrates the hot air circulation system within the Ariete 4633 Air Fryer, showing how air flows to cook food evenly.

7. Once the set cooking time has elapsed, the appliance will beep, indicating that cooking is complete. Carefully pull out the basket and remove the food.

5.2 Preset Programs

The Ariete 4633 Air Fryer features 9 convenient preset programs for various food types:

- Fries
- Fresh Potatoes
- Red Meat
- Fish
- Chicken
- Pizza
- Desserts
- Defrost
- Custom (manual setting)

To use a preset program, press the **Program Selection Button** repeatedly until the desired program icon is displayed. The appliance will automatically set the optimal temperature and time. You can manually adjust these settings if desired before pressing the **Start/Pause Button**.

5.3 Grill and Shake Functions

- **Grill Function:** Activate this function for recipes that require grilling. Refer to specific recipes for recommended use.
- **Shake Reminder:** For certain foods, the air fryer will emit an audible alert and display a 'Shake' icon to remind you to shake the basket halfway through the cooking cycle. This ensures even cooking and browning. Carefully remove the basket, shake its contents, and reinsert it to resume cooking.

6. Cooking Guide

For optimal results, consider the following tips:

- **Preheating:** For best results, preheat the air fryer for 3-5 minutes at the desired cooking temperature before adding food.
- **Oil Usage:** While air frying requires significantly less oil than traditional frying, a small amount (approximately 1 tablespoon) of oil can be added to fresh ingredients like potatoes or vegetables to enhance crispiness and flavor.



Image: This image demonstrates adding a small amount of oil, approximately one tablespoon, to fresh fries in the air fryer basket before cooking. This step helps achieve a crispier texture.

- **Shaking:** For smaller items like fries, nuggets, or chicken wings, shaking the basket halfway through cooking ensures even browning and crispiness.
- **Do Not Overfill:** Avoid overloading the basket, as this can prevent proper air circulation and lead to uneven cooking. Cook in batches if necessary.
- **Food Variety:** The Ariete 4633 Air Fryer is versatile and can cook a wide range of foods, from frozen snacks to fresh meats, vegetables, and even desserts.



Image: This image showcases various dishes that can be prepared using the Ariete 4633 Air Fryer, including fried chicken, fish, vegetables, and fries, illustrating the appliance's versatility.



Image: A close-up view of the air fryer basket filled with golden-brown fries, alongside other cooked items like onion rings and pizza, demonstrating the appliance's cooking capabilities.

7. Cleaning and Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your air fryer.

1. Always unplug the appliance from the power outlet and allow it to cool down completely before cleaning.
2. **Frying Basket and Pan:** These parts are dishwasher safe. Alternatively, clean them with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak them in hot water for about 10 minutes before cleaning.
3. **Interior of the Appliance:** Wipe the interior with a damp cloth and a mild detergent if necessary. Do not use abrasive sponges or metal brushes.
4. **Exterior of the Appliance:** Wipe the exterior with a damp cloth. Do not use harsh or abrasive cleaning agents.
5. Ensure all parts are thoroughly dry before reassembling and storing the appliance.

8. Troubleshooting

If you encounter any issues with your Ariete 4633 Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Power cord not plugged in; Basket not inserted correctly.	Ensure the power cord is securely plugged into a grounded outlet. Push the frying basket firmly into the main unit until it clicks.
Food is not cooked evenly.	Basket is overloaded; Food not shaken during cooking.	Do not overfill the basket. Cook in smaller batches if necessary. Shake the basket halfway through cooking for even results.
White smoke comes from the appliance.	Fatty residue from previous use; Excess oil on food.	Clean the basket and pan thoroughly after each use. Ensure food is not excessively oily. If smoke persists, contact customer support.
Appliance emits an unusual odor.	Normal during first few uses; Residue inside.	This is normal for new appliances. Ensure proper ventilation. If odor persists after several uses, clean the interior thoroughly.

9. Technical Specifications

Below are the technical specifications for the Ariete 4633 Air Fryer:

Specification	Detail
Brand	Ariete
Model Number	4633
Color	White
Capacity	4 Liters
Power	1400 Watts
Material	Plastic
Special Features	Air frying, grill and shake function, 9 preset programs
Dimensions (D x W x H)	34.5 cm x 26 cm x 29 cm

Specification	Detail
Control Method	Touch



Image: This image provides the dimensions of the Ariete 4633 Air Fryer, showing its height as 29 cm, width as 26 cm, and depth as 34.5 cm.

10. Warranty and Customer Support

Warranty information for the Ariete 4633 Air Fryer is typically provided with the product packaging or can be found on the manufacturer's official website. Please refer to these sources for details regarding warranty coverage and terms.

For technical assistance, spare parts, or service inquiries, please contact Ariete customer support through their official channels. Information regarding the availability of spare parts was not provided in the product details.

Always ensure you have your product model number (4633) and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question