Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

charmast W1148

Charmast Portable Charger Instruction Manual

Model: W1148

Introduction

Welcome to your new Charmast Portable Charger. This slim, high-capacity power bank is designed to keep your devices charged on the go, featuring multiple built-in cables and versatile charging options. Its compact design makes it an ideal companion for travel, work, or daily use, ensuring your devices never run out of power.

Image: The Charmast Portable Charger (Model W1148) in dark color, showcasing its sleek design and integrated cables.

Package Contents

- 1 x Charmast 10000mAh Power Bank
- 1 x User Manual
- 1 x Mesh Pouch

Image: Contents of the Charmast Portable Charger package, including the power bank, user manual, and mesh pouch.

Key Features

- **Built-in 4 Cables:** Includes 3 output cables (for iPhone, USB-C, Micro-USB) and 1 input cable for recharging.
- **6 Outputs & 3 Inputs:** Charge up to 6 devices simultaneously with various output ports and recharge the power bank using 3 different input options.
- **Slim & Lightweight Design:** Compact dimensions (5.68"x2.63"x0.69") and light weight (0.55lb) for easy portability.

- **Digital LED Display:** Accurately shows the remaining battery percentage.
- **Universal Compatibility:** Supports a wide range of devices including iPhone, Samsung, Google Pixel, other Android phones, tablets, and more.

Image: A visual representation of the Charmast power bank highlighting its four built-in cables for various device types.

Image: The power bank connected to multiple devices, demonstrating its capability to charge up to six devices at once.

Image: A person holding the Charmast power bank, illustrating its ultra-slim and lightweight design for easy portability.

Initial Setup

Before first use, it is recommended to fully charge your Charmast Portable Charger.

Charging the Power Bank

The power bank can be recharged using its built-in USB-A input cable, a USB-C input, or a Micro-USB input.

1. Connect the built-in USB-A cable to a compatible USB wall adapter (not included) or a computer USB port.

2. Alternatively, use a USB-C cable or Micro-USB cable to connect the respective input ports on the power bank to a power source.
3. The digital LED display will show the charging progress. A full charge typically takes approximately 6.0 hours via the built-in USB-A input or 4.5 hours via 15W USB-C input.

Image: Diagram illustrating the two primary ways to recharge the power bank: via the built-in USB-A cable or a USB-C input, along with estimated charging times.

Operating Instructions

Charging Your Devices

The Charmast Portable Charger offers multiple output options to charge your electronic devices.

1. Identify the correct built-in cable for your device (Lightning for iPhone/iPad, USB-C for Android/newer devices, Micro-USB for older Android/accessories).
2. Connect the appropriate built-in cable directly to your device's charging port.
3. For additional devices, use your own USB-A or USB-C cables with the available output ports on the power bank.
4. The power bank will automatically begin charging your connected device(s).

Checking Battery Level

Press the power button once to activate the digital LED display, which shows the remaining battery percentage.

Device Compatibility

This power bank is designed for wide compatibility with various popular electronic devices.

- iPhone Series (e.g., iPhone 13, 12, 11, 8, 7, XR, XS Max)
- Samsung Series (e.g., S22, S21, S20, A52, A32, Z Fold series, Z Flip series)
- Google Pixel Series
- Other Android Phones
- Tablets (e.g., iPad)
- Headphones and other Micro-USB powered devices

Image: An illustration showing the power bank charging various devices like iPhones, Samsung phones, Pixel phones, tablets, and headphones, emphasizing its broad compatibility.

Care and Maintenance

- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Do not expose the power bank to water or excessive moisture.
- For optimal battery health, charge the power bank fully at least once every three months if not in regular use.
- Clean the exterior with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.

Troubleshooting

Problem	Possible Cause	Solution
Power bank not charging	Cable not properly connected; Power source issue; Power bank battery depleted	Ensure all cables are securely connected. Try a different wall adapter or USB port. Allow sufficient time for charging.
Device not charging from power bank	Incorrect cable used; Device not compatible; Power bank battery depleted	Ensure the correct built-in cable or external cable is used for your device. Check power bank battery level. Verify device compatibility.
Slow charging	Using a low-power adapter; Multiple devices charging simultaneously; Cable issue	Use a higher wattage adapter for faster recharging. Charging multiple devices may reduce individual charging speed. Try a different cable.
Digital display not working	Power button not pressed; Device malfunction	Press the power button firmly. If issue persists, contact customer support.

Product Specifications

Feature	Detail
Model Number	W1148
Battery Capacity	10000 Milliamp Hours
Product Dimensions	5.68 x 2.63 x 0.7 inches
Item Weight	8.8 ounces
Special Features	Built In Cable
Connector Type	For iPhone, Android
Manufacturer	Dong guan Utopia-Originality Technology Co., Ltd
Color	Dark

Warranty and Support

Your Charmast Portable Charger comes with an 18-month warranty and lifetime technical support. For any inquiries or assistance, please refer to the contact information provided in your package or visit the official Charmast website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CY2JJ4WS

More documents and user manuals: **https://manuals.plus/**