Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UBeesize C72

UBeesize 72-inch Magnetic Tripod with Remote Instruction Manual

Model: C72

Introduction

Thank you for choosing the UBeesize 72-inch Magnetic Tripod with Remote. This versatile accessory functions as both an extendable selfie stick and a stable tripod, designed for capturing photos and videos with your smartphone. It features magnetic attachment for MagSafe compatible devices and includes a silicone clip for other phones, along with a wireless Bluetooth remote for convenient operation.

Please read this manual carefully before use to ensure proper setup and operation.

Package Contents

- 1 x UBeesize 72-inch Magnetic Tripod Selfie Stick
- 1 x Wireless Bluetooth Remote
- 1 x Auxiliary Silicone Phone Clip

Product Features

- **Extendable Height:** Adjusts from a compact 15 inches to an extended 72 inches using a 6-section telescopic pole.
- **Magnetic Attachment:** Built-in N52 magnetic ring for secure attachment of MagSafe compatible iPhones (iPhone 12 series and newer) and MagSafe cases.
- **Auxiliary Silicone Clip:** Provides secure holding for non-magnetic phones or for enhanced protection.
- **Wireless Remote:** Detachable Bluetooth 5.0 remote shutter with a range of up to 33 feet (10 meters) for hands-free photo and video capture.
- **Adjustable Angles:** Features 180° neck rotation and 360° head rotation for flexible shooting perspectives.
- **Durable Construction:** Made from lightweight aluminum material.



Image: Magnetic phone attachment mechanism, highlighting the secure hold for MagSafe compatible devices.



Image: The detachable wireless remote control, illustrating its Bluetooth range and compatibility with Android 4.4+ and iOS 6+ devices.

Image: Visual representation of the tripod's adjustable height (15 to 72 inches) and the 180° neck and 360° head rotation capabilities.

Image: The auxiliary silicone clip, designed to securely hold non-magnetic phones or provide additional protection for any device.

Image: Overview of the tripod's universal compatibility, showcasing various iPhone (15, 14, 13, 12/11 series) and Samsung Galaxy (S23, S22, S21/20, Note 20/10/9/8) models.

Setup Instructions

1. **Open the Tripod Legs:** Gently pull out one leg of the tripod, then spread the other two legs outwards until they are fully extended and stable. The legs will fully deploy only after the center hub is pulled up.
2. **Extend the Tripod Pole:** Hold the magnetic head and push the center hub downwards. Simultaneously, pull the telescopic pole upwards to extend it to your desired height. Ensure all sections are securely locked.
3. **Adjust and Lock Angle:** Loosen the knob on the side of the magnetic head by turning it counter-clockwise. Adjust the phone holder to your desired angle (180° neck rotation, 360° head rotation), then turn the knob clockwise to secure it.

   CAUTION: Do NOT force the magnetic head without loosening the knob. This may damage or loosen the joint.
4. **Attach Your Phone:**
   - **For MagSafe Compatible Phones:** Simply align your iPhone (12 series or newer) or MagSafe case with the magnetic head. The phone will snap into place securely.
   - **For Non-Magnetic Phones:** Attach the auxiliary silicone phone clip to the magnetic head. Place your phone securely within the silicone clip.

Image: Detailed steps on how to properly open the tripod legs, extend the pole, and adjust the head angle.

Operating Instructions

Using the Wireless Remote

1. **Pairing:** Turn on the remote by pressing and holding the button until the indicator light flashes. On your phone, go to Bluetooth settings and select "UBeesize Remote" (or similar) to pair. The light will stop flashing once paired.
2. **Capturing Photos/Videos:** Open your phone's camera app. Press the button on the remote to take a photo or start/stop video recording.
3. **Power Off:** Press and hold the remote button again until the indicator light turns off to conserve battery.

Compatibility

The UBeesize Magnetic Tripod is compatible with a wide range of smartphones:

- **Direct Magnetic Attachment (MagSafe):** iPhone 15 Series (15/15 Pro/15 Pro Max), iPhone 14 Series (14/14 Pro/14 Pro Max), iPhone 13 Series (13/13 Pro/13 Pro Max/13 mini), iPhone 12 Series (12/12 Pro/12 Pro Max/12

mini), or phones with MagSafe compatible cases.

- **Via Auxiliary Silicone Clip:** Most Android phones and older iPhone models (e.g., iPhone 11 series, iPhone X/XS/XR, iPhone 8/7/6S/6 series) that fit within the clip's dimensions.

Maintenance

- Clean the tripod with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the tripod in a cool, dry place when not in use.
- Ensure the telescopic pole sections are clean and free of debris to prevent sticking.
- Periodically check all screws and joints for tightness.

Troubleshooting

Remote Control Issues:

- **Remote not pairing:** Ensure the remote is charged (if applicable) and within 33 feet (10 meters) of your phone. Turn off and on both the remote and your phone's Bluetooth, then try pairing again.
- **Remote not taking photos:** Check if the remote is successfully paired. Ensure your phone's camera app is open and active.

Tripod Stability Issues:

- **Unstable tripod:** Ensure all three legs are fully extended and placed on a flat, stable surface.
- **Phone not holding securely:** For magnetic attachment, ensure your phone or case is MagSafe compatible. For the silicone clip, ensure the phone is properly seated and the clip is tight.

For more detailed troubleshooting, please refer to the officialTroubleshooting Guide (PDF).

Specifications

Feature	Detail
Brand	UBeesize
Model Name	72" Magnetic Tripod
Model Number	C72 (UB-C72YPGBK)
Material	Aluminum
Color	Black
Maximum Height	72 inches (183 cm)
Minimum Height	15 inches (38 cm)
Folded Size	15 inches (38 cm)
Item Weight	16 ounces (453 grams)
Weight Limit	11.2 ounces (317 grams)
Number of Leg Sections	6

Tripod Head Type	Ball Heads
Wireless Remote Technology	Bluetooth 5.0
Wireless Remote Range	Up to 33 feet (10 meters)
UPC	840322305823

Warranty and Support

The UBeesize 72-inch Magnetic Tripod comes with a 1-year manufacturer's warranty.

For further assistance, please refer to theTroubleshooting Guide (PDF) or contact UBeesize customer support.

© 2026 UBeesize. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CY2NH57B

More documents and user manuals: **https://manuals.plus/**