OMISOON DH-ICM01

OMISOON Ice Maker User Manual

Model: DH-ICM01

Introduction

Thank you for choosing the OMISOON Ice Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.



Image: The OMISOON Ice Maker, a compact black unit, is shown with a clear window displaying freshly made ice cubes. Beside it, a glass with a blue drink and ice, along with an ice scoop, highlights its function.

Product Overview

The OMISOON Ice Maker is designed for convenient and rapid ice production, suitable for various settings from home kitchens to offices and outdoor events. It features a self-cleaning function and offers two ice cube sizes.

Key Features:

- **Efficient Ice Production:** Produces 9 ice cubes in 6-8 minutes, with a daily capacity of up to 12 kg (26 pounds).
- **Two Ice Cube Sizes:** Choose between large and small ice cubes to suit your needs.
- **Self-Cleaning Function:** Simplifies maintenance and ensures hygienic ice production.
- **User-Friendly Design:** Features a transparent front window with ambient light, LED indicators for 'ice full' and 'add water', and a convenient side drainage outlet.
- **Compact and Portable:** Lightweight design for easy transport and placement on countertops.
- **Safe Materials:** Constructed with food-grade ABS material for safe and taste-free ice.

What's in the Box:

- OMISOON Ice Maker
- Ice Basket
- Ice Scoop
- User Manual

Setup

1. **Unpacking:** Carefully remove the ice maker from its packaging. Inspect for any damage. Remove all packing materials, tape, and labels.
2. **Placement:** Place the ice maker on a stable, level surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit.
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker.
    - Open the lid and remove the ice basket.
    - Clean the interior with a soft cloth and warm water with a mild detergent.
    - Rinse thoroughly and drain any remaining water through the side drainage outlet.
    - Dry the interior completely before adding water.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Image: A visual guide demonstrating the simple operation steps: 1) Add water below the MAX line, 2) Press the ON/OFF button and select ice size, 3) Wait for 6-8 minutes, 4) Remove ice cubes with the scoop.

Operating Instructions

1. **Add Water:** Open the lid and fill the water reservoir with potable water up to the "MAX" fill line. Do not overfill.
2. **Power On and Select Ice Size:**
    - Press the **POWER** button to turn on the ice maker.
    - Press the **SELECT** button to choose your desired ice cube size:**Large Ice** or **Small Ice**. The corresponding indicator light will illuminate.
    - *Note:* If the room temperature is below 15°C (59°F), it is recommended to use small ice cubes. If the room temperature is above 30°C (86°F), large ice cubes are recommended.
3. **Ice Production:** The ice maker will begin the ice-making cycle. The first batch of ice cubes will be ready in approximately 6-8 minutes. Subsequent batches may be produced more quickly.

- The transparent front window allows you to monitor the ice production process.
- The **Ice Full Indicator** will light up when the ice basket is full. The machine will automatically pause production.
- The **Add Water Indicator** will light up when the water level is low. The machine will pause production until water is refilled.

4. **Remove Ice:** Use the provided ice scoop to remove ice cubes from the basket. Ice cubes cannot be stored in the machine for extended periods as they will melt. Transfer them to a freezer for storage.
5. **Turn Off:** Press the **POWER** button to turn off the ice maker when you are finished.



Image: A close-up view illustrating the efficient ice-making process, showing water being frozen into 9 ice cubes in approximately 6 minutes.



Image: This image displays the two available ice cube sizes: large bullet-shaped ice ideal for whiskey and cocktails, and small bullet-shaped ice suitable for juice and soda.

Maintenance

Self-Cleaning Function:

The ice maker is equipped with a self-cleaning function for easy and thorough cleaning.

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the **CLEAN** button (often combined with the ON/OFF button, refer to control panel image) for a few seconds until the self-cleaning cycle begins.
3. The cleaning cycle typically takes about 30 minutes. The machine will circulate water to clean its internal components.
4. Once the cycle is complete, drain the dirty water through the side drainage outlet.
5. Rinse the interior with fresh water and drain again.



Image: A visual representation of the self-cleaning function, showing water swirling inside the ice maker, indicating a 30-minute cleaning cycle activated by a single press.

Regular Cleaning:

- **Exterior:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Ice Basket and Scoop:** Wash the ice basket and scoop with warm, soapy water regularly. Rinse thoroughly and dry.
- **Water Reservoir:** Periodically clean the water reservoir to prevent mineral buildup. For stubborn deposits, use a solution of water and vinegar (1:1 ratio), let it sit for 15-20 minutes, then scrub and rinse thoroughly.
- **Drainage:** Always ensure the side drainage outlet is clear and accessible for easy water removal.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir. Power not connected. Ambient temperature too high.	Fill water reservoir to MAX line. Ensure unit is properly plugged in. Operate in a cooler environment.
"Add Water" indicator is on.	Water level is low.	Add water to the reservoir.
"Ice Full" indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice cubes are thin or melt quickly.	First few batches. High room temperature.	The first 3-4 batches are often thinner. Subsequent batches will be thicker. Use large ice cube setting in warmer conditions.
Unusual noise during operation.	Normal operation sounds (compressor, water pump). Unit not level.	This is normal. Ensure the ice maker is on a flat, stable surface.

If the problem persists after trying the above solutions, please contact customer support.

Specifications

Attribute	Value
Brand	OMISOON
Model Number	DH-ICM01
Product Dimensions (L x W x H)	34.7 x 22 x 30 cm (13.66 x 8.66 x 11.81 inches)
Item Weight	6.9 Kilograms (15.21 lbs)
Ice Production Capacity	Up to 12 kg (26 lbs) per 24 hours
Power	130 Watts
Voltage	230 Volts
Material	Plastic (Food-grade ABS)
Refrigerant	R600a

Warranty and Support

For warranty information and customer support, please refer to the contact details provided with your purchase or visit the official OMISOON website. Keep your purchase receipt as proof of purchase for warranty claims.
Contact Information: Please refer to the contact information provided on the product packaging or the official OMISOON website for support.

© 2024 OMISOON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question