Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

zila FCKC

zila HD Kids Digital Camera FCKC User Manual

Model: FCKC

Introduction

Thank you for choosing the zila HD Kids Digital Camera. This camera is designed for children aged 4-8 years, offering a fun and durable way to capture memories. It features 8MP photo resolution, 1080P video recording, a 2.0-inch LCD display, and IP54 waterproof and dustproof protection. Please read this manual carefully to ensure proper use and maintenance of your camera.

Product Overview

Familiarize yourself with the camera's components and controls.



Image: Product Structure Diagram. This image illustrates the various parts of the camera, including the lens, microphone, display, and control buttons.

Camera Components:

- **Lens:** Captures photos and videos.
- **Microphone:** Records audio during video capture.
- **Display (2.0-inch LCD):** Shows menus, photos, and videos.
- **Power Button:** Turns the camera on/off.
- **Camera Button:** Takes photos or starts/stops video recording.
- **Play Button:** Enters playback mode to view media.
- **Set Buttons:** Accesses settings and confirms selections.
- **Navigation Buttons (Up, Down, Left, Right):** Used for menu navigation and digital zoom.
- **SD Card Slot:** For inserting a Micro SD card (up to 32GB).
- **USB Port:** For charging and data transfer.
- **Reset Button:** Used to reset the camera if it becomes unresponsive.

Setup

1. Charging the Battery

The camera is equipped with a built-in 1000MAH Li-ion battery. Before first use, fully charge the camera.

1. Locate the USB port on the camera.
2. Connect the provided USB charging cable to the camera's USB port.
3. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
4. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.
5. A full charge typically provides 1-2 hours of continuous use.

2. Inserting a Micro SD Card

While the camera has 1GB of built-in memory, a Micro SD card (up to 32GB, not included) is recommended for storing more photos and videos.

1. Locate the Micro SD card slot, usually protected by a cover.
2. Gently open the cover.
3. Insert the Micro SD card with the metal contacts facing the correct direction (refer to the diagram near the slot). Push until it clicks into place.
4. Close the cover securely to maintain waterproof and dustproof integrity.

Operating Instructions

1. Power On/Off

- To power on: Press and hold the **Power Button** for a few seconds.
- To power off: Press and hold the **Power Button** again until the screen turns off.

2. Taking Photos

1. Ensure the camera is in photo mode (indicated by an icon on the screen). If not, use the navigation buttons to switch modes.
2. Frame your shot using the LCD display.
3. Press the **Camera Button** to take a picture.
4. Use the Up/Down navigation buttons for 4X digital zoom.

3. Recording Videos



Image: Video Record Function. This image highlights the camera's ability to record videos, showing a pink camera model in action.

1. Switch to video recording mode using the navigation buttons.
2. Press the **Camera Button** once to start recording. A red recording indicator will appear on the screen.
3. Press the **Camera Button** again to stop recording.

4. Playback Mode

- Press the **Play Button** to enter playback mode.
- Use the Left/Right navigation buttons to browse through your photos and videos.
- To exit playback mode, press the **Play Button** again or the **Power Button**.

5. Selfie Mode



Image: Enjoy Selfie Time. This image demonstrates the camera's selfie mode, showing children taking a picture of themselves.

The camera supports a selfie mode, allowing children to easily take pictures of themselves or with friends.

- Switch to selfie mode (refer to on-screen icons or manual for specific button combination).
- Position the camera to capture your desired selfie.
- Press the **Camera Button** to take the selfie.

6. Fun Photo Frames and Stickers



Image: Funny Frames & Stickers & Filters. This image showcases the creative options available, such as various frames, stickers, and color filters.

The camera includes 12 kinds of cute stickers and 7 kinds of photo frames to enhance creativity. You can also switch between color and black-and-white photo modes.

- In photo mode, use the navigation buttons to access the frames/stickers menu.
- Select your desired frame or sticker and press the**Set Button** to apply.
- To change color modes, navigate to the filter options in the menu.

Maintenance

1. Waterproof and Dustproof Care



Image: Waterproof Camera. This image shows the camera being used near water, highlighting its IP54 waterproof feature.

The camera features IP54 waterproof and dustproof technology, allowing for use in various environments and protection against splashes and dust. It is waterproof up to 1 meter depth.

- Ensure all port covers (USB, SD card) are securely closed before exposing the camera to water or dust.
- Do not submerge the camera beyond 1 meter depth or for extended periods.
- After exposure to water, wipe the camera dry with a soft, clean cloth.
- Avoid using harsh chemicals or abrasive materials for cleaning.

2. General Cleaning

- Use a soft, dry cloth to clean the camera body.
- For the lens, use a specialized lens cleaning cloth to avoid scratches.

3. Battery Care and Storage

- Charge the battery regularly, even if the camera is not in frequent use, to maintain battery health.
- Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **Camera does not turn on:**
  Ensure the battery is charged. Connect the camera to a charger and try again. If unresponsive, press the Reset button with a thin object (e.g., paperclip).
- **Cannot take photos/record videos:**
  Check if a Micro SD card is inserted correctly and has sufficient free space. The camera has 1GB built-in memory, but an SD card is recommended for extensive use.
- **Poor image/video quality:**
  Ensure the lens is clean and free from smudges. Check lighting conditions.
- **Camera freezes or becomes unresponsive:**
  Use a thin object to press the Reset button located on the camera body. This will restart the camera without deleting data.
- **Water ingress:**
  If water enters the camera despite closed covers, immediately power off the camera and allow it to dry completely in a well-ventilated area. Do not attempt to use it until fully dry.

Specifications

Feature	Specification
Model Name	FCKC
Photo Resolution	8 MP
Video Resolution	1080P (1920*1080P/25FPS)
LCD Screen Size	2.0 Inches
Digital Zoom	4 x
Viewing Angle	140 Degrees
Water Resistance Rating	IP54 (Waterproof up to 1 Meter)
Supported File Format	AVI, JPG
Built-in Memory	1 GB
Micro SD Card Support	Up to 32 GB
Battery Type	1000MAH Li-ion battery (included)
Connectivity	USB
Item Weight	0.1 Kilograms
Manufacturer	zila

Warranty and Support

For warranty information and customer support, please refer to the packaging or contact the manufacturer directly.
Keep your purchase receipt as proof of purchase.
Manufacturer: zila

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYC28FVK

More documents and user manuals: **https://manuals.plus/**