Ariete 1998

Ariete 1998 Double Portable Induction Hob User Manual

Model: 1998

1. Introduction

Thank you for choosing the Ariete 1998 Double Portable Induction Hob. This appliance is designed for efficient and fast cooking, suitable for various environments including your kitchen, camping trips, or office. Please read this manual carefully before using the appliance to ensure safe and optimal operation.



Figure 1: Ariete 1998 Double Portable Induction Hob

This image shows the Ariete 1998 Double Portable Induction Hob, featuring two cooking zones with individual digital displays and touch controls. The hob has a sleek black ceramic glass surface.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, injury to persons, or damage to the appliance, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.

- Close supervision is necessary when any appliance is used by or near children. This appliance features a child protection function.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The appliance has an automatic shut-off feature after 2 hours of inactivity for safety.
- Use only induction-compatible cookware with a flat bottom and a diameter up to 27 cm.
- Do not place metallic objects such as knives, forks, spoons, and lids on the hob surface as they can get hot.

3. Product Overview

The Ariete 1998 Double Portable Induction Hob features two independent cooking zones, each with its own control panel and digital display. The ceramic glass surface is durable and easy to clean.

3.1 Control Panel

Each cooking zone is equipped with a touch-sensitive control panel for easy operation. The main controls include:

- **ON/OFF Button:** To power the hob on or off.
- **MAX/MIN Buttons:** For quick adjustment to maximum or minimum power levels.
- **'+' and '-' Buttons:** To increase or decrease power levels and timer settings.
- **Keep Warm Button:** To activate the keep warm function.
- **Function Button:** To cycle through various cooking functions or settings.
- **Child Lock Indicator:** Indicates when the child safety lock is active.



Figure 2: Close-up of the Left Control Panel

This image provides a detailed view of the left control panel, showing the digital display, MAX/MIN buttons, Keep Warm button, '+' and '-' buttons, Function button, and ON/OFF button. The display shows 'ON' indicating the hob is ready for operation.

4. Setup

Before first use, ensure the hob is properly set up.

1. **Unpacking:** Carefully remove the hob from its packaging. Retain the packaging for future storage or transport.
2. **Placement:** Place the induction hob on a flat, stable, heat-resistant surface. Ensure there is adequate ventilation around the appliance. Do not block the ventilation openings.
3. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of the appliance (220 Volts).

5. Operating Instructions

Follow these steps to operate your Ariete 1998 Double Portable Induction Hob.

5.1 Basic Operation

1. **Power On:** Press the **ON/OFF** button for the desired cooking zone. The display will show 'ON'.
2. **Place Cookware:** Place an induction-compatible pot or pan (up to 27 cm diameter) centrally on the cooking zone.
3. **Adjust Power:** Use the **'+'** or **'-'** buttons to select the desired power level. The hob offers 10+8 power levels for precise cooking control. You can also use **MAX** or **MIN** for quick adjustments.
4. **Cooking:** The hob will begin heating the cookware.
5. **Power Off:** After cooking, press the **ON/OFF** button again to turn off the cooking zone. The display may show 'H' indicating residual heat.



Figure 3: Induction Hob in Use

This image demonstrates the Ariete 1998 Double Portable Induction Hob in active use, with two different induction-compatible pans simultaneously cooking on each hob. The digital displays show active power settings.

5.2 Timer Function

The hob features a timer function for precise cooking duration, up to 4 hours.

1. While cooking, press the **Function** button until the timer indicator lights up or the display shows a time setting.
2. Use the **'+'** or **'-'** buttons to set the desired cooking time.
3. The hob will automatically turn off once the set time has elapsed.

5.3 Child Safety Lock

To prevent accidental operation, the hob is equipped with a child safety lock.

- To activate the child lock, press and hold the **'-'** button (or indicated lock button) for a few seconds until the lock indicator appears on the display.
- To deactivate, press and hold the same button again until the lock indicator disappears.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your induction hob.

1. **Before Cleaning:** Always unplug the appliance from the power outlet and allow it to cool completely.
2. **Cleaning the Surface:** Wipe the ceramic glass surface with a soft, damp cloth and a mild detergent. For stubborn stains, use a ceramic hob cleaner. Do not use abrasive cleaners, scouring pads, or harsh chemicals.
3. **Control Panel:** Wipe the control panel gently with a soft, dry cloth.
4. **Ventilation Openings:** Ensure the ventilation openings are free from dust and debris.
5. **Storage:** When not in use for extended periods, store the hob in a dry place, preferably in its original packaging.



Figure 4: Cleaning the Induction Hob

This image shows a hand gently wiping the ceramic glass surface of the induction hob with a soft blue cloth, demonstrating the ease of cleaning the appliance.

7. Troubleshooting

If you encounter issues with your induction hob, refer to the following common problems and solutions:

- **Hob does not turn on:**
  - Check if the power cord is securely plugged into a working outlet.
  - Ensure the main power switch (if any) is on.
- **No heat, but hob is on:**
  - Verify that the cookware is induction-compatible.
  - Ensure the cookware is centered on the cooking zone.

- Check if the pot diameter is within the compatible range (up to 27 cm).

- **Display shows an error code:**
  - Refer to the specific error code in the full product manual (if available) or contact customer support.
- **Hob automatically shuts off:**
  - This may be due to the 2-hour automatic shut-off safety feature.
  - Overheating protection may have activated. Allow the hob to cool down before restarting.

If the problem persists after attempting these solutions, please contact Ariete customer support.

8. Specifications

Feature	Specification
Brand	Ariete
Model Number	1998
Color	Black
Product Dimensions (L x W x H)	58 x 35 x 6.5 cm
Item Weight	5 Kilograms
Power	2000 Watts + 1500 Watts (Total 3500W)
Voltage	220 Volts
Heating Elements	2
Control Type	Touch
Burner Type	Induction
Included Components	2 ceramic glass plates
Power Source	AC Adapter
Max Pot Diameter	27 cm
Timer	Up to 4 hours

9. Warranty and Support

Information regarding the specific warranty period for the Ariete 1998 Double Portable Induction Hob is not available in the provided data. For detailed warranty terms and conditions, please refer to the product packaging, the official Ariete website, or contact the retailer where the product was purchased.
For technical support, spare parts availability, or any other inquiries, please contact Ariete customer service through their official channels.

© 2024 Ariete. All rights reserved.