Safemo SF-KX1PB1_SS

Safemo Rechargeable Battery Pack (Model SF-KX1PB1_SS) Instruction Manual

For Safemo Wireless Security Cameras

Introduction

This manual provides essential instructions for the proper use and maintenance of your Safemo Rechargeable Battery Pack, Model SF-KX1PB1_SS. This battery pack is designed exclusively for use with Safemo wireless outdoor security cameras, offering extended power for up to 180 days on a single charge, ensuring reliable and uninterrupted monitoring.

Package Contents

Upon opening the package, verify that all components are present:

- Safemo Rechargeable Battery Pack (Model SF-KX1PB1_SS)
- USB Charging Cable (Type-C)
- Instruction Manual (this document)



Image: A single Safemo Rechargeable Battery Pack, gray in color, with a silver 'PUSH' latch on top, representing the product.

Setup and Charging

Initial Charge

Before first use, fully charge the battery pack. Connect the provided USB charging cable to the battery pack and a compatible USB power adapter (not included). The charging indicator on the battery will show its status.



Image: The Safemo battery pack connected to a USB-C charging cable, illustrating the charging process.

Battery Installation

This battery pack is designed for easy installation and removal from compatible Safemo wireless security cameras. Refer to your specific Safemo camera's instruction manual for detailed steps on how to open the battery compartment and correctly insert the battery pack. Ensure the battery is securely latched into place.



Image: A person inserting the Safemo battery pack into a compatible wireless security camera, highlighting the simple installation process.

Operation

Powering Your Camera

Once installed, the battery pack will power your Safemo wireless security camera, providing up to 180 days of operation on a single charge under typical usage conditions. Battery life may vary based on camera settings, activity levels, and environmental factors.



Image: A visual representation of the battery pack's extended life, indicating up to 180 days of power for continuous monitoring.

Compatibility

This battery pack is specifically designed and tested for compatibility with Safemo wireless outdoor security cameras. Using it with non-Safemo devices or incompatible models may result in improper function or damage.

Alexa Integration (Camera Feature)

While this manual focuses on the battery pack, your Safemo camera, powered by this battery, can integrate with Amazon Alexa for enhanced control and monitoring. This allows for voice commands to view live feeds and receive motion announcements. For detailed instructions on connecting your Safemo camera to Amazon Alexa, please refer to the video below.

Your browser does not support the video tag.

Video: This video demonstrates how to connect your Safemo camera to Amazon Alexa, enabling voice control and live feed viewing. This functionality relies on the camera being powered by a compatible battery pack like the SF-KX1PB1_SS.

Maintenance and Care

Recharging

Recharge the battery pack when the camera's battery level is low. The camera app will typically provide notifications. Regular charging helps maintain optimal battery performance and longevity.

Storage

If storing the battery pack for an extended period, ensure it is partially charged (around 50%) and stored in a cool, dry place away from direct sunlight and extreme temperatures. Avoid fully discharging the battery before storage.

Disposal

Dispose of used Lithium-Ion batteries responsibly according to local regulations. Do not dispose of batteries in household waste or by incineration.



Image: The back of the Safemo battery pack, displaying important safety and disposal symbols, including the crossed-out wheeled bin indicating separate waste collection.

Troubleshooting

- **Battery not charging:** Ensure the USB cable is securely connected to both the battery pack and the power source. Try a different USB cable or power adapter.
- **Camera not powering on:** Verify the battery pack is fully charged and correctly inserted into the camera. Check the camera's own power button or app status.
- **Reduced battery life:** This can be influenced by frequent live view access, high motion detection activity, or extreme temperatures. Review camera settings in the Safemo app to optimize battery usage.

Specifications

Feature	Detail
Model Number	SF-KX1PB1_SS
Battery Type	Lithium Ion
Battery Capacity	6.4 Amp Hours
Nominal Voltage	3.6V
Energy	23.04Wh
Charging Input	5V, 2.0A (USB Type-C)
Dimensions	74.8mm (2.9 in) x 41.3mm (1.6 in)
Item Weight	4.2 ounces
Compatibility	Safemo wireless outdoor security cameras only



Image: Front view of the Safemo Rechargeable Battery Pack, highlighting the 'PUSH' release mechanism.



Image: Dimensions of the Safemo battery pack (74.8mm x 41.3mm) shown alongside a smartphone for visual size comparison.

Warranty and Support

For warranty information and customer support, please refer to the official Safemo website or contact Safemo customer service directly. Keep your purchase receipt for warranty claims.
Manufacturer: SAFEMO
Date First Available: March 19, 2024

© 2024 Safemo. All rights reserved.