Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Crosman CS7SXS

Crosman Shockwave NP QuietFire Air Rifle .177-Caliber User Manual

Model: CS7SXS

Important Safety Information

WARNING: This air rifle is not a toy. Misuse or careless use may result in serious injury or death. Always treat this air rifle as if it were loaded. Read all instructions before use. Always wear safety glasses when handling or shooting this air rifle. Keep fingers away from the trigger until ready to shoot. Never point the air rifle at anything you do not intend to shoot. Ensure a safe backstop is in place before firing. Store the air rifle unloaded and in a secure location, separate from pellets, and out of reach of children.

- Always keep the muzzle pointed in a safe direction.
- Always keep your finger off the trigger until ready to shoot.
- Always keep the air rifle unloaded until ready to use.
- Always wear eye protection.
- Be sure of your target and what is beyond it.
- Never shoot at hard surfaces or water.
- Never climb or jump with a loaded air rifle.
- Avoid ricochet.
- Store air rifle and pellets separately and securely.
- Never use alcohol or drugs before or during shooting.

Product Overview

The Crosman Shockwave NP QuietFire Air Rifle is a .177-caliber break barrel air rifle designed for target shooting and pest control. It features Nitro Piston technology for smoother cocking and reduced recoil, along with QuietFire sound suppression technology for quieter operation. The durable all-weather synthetic stock and foregrip ensure longevity and comfortable handling in various conditions. This model comes equipped with a CenterPoint 4x32mm scope for enhanced accuracy.



Image: The Crosman Shockwave NP QuietFire Air Rifle, a .177-caliber break barrel air rifle with a mounted scope.

Key Features:

- **.177-Caliber Break Barrel:** Designed for single-shot .177 caliber pellets.
- **Durable All-Weather Design:** Features a synthetic stock and foregrip for robust performance in various environments.
- **Nitro Piston Technology:** Provides smoother cocking, reduced recoil, and quieter shooting compared to traditional spring-powered air rifles.
- **QuietFire Sound Suppression:** Integrated technology to significantly reduce muzzle noise.
- **High Performance:** Rifled steel barrel capable of delivering pellets up to 1200 feet per second (fps).
- **CenterPoint 4x32mm Scope:** Included for improved aiming and accuracy at various distances.

What's Included

Upon unpacking, verify that all components are present:

- Crosman Shockwave NP QuietFire Air Rifle
- CenterPoint 4x32mm Scope
- User Manual (this document)



Image: The Crosman Shockwave NP QuietFire Air Rifle packaged in its retail box, showing the rifle and scope.

Setup

1. Unpacking and Inspection

Carefully remove the air rifle and all accessories from the packaging. Inspect for any signs of damage. If any components are missing or damaged, contact Crosman customer support immediately.

2. Scope Mounting

1. Ensure the air rifle is unloaded and the safety is engaged.
2. Attach the scope rings to the dovetail rail on top of the air rifle receiver. Do not overtighten.
3. Place the CenterPoint 4x32mm scope into the rings. Adjust its position for comfortable eye relief when shouldering the rifle.
4. Ensure the scope's reticle is level. Gently tighten the scope ring screws evenly until the scope is secure. Avoid excessive force to prevent damage to the scope tube.



Image: A close-up view of the Crosman Shockwave NP QuietFire Air Rifle, highlighting the scope mounting area and trigger assembly.

Operating Instructions

1. Loading the Air Rifle

1. **Engage Safety:** Always ensure the safety mechanism is engaged before loading.
2. **Break the Barrel:** Firmly grasp the barrel and strike it downwards near the muzzle to break it open. Continue to pull the barrel down until the cocking mechanism locks into place. This action compresses the Nitro Piston.
3. **Insert Pellet:** Place one .177 caliber pellet (skirt first) into the breech. Ensure the pellet is fully seated.
4. **Close the Barrel:** Return the barrel to its original position by pushing it upwards until it locks securely. Do not slam the barrel shut.

2. Firing the Air Rifle

1. **Aim:** Point the air rifle at your intended target, ensuring a safe backstop.
2. **Disengage Safety:** Once your target is acquired and you are ready to fire, disengage the safety.
3. **Fire:** Place your finger on the trigger and squeeze gently and steadily until the air rifle fires.
4. **Re-engage Safety:** After firing, immediately engage the safety mechanism.

Note: The Nitro Piston technology provides a consistent shot cycle. The QuietFire suppression reduces the sound signature, but the air rifle is not silent.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your Crosman Shockwave air rifle.

- **Cleaning the Barrel:** Periodically clean the barrel using a .177 caliber cleaning kit. Follow the cleaning kit instructions. Avoid excessive cleaning, as it can wear the rifling.
- **Lubrication:** Apply a small amount of non-petroleum-based lubricant to pivot points and moving parts as needed. Consult the Crosman website or contact support for recommended lubricants.
- **Exterior Cleaning:** Wipe down the exterior of the air rifle with a soft, damp cloth to remove dirt and debris. Avoid harsh chemicals.
- **Storage:** Store the air rifle in a cool, dry place, unloaded, with the safety engaged. Keep it in a gun case to protect it from dust and damage.

Troubleshooting

If you encounter issues with your air rifle, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air rifle does not cock.	Barrel not fully broken or latched.	Ensure the barrel is firmly pulled down until the cocking mechanism clicks and locks.
Pellet does not fire or has low power.	Improper pellet seating, incorrect pellet size, or damaged piston seal.	Ensure pellet is fully seated. Use only .177 caliber pellets. If problem persists, contact customer support.
Inaccurate shots.	Loose scope, dirty barrel, inconsistent pellets, or improper shooting technique.	Check scope mounts for tightness. Clean the barrel. Try different quality pellets. Practice consistent shooting form.
Excessive noise during firing.	Normal operation (QuietFire reduces, not eliminates, noise), or internal issue.	Ensure proper pellet usage. If noise is unusually loud or changes, contact customer support.

Specifications

Feature	Detail
Brand	Crosman
Model Name	Crosman® CS7SXS Shockwave .177 Break Barrel Air Rifle, Black
Model Number	CS7SXS
Caliber	.177-caliber
Power Type	Gas-Piston (Nitro Piston Technology)
Barrel Material	Alloy Steel
Frame Material	Nylon (Synthetic Stock)
Color	Black
Item Weight	6 Pounds
Product Dimensions (L x W x H)	1"L x 1"W x 1"H (*Note: These dimensions appear to be placeholder values from the source data and may not reflect actual product size.*)
Included Components	Air Rifle, CenterPoint 4x32mm Scope
UPC	028478152861

Warranty and Support

The Crosman Shockwave NP QuietFire Air Rifle comes with a **5-year limited warranty**. For warranty claims, technical assistance, or to purchase replacement parts, please contact Crosman customer support directly.

Crosman Customer Support:

- Visit the official Crosman website for contact information and FAQs: www.crosman.com
- Refer to the contact details provided in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYH2SFJL

More documents and user manuals: **https://manuals.plus/**