SKRT XW-E01

SKRT Electric 4 Wheel Mobility Scooter Model XW-E01 User Manual

Comprehensive instructions for safe and effective use.

1. Introduction

This manual provides essential information for the safe operation, maintenance, and care of your SKRT Electric 4 Wheel Mobility Scooter, Model XW-E01. Please read this manual thoroughly before using the scooter to ensure proper function and to prevent injury or damage.

The SKRT Electric 4 Wheel Mobility Scooter is designed to provide reliable and comfortable personal transportation for seniors and adults, featuring a robust 800W motor and a 500 lbs weight capacity.



Image 1.1: The SKRT Electric 4 Wheel Mobility Scooter (Silver model) with an attached rear storage basket.

2. Safety Information

Your safety is paramount. Always adhere to the following safety guidelines:

- **Speed Adjustment:** It is suggested for seniors to use the scooter at mid-speed settings for optimal control and safety.
- **Safety Belt:** Always use the integrated safety belt while operating the scooter.
- **Anti-Tipping Rollers:** The scooter is equipped with anti-tipping rollers for enhanced stability. Ensure they are not obstructed.
- **Visibility:** Utilize the front headlight (high/low beam), rear running/brake lights, and turn signals to ensure visibility to others, especially in low-light conditions.
- **Braking:** Familiarize yourself with the front and rear brakes and the parking brake. Always engage the parking brake when stationary.
- **Terrain:** While designed for various terrains, exercise caution on uneven surfaces. The 4.5-inch ground clearance and front shock absorbers aid in a smooth ride.

- **Anti-Theft System:** The scooter includes an anti-theft system with a siren warning function.



Image 2.1: Visual representation of the scooter's safety features, including its durable construction and design for comfort.



Image 2.2: Close-up of the rear of the scooter, illustrating the anti-tipping rollers designed to prevent backward leaning.

3. Setup and Initial Use

Your SKRT Electric 4 Wheel Mobility Scooter is delivered fully assembled and ready to ride. No complex assembly is required, saving time and ensuring product quality upon arrival.

- **Unpacking:** Carefully remove the scooter from its packaging. It is recommended to have assistance due to the product's weight.
- **Initial Charge:** Before first use, ensure the battery is fully charged. Refer to the charging instructions in the "Operation" section.
- **Seat Adjustment:** Adjust the Captain's seat (headrest, backrest, and armrest) to a comfortable and secure position.
- **Pre-Ride Check:** Before each ride, verify that all controls are functioning correctly, tires are adequately inflated, and the parking brake engages properly.



Image 3.1: The SKRT Mobility Scooter, highlighting its fully assembled status upon delivery.

4. Operation

Operating your mobility scooter involves understanding its controls and features. For basic operation, charge the battery, turn on the device, adjust the seat, and operate the controls as needed.

4.1 Controls and Features

- **Remote Key:** Use the remote key for starting and securing the scooter.
- **LCD Monitor Screen:** Provides essential information such as speed, battery level, and distance.
- **Speed Control:** Adjust the speed using the designated controls. Remember to use mid-speed for safety, especially for seniors.
- **Lighting System:**
  - Front Headlight: Features high/low beam settings for varying visibility needs.
  - Rear Running/Brake Lights: Automatically activate for visibility and when braking.
  - Turn Signals: Use to indicate turns to other road users.
- **Horn:** Use the horn to alert pedestrians or other vehicles.
- **Brakes:** The scooter is equipped with front and rear brakes for stopping, and a parking brake to secure the scooter when stationary.
- **Rearview Mirrors:** Adjust mirrors for clear visibility of your surroundings.
- **Storage:** Two storage spaces are available for personal items.



Image 4.1: Detailed views of the adjustable Captain's seat, headlight controls, and the heavy-duty front bumper.



Image 4.2: An overview of the scooter's operational features, including adjustable speed and safety components.

4.2 Charging the Battery

The scooter is powered by a 48-volt 20-ah lead-acid battery. To charge:

1. Locate the charging port on the scooter.
2. Connect the charger to the scooter's charging port.

3. Plug the charger into a standard electrical outlet.
4. Allow 6-7 hours for a full charge. The indicator light on the charger will change when charging is complete.
5. Disconnect the charger once fully charged. Avoid overcharging.

A single charge can provide up to 25 miles of travel or 90 minutes of continuous use, depending on terrain and speed.

5. Maintenance

Regular maintenance ensures the longevity and safe operation of your SKRT Mobility Scooter.

- **Battery Care:**
  - Charge the battery regularly, even if the scooter is not in frequent use, to maintain battery health.
  - Avoid completely draining the battery before recharging.
  - Store the scooter in a cool, dry place when not in use.
- **Tire Pressure:** Periodically check and maintain the correct tire pressure as specified in the scooter's technical details.
- **Cleaning:** Clean the scooter with a damp cloth. Avoid using high-pressure water or harsh chemicals that could damage electrical components.
- **Brake Inspection:** Regularly inspect the front and rear brakes for wear and proper function. Adjust or replace components as needed by a qualified technician.
- **General Inspection:** Periodically check all nuts, bolts, and fasteners to ensure they are secure. Inspect lights, horn, and other electrical components for proper operation.

6. Troubleshooting

This section addresses common issues you might encounter with your scooter.

- **Scooter Does Not Turn On:**
  - Ensure the battery is charged.
  - Check that the remote key is properly inserted and turned.
  - Verify that the main power switch (often located under the seat) is in the "ON" position.
- **Reduced Range or Power:**
  - The battery may not be fully charged or may be nearing the end of its lifespan.
  - Check tire pressure; underinflated tires can reduce efficiency.
  - Operating on inclines or rough terrain will consume more power.
- **Brakes Not Responding:**
  - Inspect brake cables and pads for wear or damage.
  - If issues persist, contact customer support or a qualified technician.

For issues not covered here, please refer to the "Support" section for contact information.

7. Specifications

Key technical specifications for the SKRT Electric 4 Wheel Mobility Scooter Model XW-E01:

Feature	Specification
Model Number	XW-E01
Motor	800W Brushless Motor (Rear-wheel drive)
Battery	48-volt 20-ah Lead-Acid Battery
Maximum Speed	Up to 15 mph
Range per Charge	Up to 25 miles (or 90 minutes)
Charging Time	6-7 hours
Weight Capacity	Up to 500 lbs
Item Weight	243 Pounds
Product Dimensions (L x W x H)	61" x 28.7" x 55.1"
Ground Clearance	4.5 inches
Color	Silver (Red also available)



Image 7.1: Overall dimensions of the SKRT Electric 4 Wheel Mobility Scooter: 61 inches (length), 28.7 inches (width), and 55.1 inches (height).



Image 7.2: Key performance specifications including 800W brushless motor, 15 mph maximum speed, 6-7 hours charging time, and 25 miles drive mileage.

8. Warranty and Support

SKRT provides comprehensive warranty coverage for your mobility scooter:

- **Frame:** Lifetime warranty.
- **Battery and Motor:** 12-month warranty.
- **Electronic Components:** 6-month warranty.
- **Other Parts:** Limited warranty provided.

For any questions or support needs, please contact SKRT customer service. Our support team is located in California, USA, and is ready to assist you.
Note: Please be aware that if the mobility scooter is ridden or used, returns for a refund may be subject to restocking fees.

© 2025 SKRT. All rights reserved. This manual is for informational purposes only.