RYOBI PCLCW01B

Ryobi ONE+ 18V 6 in. Battery Compact Pruning Mini Chainsaw User Manual

Model: PCLCW01B | Brand: RYOBI

1. Introduction and Overview

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Ryobi ONE+ 18V 6 in. Battery Compact Pruning Mini Chainsaw, model PCLCW01B. This tool is designed for light pruning and limbing tasks, capable of cutting branches up to 4 inches in diameter. It is part of the Ryobi ONE+ 18V system, meaning it is compatible with any Ryobi ONE+ 18V battery (battery and charger sold separately).

Key Features:

- Powerful motor for cutting branches up to 4 inches.
- Compact design for access into tight, hard-to-reach spaces.
- Variable speed trigger for maximum control.
- Oil-free design for hassle-free cutting and reduced mess.
- Tool-less chain tensioning for easy adjustments.
- Chain and handle guards for increased safety.



Image 1.1: The Ryobi ONE+ 18V 6 inch Compact Pruning Mini Chainsaw (PCLCW01B) with its 6-inch bar and chain.



Image 1.2: Diagram highlighting key features such as the 6-inch bar and chain, chain guard, variable speed trigger, guarded handle, and compatibility with all 18V ONE+ batteries.

2. Safety Information

Always prioritize safety when operating power tools. Read and understand all safety warnings and instructions before using this chainsaw. Failure to follow these instructions may result in electric shock, fire, and/or serious injury.

General Safety Precautions:

- **Personal Protective Equipment (PPE):** Always wear safety glasses or goggles, hearing protection, heavy-duty gloves, and sturdy footwear. Consider a hard hat and leg protection (chaps) for extensive use.
- **Work Area:** Keep the work area clean and well-lit. Do not operate the chainsaw in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Keep bystanders, children, and pets away while operating the tool.
- **Tool Condition:** Inspect the chainsaw before each use. Ensure the chain is sharp and properly tensioned, and all guards are in place and functioning correctly. Do not use the tool if it is damaged.
- **Battery Safety:** Use only Ryobi ONE+ 18V batteries and chargers. Do not expose batteries to water or extreme temperatures. Remove the battery when not in use, before cleaning, or when performing maintenance.
- **Kickback:** Be aware of kickback, which can occur when the tip of the guide bar touches an object, or when the wood closes in and pinches the saw chain in the cut. Maintain a firm grip with both hands and position your body to avoid the cutting path.
- **Proper Grip:** Always hold the chainsaw firmly with both hands, with your thumbs and fingers encircling the handles.

3. Setup

Before operating your Ryobi ONE+ 18V 6 in. Compact Pruning Mini Chainsaw, ensure it is properly assembled and prepared for use.

Unpacking:

1. Carefully remove the chainsaw and all components from the packaging.
2. Verify that all items listed in the product packaging are present. This typically includes the chainsaw unit, scabbard, and operator's manual. Note that the battery and charger are NOT included with this tool.
3. Inspect the tool for any shipping damage. Do not use if damaged.

Battery Installation:

1. Ensure the chainsaw is turned off and the trigger is disengaged.
2. Align a charged Ryobi ONE+ 18V battery with the battery port on the tool's handle.
3. Slide the battery into the port until it clicks securely into place.
4. To remove, press the battery release latch and slide the battery out.

Chain Tensioning:

This chainsaw features tool-less chain tensioning for convenience.

1. Ensure the battery is removed for safety.
2. Locate the chain tensioning knob on the side of the chainsaw.
3. Turn the knob clockwise to increase chain tension or counter-clockwise to decrease it.
4. The chain should be snug against the guide bar, but still able to be pulled freely by hand. There should be no excessive slack. Refer to the visual guide in the manual for proper tension.

Scabbard Usage:

Always place the scabbard over the guide bar and chain when the tool is not in use or during transport to prevent accidental contact with the sharp chain.

4. Operating

Follow these guidelines for safe and effective operation of your pruning mini chainsaw.

Starting the Tool:

1. Ensure the battery is securely installed.
2. Grip the chainsaw firmly with both hands.
3. Press the safety lock-out button (if present) and then squeeze the variable speed trigger to start the chain. Release the trigger to stop the chain.

Cutting Techniques:

This chainsaw is ideal for light pruning and limbing of branches up to 4 inches in diameter.

- **Pruning:** When pruning, make clean cuts close to the main branch or trunk without damaging the branch collar.
- **Limbing:** When removing limbs, start with smaller cuts to reduce the weight of the limb before making the final cut. Avoid cutting directly overhead.
- **Variable Speed Trigger:** The variable speed trigger allows you to control the chain speed. Use lower speeds for more delicate cuts and higher speeds for faster cutting through thicker material.



Image 4.1: The mini chainsaw in use, demonstrating its capability to cut branches up to 4 inches, ideal for light pruning and limbing.



Image 4.2: The compact design of the chainsaw allows for easy access into tight, hard-to-reach spaces for precise pruning.

Runtime:

The Ryobi ONE+ 18V 6 in. Compact Pruning Mini Chainsaw can achieve over 50 cuts per charge when using an 18V ONE+ 2Ah battery, depending on the material and cutting conditions.



Image 4.3: The chainsaw positioned next to several cut logs, illustrating its runtime capability of over 50 cuts per charge with a 2Ah battery.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your chainsaw. Always remove the battery before performing any maintenance.

Chain Inspection and Sharpening:

- Inspect the chain regularly for dullness, damage, or excessive wear. A dull chain will cut slowly and can cause the tool to overheat.
- Sharpen the chain as needed using appropriate sharpening tools or have it professionally sharpened. Refer to the chain manufacturer's specifications for correct sharpening angles.
- Ensure the chain tension is correct after any maintenance or sharpening.

Bar Maintenance:

- Clean the guide bar groove regularly to remove sawdust and debris.
- Check the guide bar for burrs or damage. File down any burrs to maintain smooth chain movement.

Cleaning the Tool:

- After each use, clean the exterior of the chainsaw with a damp cloth. Do not use strong detergents or solvents.
- Remove any sawdust or debris from the motor vents to prevent overheating.
- This chainsaw features an **oil-free design**, eliminating the need for chain oil and reducing mess.



Image 5.1: The chainsaw in operation, emphasizing its oil-free design for hassle-free cutting with less mess.

Storage:

- Store the chainsaw in a dry, secure location, out of reach of children.
- Always attach the scabbard to the guide bar before storing.
- Remove the battery from the tool before long-term storage.

6. Troubleshooting

This section addresses common issues you might encounter with your Ryobi ONE+ 18V 6 in. Compact Pruning Mini Chainsaw.

Problem	Possible Cause	Solution
Chainsaw does not start.	Battery not installed correctly or discharged. Safety lock-out not engaged.	Ensure battery is fully charged and properly seated. Press safety lock-out button before squeezing trigger.
Chain does not move or moves slowly.	Chain tension too tight. Chain dull or damaged. Debris in guide bar groove.	Adjust chain tension. Sharpen or replace chain. Clean guide bar groove.
Poor cutting performance.	Dull chain. Incorrect chain tension. Cutting material too large.	Sharpen or replace chain. Adjust chain tension. Ensure material is within the 4-inch cutting capacity.
Tool overheats.	Blocked motor vents. Prolonged heavy use.	Clean motor vents. Allow tool to cool down between uses.

7. Specifications

Detailed technical specifications for the Ryobi ONE+ 18V 6 in. Battery Compact Pruning Mini Chainsaw (PCLCW01B).

Brand: RYOBI

Model Number: PCLCW01B

Power Source: Battery Powered (Ryobi ONE+ 18V)

Chain Length: 6 Inches

Chain Speed: Variable Speed

Maximum Cutting Capacity: Up to 4 Inches

Item Weight: Approximately 4.95 Pounds

Product Dimensions: 14"L x 4"W x 4"H

Included Components: Tool Only (Battery and charger NOT included), Scabbard, Operator's Manual

UPC: 046396051103

8. Warranty and Support

Your Ryobi ONE+ 18V 6 in. Battery Compact Pruning Mini Chainsaw (PCLCW01B) is backed by a manufacturer's warranty.

Warranty Information:

This product is covered by the RYOBI 3-Year Manufacturer's Warranty. This warranty covers defects in material and workmanship. Please retain your proof of purchase for warranty claims. Specific terms and conditions apply and can be found in the official warranty documentation provided with your product or on the Ryobi website.

Customer Support:

For technical assistance, warranty claims, or to purchase replacement parts (such as the A48CW02 6" Replacement Chain), please contact Ryobi customer service. Refer to the contact information provided in your product packaging or visit the official Ryobi website for support resources.

© 2025 RYOBI. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question