Puluomis USBA20070

Puluomis Tilt Out Laundry Hamper Instruction Manual

Model: USBA20070

Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Puluomis Tilt Out Laundry Hamper. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product. Keep this manual for future reference.

Safety Information

Always follow basic safety precautions when assembling and using this product to reduce the risk of injury or damage.

- Ensure all parts are present and undamaged before assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- Keep small parts away from children.
- Do not exceed the maximum load capacity of 88 lbs (40 kg).
- Place the unit on a flat, stable surface to prevent tipping.

Package Contents

Verify that all components listed below are included in your package:

- MDF Wood Panels (various sizes for cabinet frame, drawer, and tilt-out door)
- Hardware Kit (screws, dowels, cam locks, etc.)
- Drawer Slides
- Tilt-out Mechanism (metal hinges)
- Stainless Steel Handles (for drawer and tilt-out door)
- Fabric Laundry Basket (included)
- Instruction Manual (this document)

Assembly Instructions

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

1. **Step 1: Assemble the Cabinet Frame**
   Connect the side panels to the bottom and back panels using the provided hardware. Ensure all connections are secure.

   

   Image: An overhead view of the Puluomis Tilt Out Laundry Hamper with key dimensions indicated, providing a visual guide to the overall structure and component sizes during assembly.

2. **Step 2: Install Drawer Slides**
   Attach the drawer slides to the inner side panels of the cabinet frame according to the pre-drilled holes.

3. **Step 3: Assemble the Drawer**
   Assemble the drawer box using the smaller MDF panels and secure the bottom. Attach the remaining drawer slide components to the drawer sides. Install the stainless steel handle on the front of the drawer.

   

   Image: A detailed view highlighting the top drawer, stainless steel handle, metal hinges for the tilt-out door, and the elegant X-design on the door panel, illustrating key components for assembly.

4. **Step 4: Install the Tilt-Out Door Mechanism**
   Attach the metal hinges to the lower part of the cabinet frame and to the tilt-out door. Ensure the mechanism allows for smooth opening and closing, with an adjustable angle up to 35 degrees.

   

   Image: The Puluomis Tilt Out Laundry Hamper with its lower door tilted open, illustrating the maximum 35-degree opening angle of the tilt mechanism for easy access to the laundry basket.

5. **Step 5: Insert Laundry Basket**
   Place the included fabric laundry basket into the tilt-out compartment. The basket is designed to fit snugly within the cabinet.

   

   Image: A close-up view of the beige fabric laundry basket positioned inside the tilt-out compartment of the Puluomis cabinet, confirming its inclusion and fit.

6. **Step 6: Final Assembly and Placement**
   Slide the assembled drawer into its tracks. Place the top panel onto the cabinet and secure it. Position the fully assembled unit on a level surface in your desired location.

   

   Image: The fully assembled Puluomis Tilt Out Laundry Hamper, shown with its top drawer partially open and the lower tilt-out door fully open, revealing the laundry basket inside.

Operating Instructions

Your Puluomis Tilt Out Laundry Hamper is designed for convenient and discreet storage.

- **Using the Tilt-Out Hamper:** Gently pull the handle on the lower door to tilt it open. Place laundry items into the fabric basket. Push the door back to close and conceal the contents. The door can be adjusted to different angles within 35 degrees for easier access.
- **Using the Top Drawer:** Pull the top drawer handle to open. This drawer is suitable for storing smaller items such as towels, detergents, or other bathroom/kitchen essentials.



Image: The Puluomis Tilt Out Laundry Hamper placed in a modern bathroom setting next to a bathtub and sink, demonstrating its functional

integration into a living space.

Maintenance and Care

To ensure the longevity and appearance of your laundry hamper, follow these maintenance guidelines:

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Fabric Basket:** The fabric laundry basket can be removed for cleaning. Spot clean or hand wash as needed. Allow to air dry completely before placing back into the cabinet.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Placement:** Avoid placing the unit in direct sunlight or near heat sources to prevent warping or discoloration of the wood.

Troubleshooting

Problem	Possible Cause	Solution
Drawer or door sticks/doesn't open smoothly.	Loose hardware; obstruction; misaligned slides/hinges.	Check and tighten all screws. Ensure nothing is blocking the movement. Realign drawer slides or tilt-out hinges if necessary.
Cabinet wobbles or is unstable.	Uneven floor; loose connections.	Ensure the unit is on a flat, level surface. Check and tighten all assembly screws.
Laundry basket does not fit.	Basket is not fully expanded or positioned incorrectly.	Ensure the fabric basket is fully unfolded and placed correctly within the tilt-out compartment.

Specifications

Attribute	Detail
Brand	Puluomis
Model Number	USBA20070
Product Dimensions	20.5"L x 13.2"W x 35.5"H (52.07 cm L x 33.53 cm W x 90.17 cm H)
Material	Engineered Wood (MDF)
Color	White
Load Capacity	88 lbs (40 kg)
Included Components	Laundry Hamper (fabric basket)
Special Features	Heavy Duty, Adjustable Tilt Angle (max 35 degrees)
Item Weight	15 kg (33 lbs)

Note: Dimensions and weight are approximate and may vary slightly.

Warranty and Support

For any questions regarding assembly, missing parts, or product defects, please contact Puluomis customer support. Refer to your purchase documentation for specific warranty terms and contact information.
You can visit the official Puluomis store for more information:Puluomis Store on Amazon

© 2024 Puluomis. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question