Achaté 12-in-1-Stoomreiniger

Achaté 12-in-1 Handheld Steam Cleaner User Manual

Model: 12-in-1-Stoomreiniger

1. Introduction

Thank you for choosing the Achaté 12-in-1 Handheld Steam Cleaner. This versatile and powerful steam cleaner is designed to provide deep, chemical-free cleaning for various surfaces in your home. With its 12-piece accessory set, you can tackle dirt, grease, grime, and bacteria effectively and safely. Please read this manual thoroughly before first use to ensure safe operation and optimal performance.

Key Features:

- **Powerful Cleaning:** Effortlessly removes stubborn dirt, grease residues, grime, and bacteria on almost any surface without chemicals.
- **12-in-1 Versatility:** Complete with various attachments for cleaning windows, floors, textiles, car upholstery, grout, and more.
- **Eco-friendly and Safe:** Chemical-free cleaning for an environmentally friendly household. Equipped with child safety features.
- **User-friendly and Compact:** Lightweight design and a handy size ensure effortless cleaning, even in hard-to-reach corners.
- **Fast Performance:** Ready for use within 60 seconds, with a powerful steam pressure for quick and effective cleaning.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury.

- **Read All Instructions:** Familiarize yourself with the appliance before use.
- **Electrical Safety:** Do not immerse the appliance, power cord, or plug in water or other liquids. Always unplug the appliance from the electrical outlet when not in use and before cleaning.
- **Hot Steam Warning:** Steam is extremely hot and can cause burns. Never direct steam at people, pets, or electrical appliances. Keep hands and face away from the steam nozzle.
- **Water Tank:** Only fill the water tank with clean tap water. Do not add detergents, perfumes, or other chemicals to the water tank, as this can damage the appliance or create hazardous fumes.

- **Child Safety:** This appliance is not intended for use by children. Keep the appliance and its cord out of reach of children. The product features a child safety lock.
- **Surface Compatibility:** Test the steam cleaner on an inconspicuous area of the surface to be cleaned before full application, especially on delicate materials.
- **Maintenance:** Do not attempt to repair the appliance yourself. Contact qualified service personnel for repairs.

3. Package Contents

Carefully unpack your Achaté 12-in-1 Handheld Steam Cleaner and check that all items are present and in good condition. If any items are missing or damaged, please contact your retailer.

- Achaté Handheld Steam Cleaner Unit
- Short Spray Nozzle
- Long Spray Nozzle
- Steamer (for fabric)
- Bent Spray Nozzle
- Spray Nozzle with Round Brush
- Towel Cover for Steamer
- Extended Connection Hose
- Window/Door Cleaner Attachment
- Measuring Cup
- Funnel

4. Product Overview

The Achaté Handheld Steam Cleaner is designed for ease of use and portability. Its compact form factor allows for comfortable handling and storage.



Figure 4.1: The compact and portable design of the Achaté steam cleaner, making it easy to store.

The main unit features a water tank, power indicator light, steam trigger, and a connection point for various accessories. The ergonomic handle ensures a comfortable grip during use.

5. Setup

5.1 Filling the Water Tank

1. Ensure the steam cleaner is unplugged from the power outlet.
2. Unscrew the water tank cap (usually located on top or side of the unit).
3. Using the provided measuring cup and funnel, carefully fill the water tank with up to 450 ml of clean tap water. Do not overfill.
4. Securely screw the water tank cap back on.

5.2 Attaching Accessories

1. Select the appropriate accessory for your cleaning task.
2. Align the accessory with the nozzle or connection point on the main unit.
3. Push and twist (if applicable) until the accessory is securely attached. Ensure it clicks into place if designed to do so.

5.3 Powering On and Heating

1. Plug the power cord into a suitable electrical outlet.
2. The power indicator light will illuminate, indicating the unit is heating up.
3. The steam cleaner will be ready for use in approximately 60 seconds when the indicator light changes or turns off (refer to your specific model's indicator behavior).

6. Operating Instructions

Once the unit is heated, you can begin cleaning. Always hold the steam cleaner firmly and direct the steam away from yourself and others.

6.1 General Operation

1. Press and hold the steam trigger to release steam. Some models may have a continuous steam lock for extended use.
2. Move the steam cleaner slowly over the surface to be cleaned, allowing the steam to penetrate and loosen dirt.
3. For stubborn stains, hold the steam over the area for a few seconds.
4. Wipe away loosened dirt with a clean cloth if necessary.

6.2 Using Specific Attachments

- **Short Spray Nozzle:** Ideal for concentrated steam on small areas, corners, and crevices.
- **Long Spray Nozzle:** Provides extended reach for cleaning stovetops, sinks, and other kitchen surfaces.



Figure 6.1: Demonstrating the versatility of the long spray nozzle for cleaning kitchen surfaces.

- **Bent Spray Nozzle:** Designed for reaching difficult angles and tight spaces, such as around faucets or oven elements.



Figure 6.2: The bent spray nozzle is perfect for accessing challenging spots.

- **Spray Nozzle with Round Brush:** Excellent for scrubbing away tough dirt and grime on various surfaces like grout, tiles, and oven interiors.



Figure 6.3: Using the brush attachment for deep cleaning, such as on a kitchen hood filter.

- **Extended Connection Hose:** Provides greater flexibility and reach, allowing you to clean larger areas or awkward spots more comfortably.
- **Window/Door Cleaner Attachment:** For streak-free cleaning of glass surfaces. Attach the towel cover for best results.
- **Steamer with Towel Cover:** Ideal for refreshing and de-wrinkling fabrics, upholstery, and clothing.



Figure 6.4: The extended hose and continuous steam function make cleaning large surfaces like tiled walls efficient.



Figure 6.5: Chemical-free cleaning with steam effectively kills bacteria on surfaces like filters.

7. Maintenance

Regular maintenance ensures the longevity and optimal performance of your steam cleaner.

7.1 After Each Use

1. Unplug the appliance and allow it to cool down completely.
2. Carefully unscrew the water tank cap and empty any remaining water.
3. Wipe the exterior of the unit with a damp cloth.
4. Clean any used accessories with water and mild soap, then allow them to air dry.

7.2 Descaling (Periodically)

Depending on water hardness in your area, mineral deposits may build up inside the water tank. To descale:

1. Ensure the unit is unplugged and cool.
2. Mix a solution of equal parts white vinegar and water.

3. Pour the solution into the water tank (do not fill completely).
4. Allow it to sit for 30 minutes to an hour, then empty.
5. Rinse the tank thoroughly with clean water several times to remove any vinegar residue.

7.3 Storage

Store the steam cleaner and its accessories in a cool, dry place, out of reach of children.

8. Troubleshooting

If you encounter issues with your steam cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty; Unit not heated; Nozzle blocked; Mineral buildup.	Refill water tank; Wait for heating indicator; Clean nozzle; Descale the unit.
Water leaking from nozzle	Unit not fully heated; Accessory not properly attached.	Wait for full heating; Reattach accessory securely.
Power indicator not lighting up	Not plugged in; Power outlet issue; Unit malfunction.	Check power connection; Test outlet with another device; Contact support if issue persists.

If the problem persists after trying these solutions, please contact customer support.

9. Specifications

Feature	Specification
Brand	Achaté
Model Number	12-in-1-Stoomreiniger
Wattage	1000 W
Water Tank Capacity	450 ml
Heating Time	1 Minute (approx. 60 seconds)
Cord Length	3.5 m
Voltage	220 V
Form Factor	Handheld
Color	Grey with Blue
Recommended Surfaces	Floors, Carpets, Kitchen Appliances, Bathroom Tiles, Windows, Furniture, Textiles, Grout

10. Warranty and Support

This product is subject to the standard return policy of 30 days from the date of purchase. For specific warranty details, please refer to the terms and conditions provided by your retailer at the time of purchase.
For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact the seller directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question