Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LuxenHome B0CYSSJGR8

LuxenHome 29-Inch Cascading Resin Water Fountain with LED Lights User Manual

Model: B0CYSSJGR8

Introduction | Package Contents | Setup | Operating | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

This manual provides comprehensive instructions for the assembly, operation, maintenance, and troubleshooting of your LuxenHome 29-inch Cascading Resin Water Fountain with LED Lights. Please read this manual thoroughly before initial use to ensure safe and correct operation and to maximize the lifespan of your product.

Important Safety Information

- Always unplug the fountain from the power outlet before performing any assembly, disassembly, cleaning, or maintenance.
- Ensure the power cord is positioned to prevent tripping hazards and is not pinched or damaged.
- Do not operate the pump without sufficient water, as this can cause damage.
- Keep children and pets away from the fountain during operation to prevent accidents.
- Use only clean, distilled water to prevent mineral buildup and maintain pump efficiency.
- If the fountain is used outdoors, ensure it is placed on a stable, level surface and protected from extreme weather conditions.

2. Package Contents

Carefully unpack all components and inspect them for any damage. If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately.

- Fountain Body (1)
- Water Pump with LED Lights (1)
- Power Adapter (1)
- Instruction Manual (1)



Image: Overview of fountain components.

3. Setup Instructions

1. **Placement:** Choose a stable, level surface for the fountain. Ensure it is near a grounded electrical outlet and that the power cord can reach without being stretched or obstructed.
2. **Pump Connection:** Locate the water pump and the tubing inside the fountain body. Connect the pump's outlet nozzle to the end of the tubing. Ensure a secure fit to prevent leaks.
3. **Submerge Pump:** Place the pump at the bottom of the fountain's reservoir. The pump is designed to be fully submerged in water.
4. **Fill with Water:** Fill the fountain reservoir with clean, distilled water until the pump is completely covered and the water level is sufficient for circulation. Avoid overfilling.
5. **Power Connection:** Connect the power adapter to the pump's power cord, then plug the adapter into a grounded

electrical outlet. The pump and LED lights will activate.



Image: Fully assembled fountain in an outdoor setting.

Your browser does not support the video tag.

Video: Official video demonstrating the LuxenHome 29-inch cascading water fountain in operation, highlighting its water flow and LED lights.

4. Operating Instructions

- **Initial Start-up:** After plugging in, the pump will begin circulating water, and the LED lights will illuminate. It may take a few moments for water to flow consistently through all tiers.
- **Water Level:** Regularly check the water level. Due to evaporation, especially in outdoor environments, the water level will decrease over time. Refill with distilled water as needed to ensure the pump remains fully submerged.
- **LED Lights:** The integrated LED lights are designed to operate automatically when the fountain is powered on, enhancing the visual appeal during both day and night.

- **Power On/Off:** To turn the fountain on or off, simply plug or unplug the power adapter from the electrical outlet.



Image: Detailed view of water cascading and LED illumination.

5. Maintenance

- **Daily Water Check:** Ensure the water level is always above the pump. Add distilled water daily to compensate for evaporation.
- **Regular Cleaning:** Clean the fountain and pump every 2-4 weeks, or more frequently if algae or mineral deposits are visible. Unplug the fountain, drain the water, and use a soft brush or cloth with mild soap and water to clean surfaces. Rinse thoroughly.
- **Pump Cleaning:** Disassemble the pump according to its specific instructions (usually involves removing the front cover and impeller). Clean any debris, mineral buildup, or algae from the impeller and pump housing.
- **Algae Prevention:** To minimize algae growth, consider adding a non-toxic algaecide specifically designed for fountains. Avoid direct sunlight if possible.
- **Winterization (Outdoor Use):** Before the first frost, unplug and drain all water from the fountain. Clean thoroughly

and allow it to dry completely. Store the fountain and pump indoors in a dry, frost-free location to prevent damage from freezing water.

6. Troubleshooting

Problem	Possible Cause	Solution
No water flow or weak flow	Low water level, clogged pump, kinked tubing, pump not plugged in.	Check water level and refill. Unplug and clean pump. Ensure tubing is clear. Verify power connection.
LED lights not working	Loose connection, damaged LED, power issue.	Check all electrical connections. If lights are still off, contact customer support.
Excessive splashing	Fountain not level, water level too high, pump flow too strong.	Ensure fountain is on a level surface. Adjust water level. (Note: This model does not have adjustable pump flow).
Water leaking from base	Crack in fountain, improper assembly, seal issue.	Inspect the fountain for visible cracks. Ensure all connections are tight. If leaking persists, contact customer support.
Noisy pump	Low water level, debris in pump, pump not properly seated.	Check water level. Unplug and clean pump. Ensure pump is fully submerged and stable.

7. Specifications

- **Model:** B0CYSSJGR8
- **Brand:** LuxenHome
- **Color:** D Gray
- **Material:** Resin
- **Product Dimensions (L x W x H):** 11.8" x 11.2" x 28.7"
- **Item Weight:** 14.3 Pounds
- **Power Source:** Corded Electric
- **Special Feature:** Integrated LED Lights
- **UPC:** 810129482102



Image: Product dimensions overview.

8. Warranty & Support

For warranty information, technical assistance, or to report missing/damaged parts, please contact LuxenHome customer service. Refer to your purchase documentation or the retailer's website for specific warranty terms and contact details. You can also visit the official LuxenHome store for more information:**LuxenHome Store**

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYSSJGR8

More documents and user manuals: **https://manuals.plus/**