azwok RM-GCBLTV02ADBBT-UV018

azwok GCBLTV02ADBBT Replacement Remote Control User Manual

Model: RM-GCBLTV02ADBBT-UV018

1. Introduction

This manual provides instructions for the azwok GCBLTV02ADBBT replacement remote control. This remote is designed to function as a direct replacement for your original GCBLTV02ADBBT remote, offering all primary buttons and functions without requiring any programming. Simply insert batteries, and it is ready for use.

2. Setup

2.1 Battery Installation

The remote control requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or outwards to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery cover by sliding it back into place until it clicks securely.



Image showing the open battery compartment of the remote control, ready for AAA battery insertion.

3. Operating Instructions

This replacement remote control operates using infrared technology. Ensure there is a clear line of sight between the remote and your television's infrared receiver.

3.1 Basic Functions

- **Power Button**: Press to turn the TV on or off.
- **Number Buttons (0-9)**: Use to directly select channels.
- **Volume Up/Down**: Adjust the audio volume.
- **Channel Up/Down**: Navigate through channels.
- **Mute Button**: Mute or unmute the TV sound.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Use for menu navigation and selection.
- **Back/Exit Button**: Return to the previous menu or exit current menu.
- **Home Button**: Access the TV's smart features or main menu.
- **Netflix, YouTube, Google Play Buttons**: Direct access to streaming applications (if supported by your TV model).



A detailed view of the remote control's front face, highlighting the layout of the power, number, volume, channel, navigation, and dedicated app buttons.

4. Compatible TV Models

This remote control is compatible with various TV models, including but not limited to:

- L32H7S, L40H7A, L40H7S, L43H7S, L50H7A
- NI32HG7NA9, NI40FG7NA9
- ODL24771HN-TAB, ODL32770H-TAB, ODL50672U-TAB
- SA24S46A9, SA32S67A9, SA40S67A9, SA43K67A9, SA43S67A9
- U43H7A, U43H7S, U50H7A, U50H7S, U55H7A, U55H7S, U55IP7UHD, U58H7A, U58H7S, U65H7A, U65H7S
- GCBLTVCC.1GBBT, GCBLTVC1GBBT-C2, GCBLTVC1GBBT-C5, GCBLTVC1GBBT-C6, GCBLTVC1GBBT-CHANGHONG, GCBLTVC1GBBT-CHIQ-2, GCBLTVC1GBBT-JVC-2, GCBLTVC1GBBT-THOMSON, GCBLTVC1GBBT-THOMSON-1
- GCBLTVC1GWBT-HITACHI, GCBLTVC1GWBT-HITACHI-1
- GCBLTVC2GBBT-BENQ, L24D6C, L32G7PG

Note: If your specific TV model is not listed, or if your original remote control differs significantly in appearance, please contact customer support for compatibility verification.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Verify that the TV is powered on.
- **Buttons not working:**
  - Some buttons may be specific to certain TV models or smart TV features. Ensure your TV supports the function you are trying to use.
  - Clean the remote control's surface and buttons if there is any debris.
- **Intermittent operation:**

- This could indicate low battery power. Replace batteries.
- Ensure you are within the effective operating range (up to 10 meters) and have a clear line of sight.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Care:** Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- **Storage:** Store the remote control in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact to prevent damage.

7. Specifications

Feature	Detail
Model Number	RM-GCBLTV02ADBBT-UV018
Brand	azwok
Connectivity Technology	Infrared
Number of Buttons	25
Maximum Range	10 Meters
Compatible Devices	Television
Battery Type	2 x AAA (not included)
Special Feature	No programming required
Color	Black
Item Weight	70 Grams





The rear side of the remote control, showing its ergonomic design and smooth finish.

8. Warranty and Support

This azwok replacement remote control comes with a 12-month replacement guarantee.

If you encounter any issues or have questions regarding compatibility, please contact our customer support. Provide your TV model number for efficient assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question