MiLi B0CYZ2XRMR

MiLi MiCard Wireless Rechargeable Wallet Tracker Card Instruction Manual

Model: B0CYZ2XRMR

Thank you for choosing the MiLi MiCard. This comprehensive manual will guide you through the setup, operation, maintenance, and troubleshooting of your new wireless rechargeable wallet tracker card. Designed to work seamlessly with Apple's Find My network, the MiCard helps you keep track of your valuables with ease.

1. Setup

1.1. What's in the Box

Your MiLi MiCard package includes the following items:

- MiLi MiCard (1 or 2 units, depending on pack size)
- User Manual



Image: Two MiLi MiCard devices, illustrating the product included in the 2-pack.

Your browser does not support the video tag.

Video: An overview of the MiCard, including unboxing, demonstrating its ultra-thin design and sound feature.

1.2. Charging Your MiCard

The MiLi MiCard features a wireless rechargeable battery. A full charge can last 4-6 months. To charge your device:

1. Place the MiCard on any compatible Qi wireless charging pad.
2. The LED indicator on the MiCard will illuminate to confirm charging.
3. A full charge typically takes about 1 hour.



Image: The MiLi MiCard placed on a wireless charging pad, showing the charging process.

Your browser does not support the video tag.

Video: Demonstrates the wireless charging capability of the MiCard and its integration with Apple Find My.

1.3. Pairing with Apple Find My (iOS Only)

The MiLi MiCard is MFi Certified and works exclusively with Apple's Find My app on iOS devices. Follow these steps to pair your MiCard:

1. Ensure your iOS device (iPhone, iPad, or Mac) has Bluetooth enabled and is connected to the internet.
2. Open the "Find My" app on your iOS device.
3. Tap the "Items" tab at the bottom of the screen.
4. Tap the "+" icon and then select "Add Other Item".
5. Follow the on-screen instructions to connect your MiCard. You may need to press the button on the MiCard to activate pairing mode.
6. Once connected, you can name your MiCard and assign an emoji to it.



Image: A smartphone screen displaying the Apple Find My app, showing the location of a MiLi MiCard.

Your browser does not support the video tag.

Video: Demonstrates how the MiCard helps locate items using the Apple Find My app, including playing a sound.

2. Operating Your MiCard

2.1. Locating Your MiCard

Once paired, you can locate your MiCard using the Apple Find My app:

- **Play Sound:** If your MiCard is within Bluetooth range, tap "Play Sound" in the Find My app to make it emit an audible alert (70-85dB). This is useful for finding items nearby, such as in your home or office.
- **View on Map:** The Find My app will display the last known location of your MiCard on a map. If it's out of Bluetooth

range, the Find My network (millions of Apple devices worldwide) will help pinpoint its location anonymously.

- **Directions:** You can get directions to your MiCard's location directly from the Find My app.

2.2. Left-Behind Alerts

To prevent leaving your valuables behind, enable Left-Behind Alerts in the Find My app. If your MiCard separates from your iOS device and goes out of Bluetooth range, you will receive a notification on your device, indicating its last detected location.



Image: A smartphone displaying a "Wallet left behind" notification, indicating the MiCard is no longer detected nearby.

2.3. Lost Mode - NFC Function

If your MiCard is lost and found by someone else, the NFC function allows them to retrieve your contact information (if you've enabled it in Lost Mode). A finder can simply tap their NFC-enabled smartphone on your MiCard to see a message with your contact details, helping facilitate its return.



Image: A hand holding a MiLi MiCard near a smartphone, which displays a message with contact information after an NFC tap, demonstrating the Lost Mode feature.

3. Maintenance

Proper care ensures the longevity and optimal performance of your MiLi MiCard.

3.1. Battery Life and Recharging

The MiCard's wireless rechargeable battery is designed for long-lasting use, typically providing 4-6 months of power on a single 1-hour charge. Monitor the battery level through the Apple Find My app. Recharge the device when the battery level is low to ensure continuous tracking.

3.2. Cleaning

The MiCard features a tempered glass front and back, which may attract fingerprints. To clean, gently wipe the surfaces with a soft, lint-free cloth. Avoid using abrasive materials or harsh chemicals that could damage the finish.

3.3. Water Resistance

The MiCard has an IP65 waterproof rating, meaning it is resistant to dust and water splashes. While it can withstand light exposure to water, it is not designed for submersion. Avoid prolonged exposure to water or extreme conditions to prevent damage.

4. Troubleshooting

If you encounter issues with your MiLi MiCard, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
MiCard not connecting to Find My app.	Bluetooth is off, MiCard battery is low, or pairing issue.	Ensure Bluetooth is on. Charge the MiCard. Try re-pairing the device by removing it from the Find My app and adding it again.
Sound alert is not loud enough or not playing.	MiCard is out of Bluetooth range or obstructed.	Move closer to the MiCard. Ensure there are no heavy obstructions. Check battery level.
Battery drains quickly.	Frequent use of sound alerts, or environmental factors.	Reduce frequency of sound alerts. Ensure the device is fully charged.
MiCard turns off unexpectedly.	Accidental press of the power button (if applicable) or low battery.	Ensure the MiCard is placed in a way that prevents accidental button presses. Recharge the device.

If the issue persists after trying these solutions, please refer to the Support section for further assistance.

5. Specifications

- **Product Dimensions:** 3.3"L x 2.1"W x 0.07"Th
- **Item Weight:** 2.82 ounces
- **Batteries:** 1 Lithium Polymer battery (included)
- **Connectivity Technologies:** Bluetooth, NFC
- **Material:** Plastic
- **Water Resistance:** IP65 rated
- **Battery Life:** Up to 4-6 months on a single charge
- **Charging Time:** Approximately 1 hour for a full charge
- **Compatibility:** iOS devices only (Apple Find My network)

6. Warranty and Support

MiLi provides a manufacturer's warranty for the MiCard. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official MiLi website.

For technical support, troubleshooting assistance beyond this manual, or to inquire about warranty claims, please contact MiLi customer service. Keep your proof of purchase, such as your receipt or order number, as it may be required for warranty validation.

You can typically find contact information for MiLi customer service on their official website:www.mili-shop.com

© 2024 MiLi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question