Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nehilumn CM-106S

Nehilumn 4-5 Cups Drip Coffee Maker Instruction Manual

Brand: Nehilumn | Model: CM-106S

Product Overview

The Nehilumn 4-5 Cups Drip Coffee Maker is designed for convenience and efficiency, perfect for individuals or small households. It features a compact design, an anti-drip function, and an automatic keep-warm feature to ensure your coffee stays hot and fresh.

- Perfect for a family or a small group: 4-5 cups of brewing capacity is the perfect size for a family or a group, just the right amount of capacity for everyone's coffee needs.
- Anti-drip function: This coffee maker has an anti-drip feature, so when the coffee is halfway through brewing and you take the coffee pot away, it stops dripping and doesn't spill coffee everywhere.
- Keep warm function: This 4-5 cups drip coffee maker automatically keeps the coffee warm after brewing, so you can still have a warm cup of coffee when you're done with the task at hand.
- Convenient operation: The filter basket assembly is placed and then covered with the top lid to put in the coffee pot smoothly and without any obstruction. One-touch switch, easy to operate. Equipped with reusable coffee filters, just rinse and dry after use, convenient and environmentally friendly.

Product Components



Figure 1: Overview of the Nehilumn Drip Coffee Maker and its accessories.



Figure 2: Labeled components and features of the coffee maker.



Figure 3: The permanent grounds filter and easy-clean removable filter basket.

Setup

Before first use, clean all removable parts (carafe, filter basket) with warm, soapy water. Rinse thoroughly.

1. **Fill Water Tank:** Open the top lid of the coffee maker. Fill the glass carafe with the desired amount of fresh, cold water (up to 4-5 cups, 600ml max). Pour the water from the carafe into the water tank at the back of the coffee maker. Ensure the water level does not exceed the "MAX" mark.
2. **Insert Filter:** Place the reusable permanent filter into the filter basket.
3. **Add Coffee Grounds:** Add your desired amount of ground coffee into the permanent filter. A general recommendation is 10g of coffee grounds per cup. Adjust to your taste.
4. **Position Carafe:** Place the empty glass carafe with its lid on the warming plate. Ensure it is centered and properly seated to activate the anti-drip mechanism.
5. **Close Lid:** Close the top lid of the coffee maker securely.



Figure 4: Visual guide for basic setup and operation.

Operating Instructions

1. **Power On:** Plug the coffee maker into a standard electrical outlet. Press the ON/OFF button located on the front of the unit. The indicator light will illuminate, indicating that the brewing process has started.
2. **Brewing:** Water will heat up and drip through the coffee grounds into the carafe. The brewing process will take a few minutes depending on the amount of water.
3. **Anti-Drip Feature:** If you need to pour a cup of coffee before the brewing cycle is complete, you can temporarily remove the carafe. The anti-drip function will stop the flow of coffee. Return the carafe to the warming plate within 20 seconds to prevent overflow.
4. **Keep Warm:** Once brewing is complete, the coffee maker will automatically switch to the "keep warm" function, maintaining the coffee's temperature on the non-stick warming plate. The indicator light will remain on during this phase.

5. **Power Off:** To turn off the coffee maker, press the ON/OFF button again. The indicator light will turn off. Unplug the appliance from the outlet when not in use.



Figure 5: The automatic keep-warm function ensures coffee remains hot.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

Daily Cleaning:

- Always unplug the coffee maker before cleaning.
- Remove the permanent filter and filter basket. Discard used coffee grounds.
- Wash the carafe, permanent filter, and filter basket in warm, soapy water. Rinse thoroughly and dry. These parts are generally top-rack dishwasher safe, but hand washing is recommended for longevity.

- Wipe the exterior of the coffee maker with a soft, damp cloth. Do not immerse the coffee maker in water or other liquids.
- Clean the warming plate with a damp cloth. Do not use abrasive cleaners or scouring pads.

Decalcification (Monthly or as needed):

Mineral deposits from water can build up over time, affecting performance. Decalcify regularly.

1. Fill the water tank with a mixture of 1 part white vinegar and 2 parts cold water.
2. Place the empty carafe on the warming plate.
3. Turn on the coffee maker and let half of the solution brew through.
4. Turn off the coffee maker and let it soak for at least 15 minutes.
5. Turn the coffee maker back on and let the remaining solution brew through.
6. Discard the vinegar solution. Run 2-3 full cycles of fresh, cold water through the coffee maker to rinse thoroughly and remove any residual vinegar taste.

Troubleshooting

Problem	Possible Cause	Solution
Coffee does not brew.	No power; Water tank empty; Carafe not properly placed.	Check power cord and outlet; Fill water tank; Ensure carafe is centered on warming plate.
Coffee is too weak/strong.	Incorrect coffee-to-water ratio; Coffee grounds too coarse/fine.	Adjust amount of coffee grounds; Use medium grind coffee.
Water/coffee overflows from filter basket.	Too much water/coffee grounds; Filter basket clogged; Carafe not properly placed.	Do not exceed MAX fill line; Clean filter and filter basket; Ensure carafe is fully seated.
Coffee maker leaks.	Carafe not properly placed; Mineral buildup.	Ensure carafe is fully seated; Decalcify the unit.

Specifications

Feature	Detail
Brand	Nehilumn
Model Name	CM-106S
Color	Black
Product Dimensions	7.09"D x 5.31"W x 9.25"H
Coffee Maker Type	Drip Coffee Machine

Feature	Detail
Filter Type	Reusable (Permanent Filter Included)
Capacity	4-5 Cups (20 Oz)
Power	650W
Operation Mode	Fully Automatic
Special Feature	Anti-drip function, Keep warm function
Item Weight	1.98 pounds
UPC	748253395435

Warranty and Support

Nehilumn Small Kitchen Appliances provide a one-year warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical support, or any questions regarding your Nehilumn Drip Coffee Maker, please contact Nehilumn customer service. Refer to the contact information provided in your product packaging or visit the official Nehilumn website for assistance.

Please retain your proof of purchase for warranty validation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CYZ86VCQ

More documents and user manuals: **https://manuals.plus/**