Ariete 4630

Ariete 4630 9L Air Fryer User Manual

Model: 4630

Introduction

Thank you for purchasing the Ariete 4630 9L Air Fryer. This manual provides important information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read it thoroughly before first use and keep it for future reference.
The Ariete 4630 is designed to provide a healthier alternative to traditional frying, using hot air circulation to cook food with minimal oil. It features a large 9-liter capacity, 1500W power, and 8 preset programs for versatile cooking.

Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

Product Overview

The Ariete 4630 Air Fryer features a sleek design with a transparent basket for monitoring cooking progress. The digital touchscreen provides intuitive control over settings and programs.



Figure 1: Front view of the Ariete 4630 Air Fryer, showing the digital display and the transparent cooking basket filled with french fries.



Figure 2: Overview of key features: 9L capacity, hot air cooking, intuitive touchscreen panel, and the ability to fry with only one tablespoon of oil. The image also highlights the BPA-free materials.

Setup

1. **Unpacking:** Carefully remove the air fryer and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, clean the cooking basket and any removable parts with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly.
3. **Placement:** Place the air fryer on a stable, flat, heat-resistant surface, away from walls and other appliances to allow for proper air circulation. Ensure there is at least 10 cm of free space on the back and sides, and 10 cm above the appliance.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of your appliance.

Operating Instructions

Control Panel Overview



Figure 3: Close-up of the digital touchscreen control panel, displaying temperature and time settings, along with icons for the 8 preset cooking programs: French Fries, Fresh Potatoes, Red Meat, Fish, Chicken, Pizza, Desserts, and Defrost.

The Ariete 4630 features a user-friendly digital touchscreen. The display shows temperature and time, and various icons represent the preset cooking programs.

Basic Operation

1. **Preheating (Optional):** For best results, preheat the air fryer for 3-5 minutes before adding food. Set the desired temperature and time, then press the start button.
2. **Loading Food:** Pull out the cooking basket using the handle. Place food evenly in the basket. Do not overfill the

basket to ensure proper air circulation. For optimal results, a single tablespoon of oil is sufficient for many recipes.



Figure 4: Demonstrates adding a small amount of oil (one tablespoon) to french fries placed in the air fryer basket before cooking, highlighting the minimal oil requirement.

3. **Selecting Program/Settings:**
    - **Preset Programs:** Choose from 8 preset programs by tapping the corresponding icon on the touchscreen. These include: French Fries, Fresh Potatoes, Red Meat, Fish, Chicken, Pizza, Desserts, and Defrost. Each program has a default temperature and time, which can be adjusted.
    - **Manual Settings:** Alternatively, manually set the temperature (up to 200°C) and cooking time using the '+' and '-' buttons.
4. **Starting Cooking:** Press the start/pause button to begin the cooking cycle. The transparent basket allows you to monitor the food without opening the drawer.



Figure 5: Illustrates the hot air circulation system within the air fryer, showing how air flows around the food for even cooking and crispy results.

5. **Shaking/Flipping Food:** For even cooking, especially with items like fries or chicken wings, it is recommended to shake or flip the food halfway through the cooking time. The air fryer may have a reminder function for this.
6. **Completion:** The air fryer will beep when the cooking cycle is complete. Carefully pull out the basket and transfer the cooked food to a serving dish.

Cooking Tips

- For crispy results, pat food dry before adding a small amount of oil.
- Smaller pieces of food generally require less cooking time.
- Use parchment paper or aluminum foil in the basket for easier cleanup, but ensure it does not block air circulation.
- When cooking fatty foods, periodically empty any accumulated oil from the bottom of the basket.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your Ariete 4630 Air Fryer.

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Basket and Tray:** The cooking basket and removable tray are non-stick and can be washed with warm soapy water. Use a soft sponge to avoid damaging the non-stick coating. They are also dishwasher safe.

3. **Interior:** Wipe the interior of the air fryer with a damp cloth. For stubborn residue, use a non-abrasive cleaner.
4. **Exterior:** Clean the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
5. **Heating Element:** Gently clean the heating element with a soft brush to remove any food particles.
6. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; appliance malfunction.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If the issue persists, contact customer support.
Food is not cooked evenly.	Basket overloaded; food not shaken/flipped; incorrect temperature/time.	Do not overload the basket. Shake or flip food halfway through cooking. Adjust temperature and time as needed.
White smoke coming from the appliance.	Cooking fatty food; oil/grease residue from previous use.	This is normal for fatty foods. Clean the basket and interior thoroughly after each use to prevent residue buildup.
Food is not crispy.	Too much moisture; not enough oil; basket overloaded.	Pat food dry before cooking. Add a small amount of oil (e.g., 1 tablespoon). Do not overload the basket.

Specifications

- **Model:** Ariete 4630
- **Capacity:** 9 Liters
- **Power:** 1500 Watts
- **Voltage:** 230 Volts
- **Dimensions:** 40.5 x 32 x 34.5 cm (Depth x Width x Height)
- **Weight:** 7.1 kg
- **Temperature Range:** Up to 200°C
- **Special Features:** Grill function, 8 preset programs, Transparent basket, Touchscreen display, BPA Free.

Warranty and Support

Ariete products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or spare parts, please refer to the warranty card included with your purchase or visit the official Ariete website.
Official Ariete Website: www.ariete.net
For customer service inquiries, please have your model number (4630) and purchase date available.

© 2024 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question