W-KING T9-2

W-KING T9-2 Portable Party Speaker

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the W-KING T9-2 Portable Party Speaker. This powerful 80W Bluetooth speaker is designed to deliver an immersive audio experience with deep bass, clear mids, and crisp highs, perfect for any party or outdoor gathering. Featuring vibrant mixed-color LED lights, multiple playback modes, and True Wireless Stereo pairing, the T9-2 ensures an unforgettable sound and light show. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to help you get the most out of your speaker.





Figure 1: W-KING T9-2 Portable Party Speaker

2. Package Contents

Please check the package carefully to ensure all items are present:

- 1 x T9-2 Party Full Range Speaker
- 1 x Charging Cable
- 1 x 3.5mm AUX Cable
- 1 x User Manual

3. Product Features

3.1. 80W Full-Range Speaker & Bass Reflex Tube Port

The W-KING T9-2 features two full-range drivers with an 80W speaker output. Advanced bass reflex tubes ensure deep and natural bass, enhancing the overall audio experience with enhanced bass, tight mids, and crystal clear highs without distortion at any volume.



Figure 2: Dual Full-Range Drivers for Powerful Sound

3.2. 105dB Huge Sound & Built-in DSP Technology

Experience thunderous crazy bass, rich mids, and high-pitched tones with the built-in DSP technology. The 80W outdoor party speaker delivers an incredibly huge 105dB sound, making it ideal for large gatherings.



Figure 3: Speaker with 105dB Sound Capability

3.3. EQ Modes and Vibrant Mixed Color LED Lights

The T9-2 features two EQ modes, including a bass boost option, allowing you to customize your audio. It is also equipped with colorful disco lights offering seven color modes to create a romantic party atmosphere.



Figure 4: Control Panel with EQ and Light Controls

3.4. 24H Playtime & 160W Wireless Stereo Pairing (TWS)

Enjoy up to 24 hours of playtime on a single charge (actual time varies with volume and environment). Connect two T9-2 speakers wirelessly for a powerful 160W stereo sound experience, creating an optimal sound field. *Note: The T9-2 cannot be paired with the T9-1 model.*



Figure 5: True Wireless Stereo Pairing Setup

3.5. Bluetooth 5.3 and Multiple Playback Options

Equipped with the latest Bluetooth 5.3 chip for stable, long-distance transmission. The speaker also supports audio playback via Micro TF card, USB flash drive, and 3.5mm AUX input, ensuring compatibility with various devices.



Figure 6: Bluetooth 5.3 Connectivity



Figure 7: Multiple Playback Modes

3.6. Portable Handle & IPX5 Splash Resistant

Designed with a leather handle for easy portability. The IPX5 splash-proof function makes it suitable for outdoor use, protecting it from splashes and light rain. *Note: This speaker is splash-resistant, not fully waterproof. Do not submerge.*



Figure 8: Portable Design and IPX5 Rating

4. Controls and Ports

4.1. Control Panel

The main control panel is located on the top of the speaker, featuring a rotary knob for volume control and various buttons for playback, mode selection, and light effects.



Figure 9: Top Control Panel

4.2. Input/Output Ports

The connectivity ports are located on the rear of the speaker, protected by a rubber flap to maintain splash resistance.

- **USB Port:** For USB flash drive playback.
- **AUX Input:** 3.5mm jack for wired audio connection.
- **TF Card Slot:** For Micro TF card playback.
- **DC 5V Port:** USB-C port for charging the speaker.
- **RST (Reset) Button:** Small pinhole for factory reset.

5. Setup

5.1. Charging the Speaker

1. Connect the provided USB-C charging cable to the DC 5V port on the speaker.
2. Connect the other end of the cable to a 5V/2A power adapter (not included).
3. The charging indicator lights will show the charging status. A full charge provides up to 24 hours of playtime.

5.2. Bluetooth Pairing

1. Power on the speaker by pressing and holding the power button. The Bluetooth indicator will flash, indicating it's in pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "W-KING T9-2" from the list.
4. Once connected, the Bluetooth indicator will remain solid, and you will hear a confirmation tone.

5.3. True Wireless Stereo (TWS) Pairing

To achieve 160W stereo sound, you can pair two W-KING T9-2 speakers together:

1. Ensure both T9-2 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (usually indicated by two interlocking arrows or a similar icon).
3. The primary speaker will search for the secondary speaker. Once connected, both speakers will emit a confirmation tone, and their TWS indicators will light up.
4. Now, connect your device to the primary speaker via Bluetooth as described in section 5.2. Audio will play in stereo through both speakers.

6. Operating Instructions

6.1. Basic Playback

- **Power On/Off:** Press and hold the power button.
- **Play/Pause:** Press the Play/Pause button.
- **Volume Control:** Rotate the volume knob clockwise to increase, counter-clockwise to decrease.
- **Next Track:** Press the Next Track button.
- **Previous Track:** Press the Previous Track button.

6.2. Mode Switching

Press the 'M' (Mode) button to cycle through available playback modes: Bluetooth, AUX, TF Card, and USB.

6.3. EQ Modes

Press the EQ button to switch between different equalization modes, including a bass boost option for enhanced low frequencies.

6.4. LED Light Control

Press the Light button (often indicated by a sun or star icon) to cycle through the seven mixed-color LED light modes or to turn the lights off.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The speaker is IPX5 splash-resistant. Do not submerge it in water or expose it to heavy rain. Ensure the port cover is securely closed when near water.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge the speaker before first use and at least once every three months if not used regularly.



Figure 10: IPX5 Splash Resistance

8. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
No sound.	Volume too low; Device not connected; Incorrect mode.	Increase volume; Re-pair Bluetooth; Switch to correct playback mode (AUX, TF, USB).
Bluetooth connection unstable.	Device too far; Obstructions; Interference.	Move device closer; Remove obstructions; Avoid strong electromagnetic fields.
TWS pairing failed.	Speakers already connected to another device; Incorrect pairing procedure.	Disconnect speakers from other devices; Follow TWS pairing steps carefully. Ensure both are T9-2 models.
Lights not working.	Lights turned off.	Press the Light button to activate or cycle modes.

9. Specifications

Feature	Detail
Model Name	T9-2
Speaker Type	2 Full Range Drivers
Speaker Maximum Output Power	80 Watts
Sound Output	Up to 105dB
Connectivity Technology	Bluetooth 5.3, Auxiliary, USB Playback, TF Card
Battery Life	Up to 24 Hours (varies with usage)
Water Resistance Level	IPX5 (Splash Resistant)
Product Dimensions	7.28"D x 4.72"W x 14.57"H
Item Weight	8.58 pounds (3.9 Kilograms)
Material	Plastic, Acrylonitrile Butadiene Styrene (ABS)

10. Warranty and Support

W-KING provides a 12-month warranty for this product. If you encounter any issues or have questions, please do not hesitate to contact W-KING customer service for assistance. Your satisfaction is our priority.

For further support, please refer to the official W-KING website or contact their customer service channels.

11. Official Product Videos

No official product videos from the seller are available for embedding at this time.

© 2024 W-KING. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question