Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ANCTOR USAN1048675

ANCTOR Twin XL Bed Frame Instruction Manual

Model: USAN1048675

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your ANCTOR Twin XL Bed Frame. Designed for durability and convenience, this bed frame features a storage headboard with integrated power outlets and USB ports, eliminating the need for a box spring. Please read these instructions carefully before beginning assembly to ensure proper setup and safe use.

Safety Information

- Always follow the assembly instructions carefully to ensure stability.
- Do not exceed the maximum weight recommendation of 1000 pounds.
- Keep all small parts away from children during assembly.
- Ensure all connections are securely tightened before use.
- Periodically check and re-tighten all bolts and screws to maintain structural integrity.

Setup and Assembly

Your ANCTOR Twin XL Bed Frame is designed for easy assembly and comes packaged in a single box with all necessary components and tools. Follow these steps for a smooth setup:

1. Unpack and Identify Parts

Carefully unpack all components from the box. Verify that all parts listed in the included installation manual are present and undamaged. Each part is typically labeled with a number for easy identification.



Image: Detailed diagram illustrating all components of the ANCTOR Twin XL Bed Frame, including dimensions for the Twin XL size (86.6"L x 40.7"W x 40.6"H) and the power outlet specifications.

2. Initial Frame Assembly

Begin by assembling the main frame components. Loosely hand-tighten all bolts first, ensuring proper alignment of holes. Fully tighten bolts only after all components for a specific step are in place.



Image: Close-up view of the bed frame's metal leg and connection points, highlighting the sturdy construction.

3. Headboard Attachment

Attach the headboard to the main frame. Pay close attention to the orientation of the headboard pieces as indicated in the manual. The storage shelf and integrated power unit will be part of this assembly.



Image: The storage headboard featuring a wooden shelf and an integrated power panel with two AC outlets and two USB ports.

4. Slat Installation

Install the metal slats across the bed frame. Ensure all slats are evenly spaced and securely fastened. Some slats may have anti-slip strips to prevent mattress movement.



Image: A view of the robust metal slat support system, designed to provide strong mattress support without a box spring.

5. Final Tightening

Once all components are assembled, go back and fully tighten all bolts and screws using the provided tools. This ensures the bed frame's stability and prevents squeaking.



Image: The fully assembled ANCTOR Twin XL Bed Frame with a mattress, showcasing its overall design and functionality.

Operating Instructions

Using the Storage Headboard

The integrated storage headboard provides a convenient surface for placing small items such as books, glasses, or a mobile phone. The shelf dimensions are approximately 40.7 inches long and 5.5 inches deep.



Image: A close-up of the storage headboard, demonstrating its use for holding personal items and a tablet.

Utilizing the Integrated Charging Station

The headboard includes a built-in charging station with two standard AC outlets (110V/12A) and two 5V/2A USB ports. Connect the bed frame's power cord to a wall outlet to activate the charging station. This allows for convenient charging of electronic devices directly from your bed.



Image: A detailed view of the integrated power strip on the headboard, showing two AC outlets and two USB charging ports.

Mattress Placement

Place your Twin XL mattress directly onto the assembled metal slats. A box spring is not required for this bed frame. The frame is compatible with mattresses between 10-14 inches thick for optimal headboard visibility and comfort.



Image: A visual guide indicating recommended mattress thicknesses (8", 10", 12") for use with the bed frame, demonstrating that no box spring is needed.

Maintenance

- **Cleaning:** Wipe metal surfaces with a damp cloth. For the upholstered headboard, use a fabric cleaner suitable for linen, following product instructions.
- **Tightening:** Periodically check all bolts and screws (every 3-6 months) and re-tighten them to ensure the frame remains stable and noise-free.
- **Weight Limit:** Do not exceed the maximum weight capacity of 1000 pounds to prevent damage to the frame.
- **Power Unit:** Ensure the power cord is not pinched or damaged. Do not overload the outlets.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Bed frame is noisy or squeaks.	Loose bolts or connections.	Check and tighten all bolts and screws on the frame, especially at joints.
Bed frame feels unstable or wobbly.	Incomplete or incorrect assembly; loose connections.	Review the assembly instructions to ensure all parts are correctly installed and all fasteners are fully tightened.
Mattress slides on the frame.	Lack of anti-slip measures on slats.	Ensure any anti-slip strips on the slats are properly positioned. Consider adding additional non-slip pads between the mattress and slats if needed.
Power outlets/USB ports not working.	Power cord not plugged in; faulty connection.	Verify the bed frame's power cord is securely plugged into a functional wall outlet. Check for any visible damage to the cord or power unit.
Gap between mattress and headboard.	Mattress is too short or thin for the frame.	Ensure you are using a Twin XL mattress (80x38 inches). Consider a thicker mattress (10-14 inches recommended) or a bolster pillow to fill the gap.

Specifications

Model Number: USAN1048675

Size: Twin XL

Product Dimensions (L x W x H): 86.6" x 40.7" x 40.6"

Material: Engineered Wood, Linen, Metal

Headboard Material: Linen

Style: Industrial

Color: Vintage Brown and Gray

Maximum Weight Recommendation: 1000 Pounds

Special Features: Fade Resistant, Squeak Resistant, USB Port, Storage Headboard

Included Components: Bed Frame, Headboard, Slats, Installation Manual

Assembly Required: Yes

Power Unit: 2 AC Outlets (110V/12A), 2 USB Ports (5V/2A)

Power Cord Length: 6.56 ft

Item Weight: 48 Pounds

Warranty and Support

For warranty information or technical support, please refer to the contact details provided in your original purchase documentation or visit the official ANCTOR website. Keep your proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CZ71PMM2

More documents and user manuals: **https://manuals.plus/**