Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

topzee JS-CD-MZJ-1-3

TOPZEE Cold Press Juicer Instruction Manual

Model: JS-CD-MZJ-1-3

1. Product Overview

The TOPZEE Cold Press Juicer is designed to efficiently extract juice from various fruits and vegetables, preserving nutrients through its slow masticating process. This appliance features a bladeless spiral auger for optimal juice yield and reduced oxidation, ensuring fresh and healthy beverages.



Image 1.1: The TOPZEE Cold Press Juicer, showcasing its compact design and main components.

Key features include a quiet operation, easy-to-clean design, and an overload protection system for safe use.

2. Important Safety Instructions

To ensure safe operation and prevent damage, please read and follow all instructions carefully before using the appliance.

- Always unplug the juicer from the power outlet before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or any other liquid.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Use the food pusher provided.
- Ensure all parts are correctly assembled and locked in place before turning on the juicer.
- Do not process frozen fruits, ice, or hard seeds/pits as this may damage the auger and motor.
- If the appliance jams, turn it off immediately and clear the obstruction before restarting.
- The juicer is equipped with an overload protection system that will shut down the machine in case of overheating. Allow it to cool down before resuming operation.

- This appliance is for household use only.

3. Parts and Components

Familiarize yourself with the parts of your TOPZEE Cold Press Juicer:

1. Food Pusher
2. Feed Chute / Hopper
3. Auger (Bladeless Spiral)
4. Filter / Strainer
5. Juice Bowl / Chamber
6. Pulp Outlet
7. Juice Outlet
8. Motor Base with Control Dial
9. Juice Container
10. Pulp Container
11. Cleaning Brush



Image 3.1: Exploded view of the juicer components (refer to the main product image for visual reference of assembled parts).

4. Setup and Assembly

Follow these steps to assemble your juicer before first use:

1. Place the motor base on a stable, flat surface.
2. Align the juice bowl/chamber with the motor base and rotate it clockwise until it locks securely.
3. Insert the filter/strainer into the juice bowl, ensuring it is seated correctly.
4. Place the auger into the center of the filter/strainer, pushing it down firmly.
5. Attach the feed chute/hopper onto the juice bowl, aligning the marks and rotating clockwise until it clicks into place.
6. Position the juice container under the juice outlet and the pulp container under the pulp outlet.
7. Ensure the control dial is in the "OFF" position before plugging the appliance into a power outlet.

5. Operating Instructions

Prepare your fruits and vegetables:

- Wash all produce thoroughly.
- Remove any hard seeds, pits, or thick skins (e.g., citrus peels, pineapple skin).
- Cut ingredients into pieces small enough to fit comfortably into the feed chute. The juicer is designed for a wide range of produce, but smaller pieces prevent jamming.

Juicing process:

1. Plug in the juicer.
2. Turn the control dial to the "START" position. The juicer operates at a slow speed of 65 RPM to minimize heat buildup and preserve nutrients.
3. Gradually feed the prepared ingredients into the feed chute. Use the food pusher to gently guide the produce down. Do not force ingredients.
4. Observe as fresh juice flows into the juice container and pulp is expelled into the pulp container. The residue separation system ensures maximum juice yield and less sediment.
5. When finished juicing, turn the control dial to the "OFF" position and unplug the appliance.



Image 5.1: Enjoying fresh, nutritious juice made with the TOPZEE Cold Press Juicer.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and longevity of your juicer. All detachable parts are easy to clean.

1. Unplug the juicer from the power outlet.
2. Disassemble all removable parts (food pusher, feed chute, auger, filter, juice bowl, containers).
3. Rinse all detachable parts under running water immediately after use to prevent pulp from drying and sticking.
4. Use the provided cleaning brush to remove any stubborn pulp from the filter mesh and other crevices.
5. Wash the parts with warm, soapy water. **Note: All parts are hand wash only and are not dishwasher safe.**
6. Wipe the motor base with a damp cloth. Never immerse the motor base in water.
7. Dry all parts thoroughly before reassembling or storing.

7. Troubleshooting

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; parts not assembled correctly; overload protection activated.	Ensure power cord is securely plugged in. Check that all parts are correctly assembled and locked. If overload protection activated, unplug and let cool for 30 minutes before restarting.
Low juice yield or excessive pulp.	Ingredients too hard or fed too quickly; filter clogged.	Cut ingredients into smaller pieces. Feed produce slowly and gently. Clean the filter thoroughly.

Problem	Possible Cause	Solution
Machine jams or stops during operation.	Overloading with too much produce; hard ingredients; foreign object.	Turn off and unplug. Disassemble and remove obstruction. Ensure ingredients are properly prepared.
Loud noise or vibration.	Improper assembly; unstable surface.	Check that all parts are securely assembled. Place the juicer on a stable, flat surface.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Brand	topzee
Model Name	Cold Press Juicer (JS-CD-MZJ-1-3)
Color	Dark Grey
Product Dimensions	5.5"D x 5.5"W x 15.35"H
Item Weight	6.9 pounds
Capacity	1.5 Pounds
Maximum Power	150 Watts
Voltage	120V
Number of Speeds	65 RPM (Slow Press)
Blade Material	Acrylonitrile Butadiene Styrene
Product Care Instructions	Hand Wash Only

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official TOPZEE website. Keep your purchase receipt as proof of purchase.

For additional assistance, you may contact TOPZEE customer service through their official channels. Please have your model number (JS-CD-MZJ-1-3) ready when contacting support.

© 2024 TOPZEE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CZ77X6TS

More documents and user manuals: **https://manuals.plus/**