Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RAF R.5377

RAF Essential R.5377 Dual Basket Air Fryer User Manual

Model: R.5377

1. Important Safety Instructions

Please read all instructions carefully before using your RAF Essential R.5377 Air Fryer. Keep this manual for future reference.

- **Electrical Safety:** Ensure the voltage indicated on the appliance matches your local mains voltage. Do not operate the appliance with a damaged cord or plug.
- **Hot Surfaces:** The appliance surfaces become hot during use. Always use oven mitts when handling hot components. Do not touch hot surfaces directly.
- **Ventilation:** Do not block any ventilation openings. Ensure adequate space (at least 10 cm) around the appliance for proper air circulation.
- **Water and Liquids:** Do not immerse the main unit, cord, or plug in water or any other liquid. Do not use near water.
- **Children:** This appliance is not intended for use by children. Keep the appliance and its cord out of reach of children.
- **Placement:** Place the air fryer on a stable, heat-resistant surface, away from walls and heat-sensitive materials.
- **Intended Use:** Use the appliance only for its intended household purpose. Do not use outdoors.
- **Overfilling:** Do not overfill the baskets. This can affect cooking performance and may cause damage.
- **Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning.

2. Product Overview

The RAF Essential R.5377 is a 9-liter dual-basket air fryer designed for healthier cooking with less oil. It features independent temperature control for each basket, allowing you to cook two different foods simultaneously.



Figure 2.1: Front view of the RAF Essential R.5377 Dual Basket Air Fryer with both baskets inserted.

Components:

1. Main Unit
2. Control Panel (Digital Touch Screen)
3. Basket 1 (Left)
4. Basket 2 (Right)
5. Basket Handles
6. Air Inlet (Top)
7. Air Outlet (Rear)

3. Setup and First Use

3.1 Unpacking

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Check that all parts are present and undamaged.

3.2 Cleaning Before First Use

1. Wipe the exterior of the main unit with a damp cloth.
2. Wash the baskets and any removable trays with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely.
3. Do not immerse the main unit in water.

3.3 Placement

- Place the air fryer on a stable, level, heat-resistant surface.
- Ensure there is at least 10 cm of free space on all sides and above the appliance for proper ventilation.
- Do not place the appliance near flammable materials or heat sources.

3.4 Power Connection

Plug the power cord into a grounded electrical outlet. The appliance is now ready for use.

4. Operating Instructions

4.1 Control Panel Overview



Figure 4.1: Close-up view of the digital touch control panel, showing time, temperature, and preset icons.

The air fryer features a digital touch control panel. The display shows cooking time and temperature for each basket. Icons represent various preset cooking functions.

- **Power Button:** Turns the appliance on/off.
- **Basket Select (1/2):** Selects which basket to control.

- **Temperature +/-:** Adjusts cooking temperature.
- **Time +/-:** Adjusts cooking time.
- **Preset Icons:** Quick-select cooking programs for common foods (e.g., fries, chicken, fish, steak, vegetables).

4.2 General Cooking Steps

1. **Prepare Food:** Place your ingredients into the desired basket(s). Do not overfill. For best results, food should be in a single layer or not exceed the MAX fill line.
2. **Insert Baskets:** Slide the basket(s) firmly back into the main unit until they click into place.
3. **Power On:** Press the Power button.
4. **Select Basket:** If using both baskets, select Basket 1 or Basket 2 to set its parameters.
5. **Set Time and Temperature:**
    - Use the Temperature +/- buttons to set the desired cooking temperature.
    - Use the Time +/- buttons to set the desired cooking time.
    - Alternatively, select a preset icon for automatic time and temperature settings. You can adjust these manually after selecting a preset.
6. **Start Cooking:** The air fryer will automatically start cooking a few seconds after settings are confirmed, or you may need to press a start button (if available, usually the power button acts as start/pause).
7. **Shake/Flip Food (Optional):** For even cooking, some foods may require shaking or flipping halfway through the cooking cycle. Carefully pull out the basket, shake/flip, and reinsert. The cooking will resume automatically.
8. **Check Doneness:** Once the timer finishes, carefully pull out the basket and check if the food is cooked to your preference. If not, reinsert the basket and cook for a few more minutes.
9. **Remove Food:** Use tongs or a spatula to remove cooked food from the basket. Do not tip the basket upside down as excess oil may drip onto the food.
10. **Power Off:** Press the Power button to turn off the appliance, or it will automatically shut off after a short cooling period.

4.3 Using Dual Baskets

The RAF Essential R.5377 allows you to cook two different items simultaneously at different temperatures and times. Simply set the parameters for Basket 1, then select Basket 2 and set its parameters. Both cooking cycles will run independently.



Figure 4.2: The air fryer with both cooking baskets partially pulled out, showing their independent access.

5. Maintenance and Cleaning

Regular cleaning will ensure optimal performance and extend the lifespan of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Clean Baskets and Trays:**
    - Remove the baskets and any removable trays.
    - Wash them in hot, soapy water using a non-abrasive sponge. For stubborn food residue, soak them in warm water for about 10 minutes.
    - Rinse thoroughly and dry completely before reinserting.
    - *Note:* Check if baskets are dishwasher safe (refer to product specifications or markings). If not, hand wash only.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. If necessary, use a mild detergent. Do not use abrasive cleaners or metal scouring pads.
4. **Clean Exterior:** Wipe the exterior of the air fryer with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Storage:** Ensure the appliance is clean and dry before storing. Store it in a cool, dry place.

6. Troubleshooting

If you encounter any issues with your air fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet not working; appliance damaged.	Check power cord connection; try a different outlet; contact customer support.
Food is not cooked evenly.	Baskets overfilled; food not shaken/flipped; incorrect temperature/time.	Do not overfill; shake/flip food halfway; adjust time/temperature.
White smoke coming from appliance.	Greasy food; oil residue from previous use; food with high fat content.	Clean baskets thoroughly; remove excess fat from food; this is usually harmless. If smoke is black, unplug immediately.
Food is not crispy.	Too much moisture in food; not enough oil (for some items); temperature too low.	Pat food dry; lightly coat with oil; increase temperature or cooking time.

7. Specifications



Figure 7.1: Image showing the dimensions of the RAF Essential R.5377 Air Fryer: 38cm width, 32cm depth, 28cm height.

Feature	Detail
Model Number	R.5377
Brand	RAF
Power	2200 Watts

Feature	Detail
Voltage	220 Volts
Frequency	50 Hz
Capacity	9 Liters
Color	Black
Dimensions (W x D x H)	38 cm x 32 cm x 28 cm
Material	Aluminum, Plastic
Control Type	Touch, Manual Control
Special Feature	Temperature Control
Weight	4 Kilograms

8. Warranty and Support

8.1 Warranty Information

This RAF Essential R.5377 Air Fryer comes with an**International Warranty**. Please refer to the warranty card included with your product for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact your retailer or the authorized RAF service center in your region. You may also visit the official RAF website for further support information.

© 2023 RAF. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CZDQCTN7

More documents and user manuals: **https://manuals.plus/**