Prasky BK-688

PRASKY Professional Blender Model BK-688 Instruction Manual

Model: BK-688

1. Introduction

Thank you for choosing the PRASKY Professional Blender Model BK-688. This powerful kitchen appliance is designed for versatile use, including blending, grinding, and crushing various ingredients. With its robust motor and durable construction, it aims to simplify your food preparation tasks. Please read this manual thoroughly before first use to ensure safe and efficient operation.



Image 1.1: PRASKY Professional Blender with main pitcher and grinder attachment.

2. Important Safety Information

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before operating the blender.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the container while blending to prevent severe injury and damage to the blender. A tamper may be used when the blender is not running.
- Always unplug the blender from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Avoid contact with moving parts. Blades are sharp. Handle with care.
- Do not blend hot liquids in the main pitcher without proper ventilation, as pressure buildup can cause scalding.

- Ensure the lid is securely locked in place before operating the appliance.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Product Overview

The PRASKY Professional Blender BK-688 features a powerful motor and a versatile design to handle various blending and grinding tasks.

Key Components:

- **Motor Base:** Houses the 1000W (Max. 2400W) motor, control panel, and thermal protection system.
- **68oz Blending Container:** Large capacity, BPA-free plastic pitcher with a 6-leaf stainless steel blade assembly, suitable for smoothies, ice crushing, and juices.
- **Grinder Container:** Smaller container designed for grinding coffee beans, nuts, and spices.
- **Lid and Tamper:** For secure operation and assisting with thick mixtures.

Features:

- **Powerful Motor:** 3.0-hp motor reaching up to 25000 RPM for efficient blending.
- **6-Leaf Sharp Blade:** Designed to crush ice cubes, vegetables, and fruits effectively.
- **BPA-Free Material:** Ensures safety for food preparation.
- **Variable Speed Control:** Allows precise adjustment of blending speed.
- **Pulse Function:** Provides short bursts of power for chopping and controlled processing.
- **Pre-programmed Settings:** Dedicated settings for common tasks like Fruits/Milkshake, Sand Ice, and Grains.



Image 3.1: Powerful motor and 6-leaf blade for efficient processing.



Image 3.2: The blender includes both a main pitcher and a grinder container.

4. Setup

Before using your PRASKY Professional Blender for the first time, follow these steps:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or shipping.
2. **Clean:** Wash the blending container, grinder container, lids, and tamper with warm, soapy water. Rinse thoroughly and dry. The motor base should only be wiped with a damp cloth.
3. **Placement:** Place the motor base on a clean, dry, and stable surface. Ensure there is enough space around the blender for proper ventilation.
4. **Assemble:** Place the desired container (blending or grinding) onto the motor base, ensuring it is securely seated. The container should click into place or fit snugly.
5. **Power:** Plug the power cord into a grounded electrical outlet.



Image 4.1: Ensure the blender is fully assembled before use.

5. Operating Instructions

The PRASKY Professional Blender offers various controls for precise blending and grinding.

Control Panel:



Image 5.1: Control panel featuring On/Off switch, variable speed dial, and Pulse button.

- **ON/OFF Switch:** Located on the left, this switch powers the unit on or off.
- **Variable Speed Dial:** The central dial allows you to select speeds from low to high, or specific pre-programmed settings like 'Fruits', 'Milkshake', 'Sand Ice', and 'Grains'.
- **Pulse Button:** Located on the right, press and hold for short bursts of high-speed blending. Release to stop.

General Blending (Main Container):

1. Add ingredients to the 68oz blending container. Ensure the liquid ingredients are added first, followed by soft ingredients, then harder items like ice or frozen fruit. Do not exceed the MAX fill line.
2. Securely place the lid on the container.
3. Turn the ON/OFF switch to 'ON'.
4. Select your desired speed using the variable speed dial or choose a pre-programmed setting. For thick mixtures,

start at a lower speed and gradually increase.

5. Use the tamper through the lid opening to push ingredients towards the blades if necessary, but only when the blender is running.
6. Once desired consistency is reached, turn the ON/OFF switch to 'OFF' and unplug the unit.

Grinding (Grinder Container):

1. Add ingredients like coffee beans, nuts, or spices to the grinder container. Do not overfill.
2. Securely attach the grinder lid.
3. Place the assembled grinder container onto the motor base.
4. Turn the ON/OFF switch to 'ON'.
5. Use the variable speed dial or the Pulse function for short bursts until the desired grind is achieved.
6. Turn the ON/OFF switch to 'OFF' and unplug the unit before removing the grinder container.

Demonstration Videos:

Video 5.2: Demonstration of the PRASKY Countertop Blender for ice crushing and general kitchen use.

Video 5.3: Overview of the Smoothie Blender and Grinder Combo features and usage.

6. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your PRASKY Professional Blender.

Self-Cleaning Function:

1. After use, pour a small amount of warm water (approximately 2-3 cups) into the blending container.
2. Add a drop of dish soap.
3. Secure the lid.
4. Turn the ON/OFF switch to 'ON'.
5. Select the 'High Speed' setting or use the Pulse function for 30-60 seconds.
6. Rinse the container thoroughly with clean water.

Manual Cleaning:

- Always unplug the blender before cleaning.
- The blending container, grinder container, lids, and tamper are dishwasher safe. Place them on the top rack.
- Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
- For stubborn residue, use a non-abrasive brush or sponge.
- Ensure all parts are completely dry before storing.



Image 6.1: Visual guide for the self-cleaning process.

7. Troubleshooting

If you encounter issues with your PRASKY Professional Blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power switch off; container not properly seated.	Ensure power cord is securely plugged in. Turn ON/OFF switch to 'ON'. Verify container is correctly placed on the motor base.
Ingredients are not blending smoothly.	Too little liquid; too many ingredients; ingredients are too large.	Add more liquid. Reduce the amount of ingredients. Cut large ingredients into smaller pieces. Use the tamper to push ingredients towards the blades.

Problem	Possible Cause	Solution
Motor stops during operation.	Overheating protection activated.	Unplug the blender and allow it to cool down for at least 15-20 minutes. Reduce load or liquid amount before restarting.
Loud noise or vibration.	Container not properly seated; foreign object in blades.	Ensure container is securely placed. Unplug and check for any foreign objects around the blades.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	Prasky
Model Number	BK-688
Power (Wattage)	1000W (Max. 2400W)
Speed	Up to 25000 RPM
Blending Container Capacity	68 ounces
Product Dimensions (D x W x H)	7.87" x 6.69" x 7"
Item Weight	4.84 Pounds
Material	BPA Free Plastic (Container), Stainless Steel (Blades)
Special Features	Auto Shut Off, Cord Storage, Multiple Speeds, Programmable, Thermal Protection System
Dishwasher Safe Parts	Pitcher, Grinder, Tamper

9. Warranty and Support

The PRASKY Professional Blender Model BK-688 comes with a limited warranty. For specific warranty details, please refer to the product packaging or contact customer support.

Product Recall and Replacement: We are committed to continuous product improvement. If you previously purchased this product and would like a free upgrade to the 2025 EDITION (v 2.0), please contact us directly. We will arrange for a replacement at no extra cost.

For any questions, technical support, or warranty claims, please contact Prasky Customer Service through the retailer's platform or visit the official Prasky website.

PRASKY

Image 9.1: Prasky Brand Logo.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question