ZdalaMit 100043851

Instruction Manual for ZdalaMit 100043851 Replacement Remote Control

Brand: ZdalaMit | **Model:** 100043851

1. Introduction

This manual provides comprehensive instructions for the ZdalaMit 100043851 Replacement Remote Control, designed for use with Onn 2.1 Soundbar System model 100043851. This remote control is a direct replacement and requires no complex programming for operation. Simply install the batteries, and it is ready for immediate use.

For optimal performance and longevity of your remote control, please read this manual thoroughly and retain it for future reference.

2. Setup and Battery Installation

The ZdalaMit 100043851 remote control operates on two (2) AAA alkaline batteries (not included). Follow these steps to install the batteries correctly:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align with the markings inside the compartment. Incorrect battery orientation can prevent the remote from functioning.
4. Slide the battery cover back into place until it clicks securely.

Once batteries are installed, the remote is ready for use with your compatible Onn 2.1 Soundbar System 100043851.




MOVIE
SOUND MODE
BASS −
BASS +



Figure 2.1: Front view of the remote control. The battery compartment is located on the reverse side.

3. Operating Instructions

The ZdalaMit 100043851 remote control provides full functionality for your Onn 2.1 Soundbar System. Below is a description of the primary buttons and their functions:

Button	Function
Power ( )	Turns the soundbar system On or Off.
Input/Source	Cycles through available audio input sources (e.g., HDMI, Optical, AUX).
Bluetooth ( )	Activates Bluetooth pairing mode or switches to Bluetooth input.
Volume Up (+)	Increases the soundbar volume.
Volume Down (-)	Decreases the soundbar volume.
Play/Pause ( )	Plays or pauses audio playback.
Previous Track ( )	Skips to the beginning of the current track or the previous track.
Next Track ( )	Skips to the next track.
Movie Mode	Activates sound mode optimized for movies.
Sound Mode	Cycles through various preset sound modes (e.g., Music, News, Standard).
Bass -	Decreases the bass level.
Bass +	Increases the bass level.
Mute ( )	Mutes or unmutes the sound.



Figure 3.1: Angled view of the remote control, illustrating button placement.

Figure 3.2: Remote control in use, demonstrating line of sight operation.

Ensure there is a clear line of sight between the remote control and the soundbar's infrared (IR) receiver for

proper operation. Obstructions can interfere with the signal.

4. Maintenance

4.1. Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or damage.

4.2. Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid using abrasive cleaners, solvents, or chemical sprays, as these can damage the remote's finish or internal components.

4.3. Storage

When not in use for extended periods, it is recommended to remove the batteries from the remote control to prevent potential battery leakage, which could damage the device. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

If you experience issues with your ZdalaMit 100043851 remote control, refer to the following common problems and solutions:

- **Remote is not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the soundbar's IR receiver.
  - Confirm you are within the effective operating range of the soundbar.
- **Limited functionality or specific buttons not working:**
  - Verify that the remote control model 100043851 is indeed compatible with your specific Onn 2.1 Soundbar System model 100043851.
  - Clean the remote's IR emitter window (at the front tip) and the soundbar's IR receiver to ensure no dirt or dust is blocking the signal.

If the issue persists after following these steps, please refer to the support information provided by the manufacturer of your Onn Soundbar System.

6. Specifications

Feature	Detail
Model Number	100043851
Brand	ZdalaMit
Compatible Devices	Onn 2.1 Soundbar System 100043851

Feature	Detail
Power Supply	2 x 1.5V AAA Alkaline Batteries (Not Included)
Product Dimensions	5.84 x 1.59 x 0.55 inches
Item Weight	1.41 ounces
Color	Black
Special Feature	Ergonomic design



Figure 6.1: Dimensions of the remote control.

7. Warranty and Support

This product is a replacement remote control. For specific warranty information regarding the ZdalaMit 100043851 Replacement Remote Control, please refer to the seller's policy or contact the seller directly through your purchase platform.

For support related to the Onn 2.1 Soundbar System itself, including its original functionality or troubleshooting beyond remote control issues, please consult the original soundbar's instruction manual or contact Onn customer support.

© 2025 ZdalaMit. All rights reserved.