NINJA SFP700EU

Ninja 12-in-1 Multi-Cooker Combi, Oven & Fryer

Model SFP700EU User Manual

Introduction

Welcome to the world of versatile cooking with your new Ninja 12-in-1 Multi-Cooker Combi, Oven & Fryer. This appliance is designed to simplify your meal preparation, offering a wide range of cooking functions from steaming and air frying to baking and grilling. With its innovative HyperSteam and Air Fry technologies, you can achieve delicious results for family-sized meals in minutes.
This manual provides essential information on how to safely and effectively use, maintain, and troubleshoot your Ninja Combi. Please read it thoroughly before first use and keep it for future reference.

Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, injury, or damage. This appliance is for household use only.

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.

- Do not use appliance for other than intended household use.
- Ensure the appliance is placed on a stable, level, heat-resistant surface.
- Always ensure the door is fully closed before operating.
- Be aware of hot steam and hot surfaces during and after cooking.

Product Overview

The Ninja Combi Multi-Cooker is a versatile kitchen appliance designed for efficient and diverse cooking. It features an intuitive control panel and a spacious interior to accommodate family-sized meals.



Figure 1: The Ninja 12-in-1 Multi-Cooker Combi, Oven & Fryer. This image shows the overall design of the appliance, highlighting its sleek grey finish and the transparent viewing window for monitoring cooking progress.



Figure 2: Close-up of the Ninja Combi's control panel. This panel features a digital display for temperature and time, along with buttons for selecting various cooking functions such as Combi Meals, Air Fry, Bake, Steam, and more. It also includes power and start/stop controls.

Included Components:

- Ninja Combi 12-in-1 Multi-Cooker (Main Unit)
- Ninja Baking Tray
- Combi Pan
- Recipe Inspiration Guide

Setup

1. **Unboxing:** Carefully remove the appliance and all accessories from the packaging. Retain packaging materials for future storage or transport if needed.
2. **Initial Cleaning:** Before first use, wash the Combi Pan, Baking Tray, and any other removable accessories in warm, soapy water. Rinse thoroughly and dry completely. Wipe the interior and exterior of the main unit with a damp cloth.

3. **Placement:** Place the Ninja Combi on a stable, level, heat-resistant surface, away from walls and other appliances to allow for proper ventilation. Ensure there is at least 6 inches of clear space around the unit.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. The appliance is now ready for use.

Operating Instructions

The Ninja Combi features an intuitive touch control panel for easy operation.

1. **Power On:** Press the power button () to turn on the unit. The display will illuminate.
2. **Select Function:** Use the 'FUNCTION' arrows (∧ / ∨) to scroll through the available cooking functions on the display.
3. **Adjust Temperature/Time:** Once a function is selected, use the 'TEMP' arrows (∧ / ∨) to set the desired temperature and the 'TIME' arrows (∧ / ∨) to set the cooking duration.
4. **Start Cooking:** Press the 'START/STOP' button to begin the cooking cycle.
5. **Pause/Stop:** Press the 'START/STOP' button again to pause or cancel the cooking cycle.

Cooking Functions

Your Ninja Combi offers 12 versatile cooking functions to prepare a wide variety of meals.



Figure 3: Illustration of Ninja Combi's HyperSteam and Air Fry technologies. HyperSteam uses superheated steam for thorough internal cooking, while Air Fry technology ensures a crispy exterior, working together for optimal results.

Detailed Functions:

- **Combi Meals:** Designed for cooking complete, multi-component meals simultaneously. This function leverages both HyperSteam and Air Fry technologies for efficient and delicious results.
- **Combi Crisp Cooking:** Combines steam with convection heat to achieve crispy textures while keeping food moist inside. Ideal for dishes requiring a golden-brown finish.
- **Combi Cooking:** A general combined cooking mode that utilizes both steam and dry heat for balanced cooking.
- **Rice/Pasta:** Optimized settings for perfectly cooking rice and pasta dishes.
- **Sear/Saute:** Use this function to brown ingredients before other cooking methods or to quickly cook items on the Combi Pan.
- **Steam:** For healthy cooking with steam, preserving nutrients and moisture. Ideal for vegetables, fish, and dumplings.
- **Slow Cooking:** Perfect for tenderizing meats and simmering stews over extended periods at low temperatures.

- **Rising (Proofing):** Provides a controlled warm environment for dough to rise, ensuring optimal texture for baked goods.
- **Baking:** For traditional oven baking, suitable for cakes, cookies, casseroles, and more.
- **Warming:** Keeps cooked food warm at a safe temperature without overcooking.
- **Oil-free Fry (Air Fry):** Circulates hot air to cook food with little to no oil, resulting in crispy textures similar to deep frying.
- **Grill:** Uses direct heat to grill foods, perfect for meats, poultry, and vegetables, achieving char marks and a smoky flavor.



Figure 4: An example of a family-sized meal prepared in the Ninja Combi, serving up to 8 people. This image displays a plate with cooked salmon, asparagus, and rice, demonstrating the appliance's capacity for complete meals.



Figure 5: The Ninja Combi's ability to cook food directly from frozen. This image shows the appliance in use with food inside, emphasizing its efficiency in preparing meals even when ingredients are not defrosted.



Figure 6: Various baked goods, including bread and cookies, showcasing the Ninja Combi's proofing and baking capabilities. This image illustrates the versatility of the appliance for preparing a range of homemade baked items.

Maintenance

Proper cleaning and maintenance will ensure the longevity and optimal performance of your Ninja Combi.

Cleaning the Unit:

- Always unplug the unit and allow it to cool completely before cleaning.
- Wipe the exterior of the main unit with a clean, damp cloth. Do not immerse the main unit in water or any other liquid.
- Clean the interior cavity with a damp cloth and mild dish soap. For stubborn food residue, use a non-abrasive sponge.

Cleaning Accessories:

- The Combi Pan and non-stick plate are ceramic coated, and the baking tray is enamel coated for easy cleaning.

- Wash the Combi Pan, Baking Tray, and other removable accessories in warm, soapy water. Rinse thoroughly and dry completely.
- Some accessories may be dishwasher safe. Refer to the specific care instructions for each accessory.



Figure 7: Ninja Combi accessories placed in a dishwasher. This image demonstrates the ease of cleaning for the Combi Pan, baking tray, and other removable parts, highlighting their dishwasher-safe design for convenient maintenance.

Troubleshooting

If you encounter any issues with your Ninja Combi, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	Power cord not securely plugged in.	Ensure the power cord is firmly plugged into a working electrical outlet.

Problem	Possible Cause	Solution
Food is not cooking evenly.	Overcrowding the pan; improper temperature/time settings.	Avoid overcrowding. Ensure food is in a single layer. Adjust temperature and time as per recipe or desired doneness.
Excessive smoke from unit.	Food residue or grease buildup; high-fat foods.	Clean the unit and accessories thoroughly after each use. For high-fat foods, use less oil or drain excess fat.
Steam escaping from door.	Normal operation during steam functions; door not fully closed.	This is normal for steam functions. Ensure the door is securely latched.

If the problem persists after trying these solutions, please contact Ninja Customer Support.

Specifications

- **Model Name:** Ninja Combi
- **Model Number:** SFP700EU
- **Color:** Grey
- **Product Dimensions:** 12.2"D x 14.96"W x 15.75"H (31 cm D x 38 cm W x 40 cm H)
- **Item Weight:** 23.1 pounds (10.5 kg)
- **Power Source:** Electric
- **Control Type:** Touch Control
- **Special Features:** Meals in 15 minutes*, 12 cooking functions, large capacity, family size.
- **UPC:** 622356282222
- **Manufacture Year:** 2024

Warranty and Support

Your Ninja 12-in-1 Multi-Cooker Combi, Oven & Fryer is backed by a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions.
For customer support, replacement parts, or service inquiries, please visit the official Ninja website or contact their customer service line. Have your model number (SFP700EU) and purchase date ready when contacting support.

© 2024 Ninja. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question