Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Starfrit 024044-004-0000

Starfrit 10-Cup Coffee Maker Instruction Manual

Model: 024044-004-0000

Brand: Starfrit

1. Introduction

Thank you for choosing the Starfrit 10-Cup Coffee Maker. This appliance is designed to brew up to 10 cups of fresh, aromatic coffee with ease. Its modern design, combined with practical features like a reusable filter and a keep-warm function, makes it a convenient addition to any kitchen. Please read this manual thoroughly before first use to ensure proper operation and maintenance.



Image 1.1: The Starfrit 10-Cup Coffee Maker in Sage.

2. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.

- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- To disconnect, turn any control to "off," then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This coffee maker is equipped with built-in boil-dry protection for enhanced safety.

3. Components and Features

Familiarize yourself with the parts of your Starfrit Coffee Maker:

- **Water Reservoir:** Holds water for brewing. Features a clear water level window.
- **Lid:** Covers the water reservoir and filter basket area.
- **Reusable Filter Basket:** Holds ground coffee. Designed for easy removal and cleaning.
- **Funnel:** Detachable component that supports the filter basket.
- **Glass Carafe:** Collects brewed coffee, with a capacity of 10 cups.
- **Warming Plate:** Keeps the brewed coffee hot.
- **ON/OFF Switch:** Controls the power to the unit, with an indicator light.

FUNCTIONS
FONCTIONS



ON/OFF SWITCH WITH INDICATOR LIGHT
INTERRUPTEUR LUMINEUX MARCHE/ARRÊT



REUSABLE DISHWASHER SAFE FILTER BASKET AND HOLDER
FILTRE ET PORTE-FILTRE RÉUTILISABLES ALLANT AU LAVE-VAISSELLE



WATER LEVEL WINDOW
INDICATEUR DU NIVEAU D'EAU



AUTOMATICALLY SHUTS OFF
S'ÉTEINT AUTOMATIQUEMENT



KEEPS COFFEE HOT
MAINTIENT LA CHALEUR DU CAFÉ

Image 3.1: Key functions of the coffee maker, including the ON/OFF switch, reusable filter basket, water level window, automatic shut-off, and keep warm feature.



Image 3.2: The coffee maker with its reusable filter basket and detachable funnel, highlighting components for easy cleaning.

4. Setup and First Use

4.1 Unpacking

Carefully remove all packaging materials from the coffee maker. Retain the packaging for future storage or transport if needed.

4.2 Initial Cleaning

Before first use, clean all removable parts:

1. Wash the glass carafe, reusable filter basket, and funnel in warm, soapy water. Rinse thoroughly. These parts are also dishwasher-safe.
2. Wipe the exterior of the coffee maker with a soft, damp cloth. Do not immerse the main unit in water.

4.3 Priming the Unit

To clean the internal components and remove any manufacturing residue, perform a brewing cycle with only water:

1. Fill the water reservoir to the MAX 10-cup level with fresh, cold water.
2. Place the empty reusable filter basket and funnel into their positions.
3. Close the lid and place the empty glass carafe on the warming plate.
4. Plug the coffee maker into a standard electrical outlet.
5. Press the ON/OFF switch to start the brewing cycle.
6. Allow the cycle to complete. Discard the hot water from the carafe.
7. Repeat this process once more for optimal cleaning.

5. Operating Instructions

5.1 Brewing Coffee

Follow these steps to brew a fresh pot of coffee:

1. Open the lid of the coffee maker.
2. Fill the glass carafe with the desired amount of fresh, cold water (each cup marking on the carafe corresponds to a cup of brewed coffee). Pour the water into the water reservoir. Ensure the water level does not exceed the MAX 10-cup line on the water level window.
3. Place the reusable filter basket into the funnel, ensuring it is seated correctly.
4. Add the desired amount of ground coffee into the reusable filter basket. A general guideline is one level tablespoon of ground coffee per cup, but adjust to your taste.
5. Close the lid securely.
6. Place the empty glass carafe onto the warming plate, ensuring it is centered and fully pushed back.
7. Plug the coffee maker into a standard electrical outlet.
8. Press the ON/OFF switch. The indicator light will illuminate, indicating that the brewing process has begun.
9. Coffee will begin to brew and drip into the carafe. The brewing process will automatically stop once all the water has passed through.
10. The warming plate will keep the coffee hot after brewing. The coffee maker features an automatic shut-off function for safety and energy saving.



Image 5.1: A hand demonstrating the placement of the reusable filter basket into the coffee maker.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

6.1 Daily Cleaning

1. Always unplug the coffee maker from the power outlet and allow it to cool completely before cleaning.
2. Remove the glass carafe, reusable filter basket, and funnel. Discard used coffee grounds.
3. Wash the carafe, filter basket, and funnel in warm, soapy water. Rinse thoroughly. These parts are dishwasher-safe (top rack recommended).
4. Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.

5. Dry all parts thoroughly before reassembling.

6.2 Descaling (Mineral Deposit Removal)

Mineral deposits (calcium) can build up in your coffee maker over time, affecting its performance. Descale your coffee maker every 2-3 months, or more frequently if you have hard water.

1. Fill the carafe with one part white vinegar and two parts cold water.
2. Pour the mixture into the water reservoir.
3. Place the empty reusable filter basket and funnel into position, and the empty carafe on the warming plate.
4. Press the ON/OFF switch to start a brewing cycle.
5. After about 30 seconds, turn off the coffee maker and let it soak for 30 minutes.
6. Turn the coffee maker back on and let the cycle complete.
7. Discard the vinegar solution.
8. Run 2-3 cycles with fresh, cold water only to rinse out any remaining vinegar taste.

7. Troubleshooting

If you encounter issues with your coffee maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Coffee does not brew.	No water in reservoir; unit not plugged in; power switch not on.	Fill water reservoir; ensure unit is plugged in; press ON/OFF switch.
Coffee is too weak or too strong.	Incorrect coffee-to-water ratio; coffee grind too coarse/fine.	Adjust amount of coffee grounds; use appropriate grind for drip coffee.
Coffee overflows from filter basket.	Too much coffee grounds; filter basket/funnel not seated correctly; unit needs descaling.	Reduce coffee grounds; ensure filter basket and funnel are properly placed; descale the unit.
Coffee is not hot enough.	Unit needs descaling; warming plate issue.	Descale the unit. If problem persists, contact customer support.
Lid does not close properly.	Obstruction; minor warping.	Check for any obstructions. If minor warping, ensure it still seals enough for brewing. If significant, contact customer support.

8. Specifications

Detailed specifications for your Starfrit 10-Cup Coffee Maker:

Attribute	Detail
Brand	Starfrit
Model Number	024044-004-0000
Colour	Sage
Product Dimensions	16.5 x 26 x 32 cm (6.5 x 10.2 x 12.6 inches)
Capacity	10 Cups

Attribute	Detail
Power/Wattage	900 watts
Material	Plastic with metal accent
Special Features	Built-in boil-dry protection, Keep warm function, Reusable filter basket
Item Weight	1.6 kg



Image 8.1: Dimensions of the Starfrit 10-Cup Coffee Maker.

9. Warranty and Support

This Starfrit product is covered by a manufacturer's warranty. For specific warranty details, including duration and coverage, please refer to the warranty card included with your purchase or visit the official Starfrit website. If you require technical

assistance, troubleshooting beyond this manual, or need to make a warranty claim, please contact Starfrit customer support directly.
You can find contact information on the Starfrit website or on your product packaging.

© 2025 Starfrit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CZSD8DGK

More documents and user manuals: **https://manuals.plus/**