cozytrikes Gtx-L-60

Cozytrikes Gtx-L-60 Double Seat Electric Scooter

User Manual

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Cozytrikes Gtx-L-60 Double Seat Electric Scooter. Please read this manual thoroughly before operating the scooter to ensure proper use and to prevent injury or damage.

Safety Information

WARNING: Failure to follow these safety instructions may result in serious injury or death.

- Always wear a helmet and appropriate safety gear when operating the scooter.
- Ensure all components are securely fastened and in good working order before each use.
- Do not operate the scooter under the influence of alcohol or drugs.
- Observe all local traffic laws and regulations.
- Avoid sudden stops, turns, or maneuvers, especially at high speeds.
- Do not exceed the maximum weight capacity of 550 lbs (249 kg).
- Exercise caution when operating in wet conditions, as braking distance may increase.
- Keep hands and feet away from moving parts.
- This product contains batteries that are classified as HAZMAT. Handle with care and dispose of according to local regulations.

Product Overview

The Cozytrikes Gtx-L-60 is a double-seat electric scooter designed for comfortable and versatile mobility. It features a robust design suitable for various terrains.



Figure 1: Front-right view of the Gtx-L-60 Double Seat Electric Scooter. This image displays the scooter's front wheel, handlebars, front seat, and the rear section with the second seat and storage basket.



Figure 2: Rear-right view of the Gtx-L-60 Double Seat Electric Scooter. This image highlights the rear wheels, the second seat, the storage basket, and the overall profile of the scooter from the back.

Key Features:

- **Double Seating:** Accommodates two persons.
- **Powerful Performance:** Transaxle brushless electric motor.
- **Speed and Range:** Up to 20 mph, up to 48 miles per charge.
- **Convenient Storage:** Large rear basket and lockable under-seat compartment.
- **Safety Features:** E-ABS brake assist, front shock absorbers, high-capacity lighting.
- **Weather Resistance:** Sealed electronics for all-season use.

Package Contents

Upon unpacking, verify that all items are present and undamaged. If any items are missing or damaged, contact your retailer immediately.

- Gtx-L-60 Double Seat Electric Scooter (main unit)
- Smart Charger
- Key Set
- User Manual (this document)
- Assembly Tools (if required for minor assembly)

Setup

1. Unpacking and Initial Inspection:

Carefully remove all packaging materials. Inspect the scooter for any signs of damage during transit. Ensure all parts are accounted for as per the package contents list.

2. Battery Charging:

1. Locate the charging port on the scooter.
2. Connect the smart charger to the charging port.
3. Plug the charger into a standard electrical outlet.
4. Allow the batteries to fully charge before first use. The charger's indicator light will typically change color (e.g., red to green) when charging is complete. Initial charge may take several hours.
5. Disconnect the charger once charging is complete.

Note: The scooter uses five 20 Amp-Hr 12 Volt Lead acid maintenance-free batteries, or Lithium batteries. Refer to the charger's specific instructions for detailed charging procedures.

3. Pre-Ride Checks:

- **Tires:** Check tire pressure. Refer to the tire sidewall for recommended pressure.
- **Brakes:** Test both front and rear brakes to ensure they are functioning correctly.
- **Lights:** Verify that all lights (headlight, taillight, turn signals) are operational.
- **Steering:** Ensure the handlebars turn smoothly and are securely fastened.
- **Seats:** Confirm seats are securely attached and comfortable.

Operating Instructions

1. Starting the Scooter:

1. Insert the key into the ignition and turn it to the "ON" position.
2. Ensure the kickstand is up (if applicable).

2. Throttle Control:

The Gtx-L-60 uses a variable speed control twist throttle. Gently twist the throttle grip towards you to accelerate. Release the throttle to decelerate.

3. Braking:

The scooter is equipped with an electric assist brake system. Apply the brake levers gently and evenly to slow down or stop. Avoid sudden, harsh braking, especially at high speeds or on slippery surfaces.

4. Lighting System:

The full lighting system includes a headlight, taillight, and turn signals. Use the appropriate switches on the handlebars to activate these lights as needed for visibility and signaling.

5. Reverse Gear:

To engage reverse gear, locate the reverse switch (usually on the handlebars) and activate it. Operate the throttle gently when in reverse. A warning sound may indicate reverse operation.

6. Storage:

Utilize the large rear basket for carrying items. The compartment underneath the foldable seat provides additional lockable storage for personal belongings.

Maintenance

1. Battery Care:

- Charge batteries regularly, even if the scooter is not in frequent use, to maintain battery health.
- Avoid completely draining the batteries.
- Store the scooter in a cool, dry place when not in use.
- If replacing batteries, ensure they are of the correct type and specifications.

2. Tire Maintenance:

- Regularly check tire pressure and inflate to the recommended PSI.
- Inspect tires for wear, punctures, or damage. Replace worn tires promptly.

3. Cleaning:

Clean the scooter with a damp cloth. Avoid using high-pressure water jets directly on electrical components. Do not use abrasive cleaners.

4. General Inspection:

Periodically check all bolts, nuts, and fasteners for tightness. Lubricate moving parts as recommended by the manufacturer (if applicable).

Troubleshooting

Problem	Possible Cause	Solution
Scooter does not power on.	Battery discharged; Key not in "ON" position; Loose battery connection.	Charge batteries; Turn key to "ON"; Check battery connections.
Reduced speed or range.	Low battery charge; Under-inflated tires; Overload.	Fully charge batteries; Inflate tires to correct pressure; Reduce load.
Brakes feel weak.	Brake pads worn; Brake cable adjustment needed.	Inspect and replace brake pads; Adjust brake cables (consult a technician if unsure).
Unusual noises during operation.	Loose components; Motor issue; Wheel bearing issue.	Inspect for loose parts and tighten; Contact support if motor or wheel issues persist.

For issues not listed here or if solutions do not resolve the problem, please contact customer support.

Specifications

Model: Gtx-L-60 Electric Mobility Scooter

Brand: Cozytrikes

Product Dimensions: 78"D x 27"W x 43"H (78 x 27 x 43 inches)

Weight Capacity: 550 lbs (249 kg)

Speed: Up to 20 mph (32 km/h)

Distance per Charge: Up to 48 miles (77 km)

Batteries: Five 20 Amp-Hr 12 Volt Lead acid maintenance free batteries, or Lithium batteries

Charger: Smart charger included

Throttle Type: Variable speed control - Twist Throttle

Braking System: Electric assist brake system (E-ABS)

Drive System: Brushless motor

Lighting: Full lighting system

Reverse Gear: Yes

Material: Aluminum, Faux Leather, Plastic, Rubber, Stainless Steel

Color: Blue

Manufacturer: Mobilityscootrike

Warranty and Support

For specific warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. Warranty terms may vary depending on the region and seller.
If you require technical assistance, replacement parts, or have questions regarding your Cozytrikes Gtx-L-60 Electric Scooter, please contact the manufacturer or your authorized dealer. Keep your purchase receipt and model number readily available when seeking support.
Manufacturer: Mobilityscootrike
Model Number: Gtx-L-60 Electric Mobility Scooter

© 2024 Cozytrikes. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I change the display units from kilometers (km) to miles per hour (mph) on my Cozytrikes Gtx-L-60 Catillac electric scooter?

Based on the available manual for the Cozytrikes Gtx-L-60, there are no specific built-in instructions for toggling the display units between kilometers and miles per hour. Many electric scooters with digital displays use a...

Read full answer

Why is the throttle not working on my Cozytrikes Gtx-L-60 electric scooter?

If the throttle on your Cozytrikes Gtx-L-60 is not working, please check the following common causes and solutions based on the user manual:Check Power and Ignition: Ensure the key is inserted and turned to...

Read full answer