Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Black Shark OWS-T17

Black Shark OWS-T17 Open Ear Bluetooth Headphones User Manual

Model: OWS-T17 | Brand: Black Shark

Product Overview

The Black Shark OWS-T17 Open Ear Bluetooth Headphones are designed for comfort and performance, featuring an open-ear design, Bluetooth 5.3 connectivity, ENC noise cancellation, and IPX6 waterproofing. This manual provides instructions for setup, operation, maintenance, and troubleshooting.



Image: Black Shark OWS-T17 headphones and their charging case. The headphones feature an open-ear design with ear hooks, and the compact charging case is shown in front.

What's in the Box

Verify that all items are present in the package:

- Wireless Charging Case

- Earbuds (Left and Right)
- Charging Cable
- User Manual
- Quality Certification

Setup

1. Charging the Headphones and Case

Before first use, fully charge the headphones and the charging case. Place the earbuds into the charging case. Connect the charging cable to the case and a power source. The indicator lights on the case will show the charging status.



Image: The Black Shark OWS-T17 charging case with the earbuds securely placed inside, indicating they are ready for charging or storage.

- **Charging Time:** Approximately 1.5 hours for a full charge.
- **Earbud Playtime:** Up to 8 hours on a single charge.
- **Total Playtime with Case:** Up to 30 hours.

2. Wearing the Headphones

The OWS-T17 headphones feature an ergonomic ear-clip design for a secure and comfortable fit. Follow these steps for proper wearing:

1. Prepare your earphones.
2. Place the ear hook over the top of your ear.
3. Rotate clockwise behind the ear until it securely hangs.
4. Adjust the angle of the earphone, keeping it tilted upwards for optimal fit.



Image: A four-step diagram illustrating the correct method for wearing the Black Shark OWS-T17 open-ear headphones, showing how to position the ear hook and adjust the earbud for a secure fit.



Image: A close-up of a person wearing the Black Shark OWS-T17 open-ear headphones, demonstrating their comfortable and discreet fit around the ear.

3. Bluetooth Pairing

To pair your Black Shark OWS-T17 headphones with a device:

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Black Shark OWS-T17" in the list of available Bluetooth devices.
4. Select "Black Shark OWS-T17" to connect. Once connected, a voice prompt will confirm the successful pairing.



Image: The Black Shark OWS-T17 headphones and their charging case next to a smartphone displaying its Bluetooth settings, showing the headphones listed as a discoverable device for pairing.

Note: The headphones support Bluetooth 5.3 for stable and fast connections.

Operating Instructions

Touch Controls

The Black Shark OWS-T17 headphones feature smart touch controls on each earbud. The functions are as follows:



Image: A detailed diagram illustrating the touch control areas on both the left and right Black Shark OWS-T17 earbuds, along with a legend explaining single tap, double tap, triple tap, and touch and hold functions for media playback, calls, and mode switching.

Touch Control Functions

Action	Function (Right Earbud)	Function (Left Earbud)
Tap Once	Play/Pause, Answer Call	Play/Pause, Answer Call
Double-Tap	Next Track, End Call	Previous Track, End Call

Action	Function (Right Earbud)	Function (Left Earbud)
Tap Three Times	Activate Voice Assistant	Switch Music/Game Mode
Touch and Hold (2s)	Reject Call	N/A
Touch and Hold (3s)	N/A	Switch Music/Game Mode

Modes (Music/Game)

The OWS-T17 headphones offer two distinct modes:

- **Music Mode:** Optimized for audio playback, reducing sound leakage by 80% for a more private listening experience.
- **Game Mode:** Provides ultra-low latency (0.06s) for synchronized audio during gaming. This mode may have a shorter Bluetooth transmission distance.

To switch between modes, tap the left earbud three times or touch and hold the left earbud for 3 seconds (refer to the touch control table).



Image: A graphic highlighting the 0.06s ultra-low latency feature of the Black Shark OWS-T17 headphones, showing them connected to a smartphone playing a game, emphasizing no game lag.

Making and Receiving Calls

The headphones feature ENC Noise Cancellation for clear calls.

- **Answer Call:** Tap either earbud once.
- **End Call:** Double-tap either earbud.
- **Reject Call:** Touch and hold the right earbud for 2 seconds.



Image: A visual representation of the ENC Noise Cancellation feature of the Black Shark OWS-T17 headphones, showing a person wearing the earbuds with sound waves illustrating noise reduction for clear communication.

Product Showcase Video

Your browser does not support the video tag.

Video: An official product video showcasing the Black Shark OWS-T17 Open Ear Bluetooth Headphones, highlighting their design,

features, and usage scenarios.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the earbuds and charging case. Do not use abrasive cleaners or immerse in water.
- **Storage:** When not in use, store the headphones in their charging case to protect them and keep them charged. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The headphones are IPX6 waterproof, meaning they are protected against powerful water jets. They are suitable for exercise and outdoor activities but should not be submerged in water.



Image: The Black Shark OWS-T17 headphones shown with water droplets, illustrating their IPX6 waterproof capability, making them suitable for sports and outdoor use.

Troubleshooting

Common Issues and Solutions

Problem	Possible Solution
Headphones not pairing	Ensure Bluetooth is enabled on your device. Make sure the headphones are charged and in pairing mode (open the case). Try forgetting the device on your phone and re-pairing.
No sound from one earbud	Place both earbuds back into the charging case, close the lid, wait a few seconds, then open it again. Check battery levels.
Low volume or poor sound quality	Adjust volume on both your device and the headphones. Ensure earbuds are clean and properly seated in your ears. Check if you are in the correct mode (Music vs. Game).
Headphones not charging	Ensure the charging cable is securely connected. Try a different charging cable or power adapter. Clean the charging contacts on the earbuds and case.

Problem	Possible Solution
Touch controls not responding	Ensure your fingers are clean and dry. Try restarting the headphones by placing them in the case and taking them out.

Specifications

Feature	Detail
Model Name	BS-T17
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.3
Audio Driver Size	16.2 mm Dynamic Drivers
Noise Control	ENC Noise Cancellation
Water Resistance Level	IPX6 (Water Resistant)
Earbud Battery Life	Up to 8 Hours
Total Playtime (with Case)	Up to 30 Hours
Charging Time	1.5 Hours
Control Type	Media Control (Touch)
Frequency Range	20 Hz - 20,000 Hz
Item Weight	4.6 ounces
Charging Case Dimensions	Ultra-thin (2.2cm)

Warranty and Support

Black Shark products are manufactured to high quality standards. For warranty information, technical support, or service inquiries, please refer to the warranty card included in your product packaging or visit the official Black Shark website. Keep your purchase receipt as proof of purchase.
For further assistance, you may contact Black Shark customer support through their official channels.

© 2024 Black Shark. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D12TPT2Y

More documents and user manuals: **https://manuals.plus/**