SURPRIZON mason jar vacuum sealer

SURPRIZON Electric Mason Jar Vacuum Sealer User Manual

Model: mason jar vacuum sealer

Introduction

The SURPRIZON Electric Mason Jar Vacuum Sealer is designed to simplify food preservation by creating an airtight vacuum seal in Mason jars. This portable and efficient device helps extend the freshness of various foods, reducing waste and saving time. It is compatible with both wide-mouth and regular-mouth Mason jars.



Image: The SURPRIZON Electric Mason Jar Vacuum Sealer shown with its included accessories, including jar lids, a USB cable, and a bottle opener.

What's in the Box

Please check the package contents to ensure all items are present:

- 1 x SURPRIZON Electric Mason Jar Vacuum Sealer (Black)
- 1 x Wide-Mouth Sealing Attachment
- 1 x Regular-Mouth Sealing Attachment
- 1 x USB Charging Cable
- 1 x Bottle Opener
- 12 x Self-adhesive Labels (for recording date and food type)
- User Manual (this document)



Image: Close-up view of the vacuum sealer, highlighting its LED digital display, single control button, and Type-C charging port.

Setup

Charging the Device

Before first use, fully charge the vacuum sealer. Connect the provided USB charging cable to the Type-C charging port on the device and plug the other end into a compatible USB power adapter (not included). The LED display will indicate charging status. A full charge takes approximately 2 hours and provides up to 5 hours of sealing operation.

Attaching the Sealing Head

The vacuum sealer comes with two interchangeable sealing heads for wide-mouth and regular-mouth Mason jars. To switch between sizes, twist the bottom part of the sealer to detach the current head and attach the desired one. Ensure it clicks securely into place.



Image: Illustration demonstrating the compatibility of the vacuum sealer with both wide-mouth (3.39 inches) and regular-mouth (2.76 inches) Mason jars, and how to switch between the two sealing attachments.

Operating Instructions

Follow these steps to vacuum seal your Mason jars:

1. **Prepare the Jar:** Fill your Mason jar with food, leaving adequate headspace. Place a clean, dry metal lid (not the screw band) on top of the jar.
2. **Position the Sealer:** Place the electric Mason jar sealer directly over the metal lid, ensuring it is centered and sits firmly on the jar's rim. Apply gentle downward pressure to create a good seal between the sealer and the jar.
3. **Start Vacuuming:** Press the button on top of the sealer. The device will begin to vacuum the air from the jar. The LED display will show the working time. It is recommended to allow the device to operate for 20 seconds or more for an effective seal. The device will automatically stop when a sufficient vacuum is achieved.
4. **Remove the Sealer:** Once the vacuuming process is complete and the device stops, click the button again to stop

working (if it hasn't stopped automatically) and gently lift the sealer upwards from the jar. The jar is now vacuum-sealed. You can use the provided bottle opener to release the vacuum seal when ready to open the jar.



Image: A visual guide illustrating the four steps for vacuum sealing a regular-mouth Mason jar: placing the lid, positioning the sealer, starting the vacuum, and removing the sealer.

Maintenance

Cleaning

To clean the vacuum sealer, wipe the exterior with a soft, damp cloth. Do not immerse the device in water or any other liquid. Ensure the sealing attachments are clean and free of food debris for optimal performance. The silicone rings on the sealing attachments can be gently wiped clean.



Image: Detail showing the dual-layer silicone material of the sealing rings, which ensures effective sealing performance, and examples of the included lid labels for food storage tracking.

Storage

Store the vacuum sealer in a cool, dry place away from direct sunlight and extreme temperatures. Keep it out of reach of children.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on or operate.	Low battery or no charge.	Charge the device fully using the provided USB cable.

Problem	Possible Cause	Solution
Vacuum seal is not achieved or is weak.	Jar rim or lid is not clean/dry. Sealing attachment is not properly seated. Incorrect sealing attachment size for the jar. Lid is damaged or bent.	Ensure jar rim and lid are perfectly clean and dry. Press down firmly on the sealer to ensure a tight fit. Verify you are using the correct wide-mouth or regular-mouth attachment. Use a new, undamaged metal lid.
Device makes unusual noise during operation.	Possible obstruction or internal issue.	Stop operation immediately. Contact customer support if the issue persists.

Specifications

- **Brand:** SURPRIZON
- **Model:** mason jar vacuum sealer
- **Color:** Black
- **Material:** Acrylonitrile Butadiene Styrene (ABS)
- **Dimensions (L x W x H):** 10 x 10 x 10 cm (approximately 4.1 x 3.75 inches as per image)
- **Weight:** 390 g
- **Power:** 4 Watts
- **Voltage:** 5 Volts
- **Battery Type:** 1 Lithium-polymer (included)
- **Charging Time:** Approximately 2 hours
- **Operating Time (Full Charge):** Approximately 5 hours of sealing
- **Suction Power:** Up to -80 KPa
- **Compatibility:** Standard (Regular) and Wide-Mouth Mason Jars only



Image: A comparison chart highlighting the upgraded features of the vacuum sealer, including suction power (80 KPa), pumping time (10-20 seconds), and battery capacity (2000 mAh).

Warranty and Support

The SURPRIZON Electric Mason Jar Vacuum Sealer comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or neglect.

For warranty claims, technical support, or any questions regarding your product, please contact SURPRIZON customer service through the retailer where you purchased the product or visit the official SURPRIZON website for contact information.

Please retain your proof of purchase for warranty purposes.

© 2025 SURPRIZON. All rights reserved.