Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY 58R6E3

Instruction Manual: ALLIMITY TV Base Stand Legs

Model: 58R6E3 (L-1738 R-1738)

Introduction

This manual provides detailed instructions for the proper installation and care of your ALLIMITY TV Base Stand Legs, designed specifically for Hisense Smart LED TV 58R6E3 58" Class FHD TV models. Please read these instructions carefully before beginning installation to ensure correct assembly and safe use.



Image: The ALLIMITY TV Base Stand Legs, showing both the left and right components.

Package Contents

Please verify that all components are present before proceeding with installation:

- 1 x Left TV Stand Leg (L-1738)
- 1 x Right TV Stand Leg (R-1738)
- Screws for attachment (quantity may vary, typically 4-6 screws)



Image: The TV stand legs along with the included attachment screws.

Setup and Installation

Follow these steps to properly install the TV base stand legs:

1. **Prepare the TV:** Carefully place your Hisense 58R6E3 TV face down on a soft, clean, and stable surface (e.g., a blanket or foam) to prevent screen damage. Ensure the surface is large enough to support the entire TV.

2. **Identify Leg Orientation:** Each leg is designed for a specific side (Left or Right). The legs are typically marked with 'L' and 'R' or have a distinct shape that aligns with the corresponding slot on the TV. Ensure the mounting points on the legs align with the screw holes on the TV.



Image: Detail of the leg mounting points, highlighting the screw holes and alignment features.

3. **Attach the Legs:** Align each stand leg with the designated mounting holes on the bottom of the TV. Insert the provided screws into the holes and tighten them securely with a Phillips head screwdriver. Do not overtighten, as this may strip the screw threads or damage the plastic.

   Important Note on Screws:

   Some users have reported that the included screws may be M5 (5mm diameter) while the TV's threaded inserts require M4 (4mm diameter). If the screws do not fit easily or feel too large, *do not force them*. You may need to acquire M4 screws of appropriate length for your TV model. Consult your TV's original manual for exact screw specifications if needed.

4. **Verify Stability:** Once both legs are securely attached, carefully lift the TV and place it upright on a flat, stable surface. Gently push on the top corners of the TV to ensure it is stable and does not wobble. If there is any instability, recheck the screw tightness and leg alignment.

Operating Instructions

The ALLIMITY TV Base Stand Legs provide a stable foundation for your Hisense 58R6E3 TV. Once installed, no

further operation is required. Ensure the TV is placed on a flat, level, and sturdy surface to prevent tipping. The legs feature non-slip pads on the bottom to enhance stability and protect your furniture surface.



Image: The TV stand legs showing approximate dimensions (12 inches long, 1.37 inches high) and the non-slip feature.

Maintenance and Care

To ensure the longevity and appearance of your TV stand legs:

- **Cleaning:** Wipe the legs with a soft, dry cloth. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by drying thoroughly. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check the tightness of the screws attaching the legs to the TV. Retighten if necessary, but do not overtighten.
- **Placement:** Avoid placing the TV and stand in direct sunlight or near heat sources, which could affect the plastic material over time.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Legs do not fit into TV slots.	Incorrect leg orientation (left/right) or incompatible TV model.	Ensure legs are correctly oriented (L for left, R for right). Verify your TV model is Hisense 58R6E3.
Screws do not tighten or strip easily.	Incorrect screw size (e.g., M5 screws for M4 TV inserts) or overtightening.	Do not force screws. If they don't fit, acquire M4 screws of appropriate length. Avoid overtightening.
TV wobbles after installation.	Screws not fully tightened, legs not properly seated, or uneven surface.	Ensure all screws are securely tightened. Confirm legs are fully seated in TV slots. Place TV on a flat, level, and sturdy surface.

Specifications

Feature	Detail
Brand	ALLIMITY
Model Compatibility	Hisense Smart LED TV 58R6E3 (58" Class FHD TV)
Part Numbers	L-1738, R-1738
Material	Plastic
Color	Black
Approximate Dimensions (each leg)	12 inches (Length) x 1.37 inches (Height)
Item Weight	9.1 ounces (total package)
Mounting Type	Direct attachment to TV base

Warranty and Support

For any questions regarding installation, compatibility, or product issues, please contact the seller or manufacturer directly through the platform where the product was purchased. Please refer to your purchase documentation for specific warranty information.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D17QXZXH

More documents and user manuals: **https://manuals.plus/**