Redragon Juno G818 (GP15L)

Redragon Juno G818 Wireless Bluetooth Gaming Controller

Model: GP15L

Introduction

The Redragon Juno G818 is a versatile wireless Bluetooth gaming controller designed for an immersive gaming experience. It offers broad compatibility with various platforms, including PC (Dinput/Xinput), PlayStation 3, and PlayStation 4 (wired connection). Featuring a responsive touch panel, sensitive triggers, and dual vibration motors, the Juno G818 provides precise control and tactile feedback for a wide range of games. Its long-lasting battery ensures extended gameplay sessions.



Image: Front view of the Redragon Juno G818 Wireless Bluetooth Gaming Controller, showcasing its ergonomic design, dual analog sticks, D-pad, action buttons, and central touch panel.

Setup Guide

1. Charging the Controller

Before first use, fully charge the controller. Connect the included micro USB cable to the controller's charging port and the other end to a USB power source (e.g., PC, USB wall adapter). The indicator light will show charging status and turn off when fully charged. A full charge provides up to 24 hours of continuous use.



Image: The Redragon Juno G818 controller highlighting its Li-Ion battery and 24-hour continuous battery life, along with the micro USB charging port.

2. Connecting to Devices

- **Bluetooth Connection (PC/PS4):**
  For wireless connection, ensure your PC or PS4 has Bluetooth enabled. On the controller, press and hold the SHARE and PS buttons simultaneously until the light bar flashes rapidly. On your device, search for new Bluetooth devices and select "Redragon Juno G818" to pair. Once paired, the light bar will turn solid.
- **Wired Connection (PC/PS3/PS4):**
  Connect the micro USB cable from the controller to a USB port on your PC, PS3, or PS4. The controller will automatically be recognized and ready for use. For PS3 and PS4, a wired connection is required for full functionality.



Image: The Redragon Juno G818 controller illustrating its full compatibility with PC (Dinput/Xinput), PS3, and PS4 (wired connection), and the 3.5mm audio connector.

Operating Instructions

Key Features and Functions

- **Touch Panel:** The central touch panel can be used for navigation and specific in-game interactions, depending on the game and platform.
- **Sensitive Triggers (LT/RT):** The rear triggers are designed to be highly sensitive and capacitive, allowing for a wide range of nuanced inputs, from light presses to full depressions for actions like acceleration or shooting.
- **Dual Vibration Motors:** Equipped with two internal force-feedback motors, the controller provides immersive haptic feedback, enhancing the gaming experience with realistic vibrations for impacts, explosions, and other in-game events.
- **3.5mm Audio Connector:** Plug in your compatible headset to the 3.5mm audio jack for in-game audio and voice chat (functionality may vary by platform and game).



Image: Side view of the Redragon Juno G818 controller, emphasizing its sensitive triggers and the presence of two vibration motors for enhanced precision and comfort.



Image: The Redragon Juno G818 controller from an angled top-down view, illustrating the full vibration capability provided by its two internal force-feedback motors.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Redragon Juno G818 controller.

- **Cleaning:** Use a soft, dry cloth to wipe down the controller regularly. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To maximize battery life, avoid completely draining the battery frequently. Charge the controller when

the battery low indicator appears. If storing for an extended period, charge the battery to about 50% every few months.

- **Cable Management:** When not in use, coil the micro USB cable neatly to prevent kinks and damage.

Troubleshooting

If you encounter issues with your Redragon Juno G818 controller, try the following solutions:

- **Controller Not Connecting:**
  - Ensure the controller is charged.
  - For Bluetooth, ensure your device's Bluetooth is on and the controller is in pairing mode. Try unpairing and re-pairing.
  - For wired connection, try a different USB port or cable.
  - Perform a reset: Locate the small reset hole on the back of the controller (near the micro USB port). Use a thin, pointed object (like a paperclip) to press the button inside for a few seconds.



Image: Rear view of the Redragon Juno G818 controller, highlighting the sensitive LT/RT triggers and the small reset button located on the back.

- **Buttons/Sticks Unresponsive or Drifting:**
  - Reset the controller as described above.
  - Ensure the controller's firmware is up to date (check Redragon's official website for PC software/drivers).
  - Clean around the buttons and sticks to remove any debris.
- **Audio Issues (3.5mm Jack):**
  - Ensure your headset is fully plugged in.
  - Test the headset with another device to confirm it's working.
  - Check audio settings on your console/PC to ensure output is directed to the controller.

Specifications

Feature	Detail
Model Number	GP15L
Connectivity	Wireless Bluetooth, Wired (Micro USB)
Compatibility	PC (Dinput/Xinput), PS3 (Wired), PS4 (Wired)
Battery Type	1 Lithium Ion
Battery Life	Up to 24 hours continuous use
Dimensions	16 x 10.5 x 5.5 cm
Weight	150 g
Audio Port	3.5mm Jack
Feedback	Dual Force-Feedback Vibration Motors
Additional Features	Touch Panel, Sensitive Triggers

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the official Redragon website or the retailer's purchase policy where the product was acquired. Keep your proof of purchase for warranty claims.
For further assistance, you may contact Redragon customer support directly through their official channels.

© 2024 Redragon. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I turn off the Redragon Juno G818 (GP15L) controller completely and check its battery health?

To manage the power and battery of your Redragon Juno G818 (GP15L), please follow these steps:Turning Off the Controller: While the manual does not specify a dedicated "Off" button, most controllers of this type...

Read full answer