Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

saschedross Universal Replacement AC Adapter

saschedross AC Adapter Instruction Manual

Universal Replacement AC Adapter for RadioShack Devices

Introduction

This manual provides instructions for the safe and effective use of your saschedross AC Adapter. Please read this manual thoroughly before use and retain it for future reference.

Important Safety Instructions

- Ensure the adapter's voltage and current ratings match your device's requirements.
- Do not expose the adapter to water or excessive moisture.
- Avoid using the adapter in extreme temperatures.
- Do not disassemble or modify the adapter.
- Keep out of reach of children.
- Unplug the adapter from the power outlet when not in use for extended periods.

Setup

1. **Verify Compatibility:** Confirm that your device's power requirements (voltage and current) match the specifications of this AC adapter. Refer to your device's original manual or power input label.
2. **Connect to Device:** Insert the adapter's output connector securely into the power input port of your RadioShack device.
3. **Connect to Power Outlet:** Plug the AC adapter into a standard 110V AC wall outlet.



Figure 1: Connecting the AC adapter to a power source.

Operating Instructions

Once connected, the AC adapter will supply power to your compatible RadioShack device. No further user interaction is typically required for basic operation.

- Ensure the connection is firm at both the device and the wall outlet.
- If your device has a power indicator, confirm it illuminates to show power reception.

Maintenance and Care

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a dry, soft cloth to wipe the surface. Do not use liquid cleaners.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.

- **Inspection:** Periodically inspect the adapter and its cable for any signs of damage, such as frayed wires or cracked casing. If damage is observed, discontinue use immediately.



Figure 2: The AC adapter with its integrated cable.

Troubleshooting

Problem	Possible Cause	Solution
Device not powering on.	Adapter not properly connected. Power outlet not active. Device incompatibility.	Ensure all connections are secure. Test the outlet with another device. Verify adapter specifications match device requirements.
Adapter feels hot.	Normal operation (slight warmth). Overload or faulty adapter.	A slight warmth is normal. If excessively hot, disconnect immediately and discontinue use.
Intermittent power.	Loose connection. Damaged cable/adapter.	Check connections. Inspect cable for damage. If damaged, replace the adapter.

Specifications

Brand:	saschedross
Model:	Universal Replacement AC Adapter
Input Voltage:	110 Volts (AC)
Power Source:	Corded Electric
Connector Type:	2-Pin (Main Power Connector)
Color:	Black
Manufacturer:	Shenzhen Waweis Technology Co., Ltd
Compatible Devices:	RadioShack 32-1250 FM Wireless Receiver RadioShack U120020D RadioShack 15-255 RadioShack 15-1838 ATV-1000 UHF VHF FM Amplified Antenna RadioShack 23-696 CR-3 Battery Charger RadioShack SY-1225 Radio Scanner AC/DC Adapter RadioShack DV-1225S 33-1196 RadioShack 270-1533E



Figure 3: Physical dimensions of the AC adapter.

Warranty Information

This product is typically covered by a standard return policy. For specific warranty details and return procedures, please refer to the retailer's policy at the time of purchase. The buybox winner information indicates a 30-day return policy.

Customer Support

For technical assistance or inquiries regarding this product, please contact the seller directly through the platform where the purchase was made. The seller for this product is TATMALL.

© 2024 saschedross. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D1C28694

More documents and user manuals: **https://manuals.plus/**