Lenox 896609

Lenox Wildflowers All-Purpose Bowls (Set of 4)

Model: 896609

Introduction

This manual provides instructions for the Lenox Wildflowers All-Purpose Bowls, Model 896609. This set includes four stoneware bowls featuring a floral motif. These bowls are designed for versatile use and are both dishwasher and microwave safe. Please read these instructions carefully before first use.



Image: The set of four Lenox Wildflowers all-purpose bowls, showcasing their design and quantity.

Setup

Unpacking

- Carefully remove all bowls from their packaging.
- Inspect each bowl for any signs of damage that may have occurred during transit. If any damage is found, refer to the 'Troubleshooting' section.

Initial Cleaning

- Before first use, wash all bowls thoroughly with warm, soapy water or place them in a dishwasher.
- Rinse completely and dry with a soft cloth or allow to air dry.

Operating

General Use

- These all-purpose bowls are suitable for serving a variety of foods, including soups, salads, pasta, and desserts.
- The stoneware material is designed for everyday use.



Image: Lenox Wildflowers bowls integrated into a table setting, demonstrating their use for serving meals.

Microwave Use

- The bowls are microwave safe.
- Exercise caution when removing bowls from the microwave as they may become hot. Use oven mitts or a cloth to prevent burns.

Maintenance

Cleaning Instructions

- The bowls are dishwasher safe. Place them securely in the dishwasher rack to prevent movement and potential chipping during the wash cycle.
- For hand washing, use a soft sponge or cloth with mild dish soap. Avoid abrasive cleaners or scouring pads, which can scratch the surface.



Image: A detailed view of the floral motif on a Lenox Wildflowers bowl, highlighting the stoneware finish.

Storage

- Store bowls in a cabinet or on a shelf where they are not prone to falling or being knocked over.
- To prevent scratching when stacking, consider placing a soft cloth or paper towel between each bowl.

Care Tips

- Avoid sudden and extreme temperature changes, such as moving a hot bowl directly into cold water, as this can cause thermal shock and lead to cracking.
- While stoneware is durable, it is not impervious to breakage. Handle with care to prolong the life of your bowls.

Troubleshooting

Chipping or Cracking

- If a bowl chips or cracks, discontinue use immediately to prevent injury.
- Refer to the 'Warranty' section for information on potential replacements.

Stains

- For stubborn food stains, a paste made from baking soda and water can be gently applied and left for a short period before washing.
- Rinse thoroughly after treatment.

Specifications

Feature	Detail
Model Number	896609
Material	Stoneware
Quantity	Set of 4 Bowls
Dimensions (Each)	6.5" L x 6.5" W x 3" H
Capacity (Each)	24 Fluid Ounces
Dishwasher Safe	Yes
Microwave Safe	Yes
Theme	Wildflowers

Warranty

Lenox offers a Replacement Promise for their products. For details regarding the terms and conditions of this promise, including how to initiate a claim for damaged or defective items, please refer to the official Lenox website or contact their customer support directly.

Support

For further assistance, questions, or to report any issues not covered in this manual, please contact Lenox Customer Service. You can typically find contact information, including phone numbers and email addresses, on the official Lenox website: www.lenox.com.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question