Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo CT2305-BK

ChooChoo CT2305-BK Modern LED Coffee Table User Manual

Model: CT2305-BK

1. Important Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Remote Control Safety:** Keep the remote control out of reach of children to prevent accidental ingestion of batteries or misuse.
- **Assembly:** Ensure all parts are correctly assembled according to the instructions to maintain stability and prevent injury.
- **Weight Capacity:** Do not exceed the recommended weight capacity for the tabletop or storage areas.
- **Placement:** Place the coffee table on a flat, stable surface to prevent tipping.

2. Package Contents

Before beginning assembly, verify that all components listed in the included assembly guide are present and undamaged. If any parts are missing or damaged, contact customer support immediately.



Image: Diagram illustrating the dimensions of the coffee table (43.3"L x 22.6"W x 16.1"H) and highlighting its thickened MDF and high-gloss acrylic material. An open drawer is also shown with its dimensions.

3. Assembly Instructions

The ChooChoo CT2305-BK coffee table is designed for straightforward assembly. Detailed, step-by-step instructions with numbered parts and all necessary assembly tools are included in your package.

1. **Preparation:** Clear a spacious area for assembly. Lay out all parts and hardware, matching them against the included parts list.
2. **Tools:** A screwdriver is recommended for assembly. All other required tools are provided.
3. **Follow the Guide:** Refer to the separate assembly instruction booklet for precise, illustrated steps. Ensure each component is securely fastened.
4. **Recommended Personnel:** Assembly is recommended for 1 person.
5. **Post-Assembly Check:** Once assembled, gently test the stability of the table and the functionality of the drawer.

If you encounter any difficulties during assembly, please refer to the Troubleshooting section or contact our professional service team for assistance.

4. Operating Instructions

4.1. LED Lighting System

The coffee table features an integrated LED lighting system with adjustable settings to enhance your living space.

- **Power On/Off:** Use the provided remote control to turn the LED lights on or off.
- **Color Selection:** Choose from 16 different light colors using the color buttons on the remote.
- **Flashing Modes:** Select from 4 dynamic flashing modes (Flash, Strobe, Fade, Smooth) to create different ambiances.
- **Brightness Adjustment:** Adjust the brightness of the lights using the designated buttons on the remote control.



Image: A collage of four images demonstrating the coffee table with its LED lights set to red, orange, blue, and green. A remote control is also displayed, indicating 16 color changes and 4 flashing modes (Brightness Adjustment, Flash, Strobe, Fade, Smooth).

4.2. Sliding Drawer Operation

The coffee table includes a large-capacity sliding drawer for convenient storage.

- **Opening the Drawer:** The drawer features push-to-open latches. Gently push the front of the drawer inward, and it

will automatically pop out.

- **Closing the Drawer:** Push the drawer back into the table until it clicks into place, ensuring it is fully closed.



Image: A close-up view of the coffee table, highlighting its large storage space. The image shows the open shelf area and the pull-out drawer filled with books and decorative items.

5. Maintenance and Care

Proper care will help maintain the appearance and longevity of your ChooChoo coffee table.

- **Cleaning:** Wipe the surface with a dry or damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the high-gloss finish.
- **Spills:** Promptly wipe up any spills to prevent staining, especially on the high-gloss acrylic surface which is waterproof and scratch-resistant.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the finish.
- **Heat:** Do not place hot items directly on the surface without protective coasters.



Image: A detailed view of the coffee table's high-gloss acrylic surface, showcasing its reflective quality and ease of cleaning. Decorative items like glasses and a book are placed on top.

6. Troubleshooting

If you encounter issues with your coffee table, refer to the following common problems and solutions:

- **LED Lights Not Working or Glitching:**
  - Check if the power adapter is securely connected to both the table and a working power outlet.
  - Ensure the remote control batteries are correctly inserted and not depleted. Replace if necessary.
  - Verify there are no obstructions between the remote control and the LED receiver on the table.
  - If issues persist, try unplugging the table for a few minutes and then plugging it back in to reset the system.
- **Drawer Does Not Close Properly or Latch:**
  - Ensure the drawer slides are correctly installed and aligned. Refer to the assembly instructions for proper

alignment.

- Check for any obstructions inside the drawer or along the slides that might prevent it from closing fully.
- Verify that the push-to-open latch mechanism is correctly installed and not damaged. If damaged, contact customer support for replacement parts.
- Avoid forcing the drawer, as this can cause damage to the mechanism or the table structure.

- **Table Stability Issues:**
  - Ensure all screws and fasteners are tightened securely. Do not overtighten.
  - Verify the table is placed on a level surface.

For problems not listed here or if solutions do not resolve the issue, please contact ChooChoo customer support.

7. Product Specifications

Brand	ChooChoo
Model Name	CT2305-BK
Product Dimensions (L x W x H)	43.31" x 23.62" x 16.14" (110cm x 60cm x 41cm)
Color	Black
Material	Engineered Wood
Finish Type	High-gloss
Number of Drawers	1
Item Weight	58.8 pounds (26.67 kg)
Recommended Uses	Living room, bedroom, store, office
Assembly Tools Included	Yes (screwdriver recommended, not included)
LED Features	16 colors, 4 flashing modes, brightness adjustment

8. Warranty and Support

Your ChooChoo CT2305-BK Modern LED Coffee Table comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions.

- **Returns:** This product is eligible for 30-day easy returns. Please check the retailer's return policy for details.
- **Customer Support:** For any questions, missing parts, assembly assistance, or warranty claims, please contact ChooChoo customer service. Contact information can typically be found on the packaging or the retailer's website.

© 2026 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D1K5458V

More documents and user manuals: **https://manuals.plus/**