VACTechPro V15

Quick start guide for the VAC Tech Pro V15 vacuum, covering assembly, eco and max power modes, 6-in-1 versatility with attachments, and essential maintenance tips for the dustbin, HEPA filter, and brush roll.

The VACTechPro brand logo, featuring the company name in a bold, sans-serif typeface.

VACTechPro V15 Cordless Vacuum Cleaner User Manual

Model: V15

1. Introduction

Welcome

Thank you for choosing the VACTechPro V15 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

Product Overview

The VACTechPro V15 is a lightweight yet powerful cordless vacuum designed for versatile cleaning across various surfaces. Its advanced features include a high-efficiency filtration system, a removable battery for extended runtime, and a multi-functional design for comprehensive home cleaning.



This image displays the VACTechPro V15 cordless vacuum cleaner in its full upright configuration, featuring a gold-colored extension wand and a grey main body with a purple dustbin. Surrounding the main unit are various accessories: a long crevice tool, a 2-in-1 brush tool, a wall-mount bracket, and two washable HEPA filters. The main floor brush head shows a green LED light, indicating its illumination feature.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust bin and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Store the appliance indoors. Put away after use to prevent accidents.
- Use only the charger supplied by the manufacturer to recharge.
- Do not incinerate the appliance even if it is severely damaged. The batteries can explode in a fire.

3. What's in the Box

Please check the package contents to ensure all items are present and in good condition:

- VACTechPro V15 Main Unit (Motor and Dustbin)
- Extension Wand (Gold)
- Motorized Floor Brush Head with Green Light
- Removable Battery Pack
- Charging Station / Power Adapter
- Crevice Tool
- 2-in-1 Brush Tool
- Wall Mount Bracket
- Additional HEPA Filters (2 included)
- User Manual (This document)

4. Product Components

Familiarize yourself with the different parts of your VACTechPro V15 vacuum cleaner:



The image shows the main vacuum body (motor and dustbin), the extension wand, the motorized floor brush with green light, the removable battery, the charging adapter, the crevice tool, the 2-in-1 brush tool, and two spare HEPA filters. Each component is designed for easy assembly and versatile cleaning.

A. Main Unit: Contains the motor, dustbin, and control panel.

B. Extension Wand: Connects the main unit to the floor brush or other attachments for extended reach.

C. Motorized Floor Brush: Features a V-shaped rotating brush and green LED lights for effective cleaning on various floor types.

D. Removable Battery: Provides power to the vacuum and can be charged separately.

E. Crevice Tool: Ideal for narrow gaps and corners.

F. 2-in-1 Brush Tool: Combines a brush and a wide nozzle for upholstery and delicate surfaces.

G. Wall Mount Bracket: For convenient storage and charging.

H. HEPA Filters: High-efficiency particulate air filters, washable and replaceable.

5. Getting Started

Assembly

1. **Attach the Extension Wand:** Insert the top end of the extension wand into the main unit until it clicks into place.
2. **Attach the Floor Brush:** Insert the bottom end of the extension wand into the motorized floor brush until it clicks.
3. **Install the Battery:** Slide the removable battery pack into the slot on the main unit until it locks securely.
4. **Optional Wall Mount:** If desired, install the wall mount bracket in a convenient location using the provided screws.

Initial Charging

Before first use, fully charge the battery. The battery can be charged while attached to the main unit or separately.

- Connect the charging adapter to the charging port on the battery or the main unit.
- Plug the adapter into a power outlet.
- The charging indicator lights will show the charging status. Allow approximately 4-5 hours for a full charge.
- Once fully charged, unplug the adapter.

6. Operating Your VACTechPro V15

Power Modes

The VACTechPro V15 offers two power modes for different cleaning needs:

- **ECO Mode:** Provides up to 35 minutes of runtime, ideal for daily cleaning and lighter debris.
- **MAX Mode:** Delivers powerful 35 KPa suction for up to 18 minutes, suitable for deep cleaning and stubborn dirt.

Press the power button to turn on the vacuum. Press the mode button to switch between ECO and MAX modes.

Using Attachments (6-in-1 Functionality)

The V15 can be easily converted into a handheld vacuum and used with various attachments:

- **Handheld Vacuum:** Detach the extension wand and floor brush from the main unit. Attach the desired tool directly to

the main unit.

- **Crevice Tool:** Use for cleaning tight spaces, corners, and edges (e.g., between sofa cushions, car seats).
- **2-in-1 Brush Tool:** Use the brush for dusting delicate surfaces like keyboards or blinds, and the wide nozzle for upholstery or car interiors.
- **Telescopic Tube:** The extension wand can be used with attachments for reaching high areas like ceilings or fan blades.

Green Light Technology

The motorized floor brush is equipped with green LED lights that illuminate dust and debris on hard floors, making it easier to spot and clean even fine particles in dimly lit areas.

7. Care and Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dustbin

1. Ensure the vacuum is turned off.
2. Locate the dustbin release button on the main unit.
3. Press the button to open the dustbin flap and empty contents into a trash can.
4. Close the dustbin flap securely.

Cleaning the Filter (HEPA)

The HEPA filter is washable. Two spare filters are included for convenience.

1. Remove the dustbin from the main unit.
2. Twist and pull out the HEPA filter assembly from the dustbin.
3. Tap off loose dirt. Rinse the filter under cold running water until the water runs clear.
4. Allow the filter to air dry completely for at least 24 hours before reinserting. Do not use a dryer or heat to dry.
5. Regular cleaning (every 2-4 weeks depending on usage) prevents loss of suction. Replace filters every 3-6 months or as needed.

Cleaning the Brush Roll

1. Turn off the vacuum and detach the floor brush.
2. Locate the brush roll release tab on the side of the floor brush.
3. Remove the brush roll.
4. Use scissors or a cleaning tool to remove any tangled hair or debris from the brush roll.
5. Reinsert the brush roll and secure it.

Battery Care

- Avoid fully discharging the battery frequently.

- Store the vacuum and battery in a cool, dry place when not in use.
- If storing for an extended period, charge the battery to about 50% and recharge every few months.

8. Troubleshooting Guide

If you encounter any issues with your VACTechPro V15, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on	Battery is not charged or not properly installed.	Charge the battery fully. Ensure the battery is securely clicked into place.
Low suction power	Dustbin is full. Filter is clogged. Brush roll is tangled. Obstruction in nozzle/wand.	Empty the dustbin. Clean or replace the HEPA filter. Remove tangled hair/debris from brush roll. Check for and remove any blockages.
Brush roll not spinning	Brush roll is jammed or tangled.	Turn off the vacuum and remove any obstructions from the brush roll.
Short runtime	Battery not fully charged. Using MAX mode excessively. Battery life degrading.	Ensure battery is fully charged. Use ECO mode for longer cleaning sessions. Consider replacing the battery if it's old.
Unusual noise	Obstruction in the air path. Damaged component.	Check for and remove any blockages in the dustbin, filter, wand, or brush head. If noise persists, contact customer support.

9. Technical Specifications

Feature	Specification
Brand	VACTechPro
Model Number	V15
Color	Gold
Product Dimensions (L x W x H)	32.9 x 11.2 x 22 cm
Item Weight	3.2 Kilograms
Capacity (Dustbin)	1.5 Liters
Suction Power	35 KPa (Max Mode)
Number of Speeds	2 (ECO, MAX)
Runtime	Up to 35 minutes (ECO Mode), 18 minutes (MAX Mode)

Feature	Specification
Special Feature	6-in-1 Vacuum, Green Light Technology
Filter Type	HEPA Filter (Washable)
Surface Recommendation	Hard Floor, Carpet
Power Source	Cordless, Battery Powered
Included Components	Main unit, battery, charging station, removable flat nozzle, telescopic tube, combined nozzle, 2 spare HEPA filters
Battery Type	1 A (included)

10. Warranty and Customer Support

VACTechPro is committed to providing excellent products and customer service.



An image showing three circular icons representing customer support: a heart with hands for professional customer service, a headset with '24H' for 24/7 assistance, and a shield with a checkmark for a 3-year warranty.

- **Warranty:** Your VACTechPro V15 comes with a 3-year warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase.
- **Professional Customer Service:** We are dedicated to assisting you and acting responsibly.
- **24/7 Assistance:** For any questions, concerns, or technical support, please contact our customer service team.
- **Contact Information:** Please refer to the VACTechPro official website or your purchase platform for the most up-to-date contact details.

© 2025 VACTechPro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why won't my VACTechPro V15 start and why are the battery lights flashing blue?

If your VACTechPro V15 will not start and the battery lights are flashing blue, it typically indicates a power or installation issue. Based on the troubleshooting guide, please follow these steps:Check Battery Installation: Ensure...

Read full answer

Why won't my VACTechPro V15 Ultra turn on even though the battery is showing as fully charged?

If your VACTechPro V15 Ultra is not turning on despite a full charge, please check the following troubleshooting steps based on the product manual:Verify Battery Installation: Ensure the removable battery pack is fully slid...

Read full answer

My VACTechPro V15 vacuum cleaner shows a full charge, but it turns off after a few seconds and the battery symbol flashes red. Does the battery need to be replaced, is it covered by the 3-year warranty, and how should I proceed?

Based on the symptoms you described for your VACTechPro V15, the flashing red battery symbol typically indicates a battery fault or that the battery has reached the end of its usable life cycle. Since...

Read full answer