Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ronson 20045

Ronson Profile Chrome Candle Lighter

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Ronson Profile Chrome Candle Lighter. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new lighter. Please read this manual thoroughly before operating the device and retain it for future reference.

Safety Information

- **Child Safety:** This candle lighter is equipped with a child-proof mechanism. A switch must be turned on before the ignition can be depressed. Always ensure the child-proof switch is engaged when not in use and store the lighter out of reach of children.
- **Fuel Type:** Use only Liquefied Petroleum Gas (LPG) specifically designed for lighters. Using incorrect fuel can be dangerous and may damage the lighter.
- **Flammable Gas:** Lighters contain flammable gas under pressure. Keep away from heat, sparks, open flames, and hot surfaces. No smoking.
- **Ventilation:** Refuel in a well-ventilated area.
- **Avoid Prolonged Exposure to Sunlight:** Do not expose to temperatures exceeding 50°C (122°F).
- **Do Not Puncture or Incinerate:** Never attempt to puncture or incinerate the lighter, even after use.
- **Flame Control:** The flame is variable. Exercise caution when igniting to prevent accidental burns. Keep flame away from face and clothing.

Product Overview

The Ronson Profile Chrome Candle Lighter is designed for safe and convenient ignition of candles, gas cookers, BBQs, and more. It features a sleek chrome finish and an extended reach to protect your fingers.



An image showing the sleek, chrome-finished Ronson Profile Candle Lighter. The lighter features a long, slender body with the Ronson logo visible near the base and the ignition mechanism located towards the top.

Key Features:

- Sleek Chrome Finish
- Variable Soft Flame
- Electronic Ignition
- Child-Proof Safety Switch
- Extended Reach (approximately 6.5 inches / 16 cm flame distance from fingers)

Setup

Fueling the Lighter:

1. Ensure the lighter is cool and the flame is extinguished.
2. Locate the refill valve at the bottom of the lighter.
3. Use a high-quality butane gas canister with a universal filling nozzle.
4. Invert the lighter and firmly press the nozzle of the butane canister into the refill valve.
5. Hold for approximately 5-10 seconds, or until gas starts to escape, indicating it is full.
6. Allow the lighter to rest for a few minutes after refueling to allow the gas to stabilize and reach room temperature.

Operating Instructions

1. **Engage Child-Proof Switch:** Locate the child-proof switch, typically near the ignition button. Slide or toggle it to the "ON" or unlocked position.
2. **Ignite:** Point the lighter away from yourself and others. Depress the ignition button firmly. The electronic ignition will create a spark, and the gas will ignite.
3. **Adjust Flame (if applicable):** If your model has a flame adjustment mechanism (usually a small dial or lever near the refill valve), you can adjust the flame height as needed. Turn towards '+' for a larger flame and '-' for a smaller flame.
4. **Extinguish:** Release the ignition button to extinguish the flame.
5. **Disengage Child-Proof Switch:** After use, always return the child-proof switch to the "OFF" or locked position for safety.

Maintenance

- **Cleaning:** Wipe the lighter with a soft, dry cloth to remove dust or smudges. Do not use abrasive cleaners or solvents.
- **Refueling:** Refuel as described in the "Setup" section when the flame becomes weak or inconsistent.
- **Storage:** Store the lighter in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the child-proof switch is engaged before storage.

Troubleshooting

Problem	Possible Cause	Solution
Lighter does not ignite.	No fuel or low fuel. Child-proof switch not engaged. Air in fuel line.	Refuel the lighter. Ensure child-proof switch is in the "ON" position. Purge air by pressing the refill valve with a small tool until gas escapes, then refuel.
Flame is weak or inconsistent.	Low fuel. Incorrect flame adjustment.	Refuel the lighter. Adjust the flame height using the adjustment dial.
Gas leaks from refill valve.	Valve not sealed properly. Overfilled.	Ensure the butane canister nozzle is firmly pressed during refueling. Do not overfill. If leakage persists, discontinue use and contact support.

Specifications

Brand	Ronson
Model Number	20045
Color	Chrome
Material	Metal
Style	Modern
Fuel Type	Liquefied Petroleum Gas
Product Dimensions	11"L x 2"W x 1.5"Th
Number of Items	1
Manufacturer	Ronson

Warranty and Support

The Ronson Profile Chrome Candle Lighter comes with a**2-year Guarantee**. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.
EU Spare Part Availability Duration: 2 Years.
For technical support, warranty claims, or further assistance, please refer to the contact information provided with your purchase or visit the official Ronson website.

© 2024 Ronson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D1KH818M

More documents and user manuals: **https://manuals.plus/**