Cesun AMZUSIJS01BLK030071

Cesun Automatic Motion Sensor Trash Can User Manual

Model: AMZUSIJS01BLK030071

1. Introduction

Thank you for choosing the Cesun Automatic Motion Sensor Trash Can. This smart, touchless trash bin is designed for convenience and hygiene, perfect for various indoor spaces such as bathrooms, bedrooms, RVs, and offices. Its slim profile and advanced features make waste disposal effortless and clean.

Key Features:

- **Touchless Operation:** Infrared motion sensor for automatic lid opening.
- **Slim Design:** Fits perfectly in narrow spaces.
- **Countdown Light:** Green indicator light for lid closure timing.
- **Excellent Sealing Ability:** Close-fitting lid contains odors.
- **Garbage Bag Fix Ring:** Keeps bags in place and out of sight.
- **Manual Control:** Option to open or close the lid manually.



The Cesun Automatic Motion Sensor Trash Can, designed for modern living spaces.

2. Setup

Follow these steps to set up your Cesun Automatic Motion Sensor Trash Can for first use:

1. **Install Batteries:** Locate the battery compartment on the underside of the lid. Insert 2 AA batteries (not included), ensuring correct polarity.
2. **Prepare Garbage Bag:** Place a garbage bag into the trash can. Use the removable inner fix ring to secure the bag in place and hide any excess bag material for a neat appearance.
3. **Power On:** Long press the power button on the lid to turn on the device. The green indicator light will illuminate.



Visual guide for the initial setup process.

3. Operating Instructions

Your Cesun trash can offers both automatic and manual operation modes.

Automatic (Motion Sensor) Mode:

The trash can utilizes infrared sensing technology for touchless operation. Simply place your hand or an object over the intelligent sensing area on the lid. The lid will automatically open. If your hand remains in the sensing area, the green indicator light will stay on, and the lid will remain open. Once your hand leaves the sensing area, the green light will start flashing, and the lid will close automatically after 5 seconds.

Manual Operation:

You can also manually control the lid. Press the designated button on the lid to open or close it as needed. This is useful for extended periods of use or when you prefer manual control.



Detailed view of the control panel on the lid.



The trash can supports both infrared and vibration induction for opening.

Soft Close Lid:

The lid is designed with a soft-close mechanism, ensuring quiet and smooth operation. This feature prevents loud slamming noises, making it ideal for use in quiet environments like bedrooms or offices.



The soft-close lid ensures quiet operation.

4. Maintenance

Proper maintenance will ensure the longevity and optimal performance of your Cesun trash can.

Cleaning:

Wipe the exterior of the trash can with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the finish. For the interior, remove the garbage bag and wipe down with a disinfectant wipe or damp cloth. Ensure the battery compartment remains dry.

Odor Control:

The close-fitting lid is designed to contain odors effectively, keeping your room fresh. For best results, change garbage bags regularly and clean the interior as needed.



The close-fitting lid helps to seal in odors.

Water Resistance:

The trash can features an IPX5 waterproof rating, making it suitable for use in humid environments like bathrooms. While it can withstand splashes, it is not designed for submersion.



IPX5 waterproof rating makes it ideal for bathroom use.

5. Troubleshooting

If you encounter any issues with your Cesun Automatic Motion Sensor Trash Can, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Lid does not open automatically.	Low batteries, sensor obstructed, power off.	Replace batteries. Ensure nothing is blocking the sensor area. Long press power button to turn on.
Lid does not close.	Object in sensing area, mechanism obstruction.	Remove any objects from the sensing area. Check for physical obstructions around the lid mechanism.
Lid closes too quickly/slowly.	Sensor sensitivity.	Ensure the sensor area is clean. The lid is designed to close after 5 seconds once the object leaves the sensing area.
Unit stops working after a short period.	Battery issue, internal fault.	Replace with fresh, high-quality batteries. If the issue persists, contact customer support.

6. Specifications

Feature	Detail
Product Dimensions	11.61 x 5.75 x 10.79 inches
Weight	2.4 Pounds
Capacity	2.6 Gallons
Color	Black
Opening Mechanism	Motion-Sensor
Material	Plastic
Power Source	2 AA Batteries (not included)
Special Features	Quiet Close, Compact, Motion Sensor, Odor Seal, IPX5 Waterproof
Recommended Use	Indoor (Bathroom, Bedroom, Home Office)



Product dimensions and capacity.

7. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Cesun customer service directly. Keep your purchase receipt for any warranty claims.

© 2025 Cesun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question