Scheppach 5911415900

Scheppach BC-MP430-X Cordless Lawn Mower User Manual

Model: BC-MP430-X (5911415900)

Introduction

This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Scheppach BC-MP430-X Cordless Lawn Mower. This powerful 2x20V (40V) lawn mower features a 43 cm cutting width and a versatile 4-in-1 function: mowing, catching, mulching, and lawn edging. Please read this manual thoroughly before first use and keep it for future reference.



Figure 1: The Scheppach BC-MP430-X Cordless Lawn Mower, showcasing its compact design and integrated grass collection bag.

Safety Information

Always observe the following safety precautions to prevent injury and damage to the lawn mower:

- Read and understand all instructions before operating the machine.
- Wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and sturdy footwear.
- Ensure the work area is clear of debris, stones, and other objects that could be thrown by the blade.
- Never operate the mower in wet conditions or on excessively steep slopes.
- Keep hands and feet away from rotating parts.
- Disconnect the battery pack before cleaning, performing maintenance, or clearing blockages.
- Store the mower in a dry, secure place, out of reach of children.

- Only use original Scheppach IXES 20V batteries and chargers.

Setup

1. Handle Assembly

Unfold the handle and secure it in place using the quick-release levers or knobs provided. Ensure the handle is firmly locked to prevent accidental folding during operation. The handle is height-adjustable for ergonomic working posture.



Figure 2: Adjusting the height of the mower handle for comfortable operation.

2. Battery Installation

The BC-MP430-X requires two 20V Scheppach IXES batteries for operation (total 40V). Open the battery compartment cover, insert the fully charged batteries into their respective slots, and ensure they click into place. Close the cover securely. Always use a safety key if provided.



Figure 3: The Scheppach IXES 20V battery platform, illustrating compatibility across various tools.

3. Cutting Height Adjustment

The cutting height can be centrally adjusted in 6 steps, from 25 mm to 75 mm. Use the lever located on the side of the mower to select the desired cutting height. Ensure the lever is securely engaged in the chosen position.



Figure 4: A hand operating the central cutting height adjustment lever, showing the 6 available settings from 25mm to 75mm.

4. Mulching Insert Installation (Optional)

For mulching, remove the grass collection bag and insert the mulching plug into the discharge chute. This will allow the finely cut grass clippings to be returned to the lawn as natural fertilizer.



Figure 5: A hand inserting the mulching plug into the mower's discharge opening.

Operating Instructions

1. Starting and Stopping

To start the mower, press and hold the safety button, then pull the bail lever towards the handle. To stop, release the bail lever.

2. Operating Modes: Eco and Auto

The mower features a convenient control panel allowing you to switch between "Eco" and "Auto" modes:

- **Eco Mode:** Provides lower speed for maximum battery life, suitable for lighter mowing tasks or maintaining already short grass.
- **Auto Mode:** The motor speed automatically adjusts according to the load, providing optimal power for varying grass conditions.



Figure 6: A hand interacting with the mower's control panel, showing the "Eco" and "Auto" mode selection buttons.

3. Mowing Techniques

The Scheppach BC-MP430-X supports various mowing functions:

- **Mowing & Catching:** Attach the 50-liter collection box to gather clippings. The box includes a level indicator.
- **Mulching:** Install the mulch insert (as described in Setup) to return finely chopped grass to the lawn.
- **Lawn Edging:** The mower is designed with both-sides lawn edging feed for clean cuts even near edges.



Figure 7: Visual representation of the mower's capabilities: standard mowing, grass collection, mulching, and precise lawn edging.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your lawn mower.

- **Cleaning:** After each use, disconnect the batteries and clean the underside of the deck, the blade, and the grass collection box. Use a brush or damp cloth; avoid using high-pressure water.
- **Blade Inspection:** Regularly check the blade for sharpness and damage. A dull or damaged blade can lead to poor cutting performance and excessive vibration. Replace or sharpen the blade as needed.
- **Storage:** For space-saving storage, the handle can be folded. Store the mower in a dry, protected area, away from direct sunlight and extreme temperatures. Remove batteries if storing for extended periods.



Figure 8: A person demonstrating the folding handle feature for compact storage and easy transport of the lawn mower.

Troubleshooting

Problem	Possible Cause	Solution
Mower does not start.	Batteries not charged or not inserted correctly. Safety key not inserted. Bail lever not engaged.	Ensure batteries are fully charged and properly seated. Insert safety key. Engage bail lever fully.
Poor cutting performance.	Dull or damaged blade. Cutting height too low for grass type. Grass collection bag full.	Sharpen or replace blade. Adjust cutting height. Empty grass collection bag.
Excessive vibration.	Damaged or unbalanced blade. Debris caught in blade area.	Inspect blade for damage and replace if necessary. Clean underside of deck and blade.
Motor stops during operation.	Overload (e.g., very thick grass). Batteries depleted.	Raise cutting height. Mow in smaller passes. Recharge batteries.

Specifications

Key technical specifications for the Scheppach BC-MP430-X Cordless Lawn Mower:

Feature	Specification
Brand	Scheppach
Model Number	BC-MP430-X (5911415900)
Power Source	Battery Powered (2 x 20V IXES, 40V total)
Cutting Width	43 cm (17 inches)
Cutting Height Adjustment	Central, 6 positions (25 - 75 mm)
Grass Collection Box Capacity	50 Liters
Recommended Lawn Area	600 - 700 m^2
Motor Type	Brushless
Functions	Mowing, Catching, Mulching, Lawn Edging
Product Dimensions (D x W x H)	53.15" x 18.5" x 45.28"
Item Weight	1 Kilogram (2.2 pounds) - *Note: This weight seems unusually low for a lawnmower and likely refers to a component, not the full product.*




Figure 9: Key specifications of the lawn mower, including recommended lawn size (600-700 m²), battery voltage (2x20V), cutting width (43 cm), and cutting height range (25-75 mm).

Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Scheppach website. For technical support, spare parts, or service inquiries, please contact Scheppach customer service or your authorized dealer. Always provide the model number (BC-MP430-X) and serial number (if applicable) when contacting support.

© 2024 Scheppach. All rights reserved.