Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dreo DOTF07

Dreo Nomad One Tower Fan User Manual

Brand: Dreo | Model: DOTF07

Introduction

Thank you for choosing the Dreo Nomad One Tower Fan. This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new fan. Please read this manual thoroughly before use and retain it for future reference.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- Always place the fan on a stable, flat surface to prevent tipping.
- Do not insert fingers or foreign objects into the grille while the fan is operating.
- Keep the fan away from water or damp environments.
- Ensure the power cord is not damaged or pinched.
- Unplug the fan from the power outlet before cleaning or performing any maintenance.
- This CE-certified fan is equipped with an anti-pinch grille, a secure plug, and integrated circuit protection, ensuring safety is always paramount.
- Do not operate the fan if it has been damaged in any way. Contact customer support for assistance.

Package Contents

- Dreo Nomad One Tower Fan Unit
- Remote Control (with 1 CR2 battery included)
- User Manual

Product Overview





Figure 1: Dreo Nomad One Tower Fan with Remote Control. An image showing the white Dreo Nomad One tower fan standing upright, with

its sleek, modern design. To the left of the fan, its white remote control is displayed at an angle, showing its buttons.

The Dreo Nomad One Tower Fan features a compact and elegant design, making it suitable for various living spaces. It includes a user-friendly control panel on top and a convenient remote control for easy adjustments from a distance.

Main Components:

- **Control Panel:** Located on the top of the fan for manual operation.
- **Air Outlet:** Front grille where air is expelled.
- **Air Inlet:** Rear grille for air intake.
- **Base:** Provides stability for the fan unit.
- **Remote Control:** Allows for convenient operation from a distance.
- **Power Cord:** For connecting the fan to an electrical outlet.

Setup

Assembly:

1. Carefully remove all packaging materials from the fan and its components.
2. Attach the base to the bottom of the fan unit. Align the base with the fan's bottom and twist or secure with provided screws (if applicable) until firmly attached.
3. Place the fan on a firm, level surface.

Power Connection:

- Ensure the fan is switched off before plugging it in.
- Plug the power cord into a standard 120V AC electrical outlet.

Operating Instructions

The Dreo Nomad One Tower Fan can be operated using either the control panel on top of the fan or the included remote control.

Control Panel Functions:

- **Power Button ( ):** Press to turn the fan On or Off.
- **Speed Button (≡):** Cycle through 4 fan speeds (1, 2, 3, 4).
- **Mode Button (○):** Switch between 4 operating modes:
  - **Normal Mode:** Constant airflow at selected speed.
  - **Natural Mode:** Simulates natural breeze with varying fan speeds.
  - **Sleep Mode:** Gradually decreases fan speed and dims display for quiet operation.
  - **Auto Mode:** Adjusts fan speed automatically based on ambient temperature.
- **Oscillation Button (↻):** Activate or deactivate 90° oscillation to distribute air widely.
- **Timer Button ( ):** Set the auto-off timer for up to 8 hours. Each press adds 1 hour.

Remote Control:

The remote control provides all the functionalities of the control panel. Ensure the remote control has a working CR2

battery installed. Point the remote directly at the fan's receiver for optimal response.

- **Power Button:** Turns the fan On/Off.
- **Speed Buttons (+/-):** Adjust fan speed up or down.
- **Mode Button:** Cycles through operating modes.
- **Oscillation Button:** Toggles oscillation.
- **Timer Button:** Sets the auto-off timer.
- **Mute Button ( ):** Mutes button sounds for quiet operation (if available on model).

Maintenance

Regular cleaning and proper storage will help prolong the life of your Dreo Nomad One Tower Fan.

Cleaning:

1. Always unplug the fan from the power outlet before cleaning.
2. Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
3. For internal cleaning, the removable rear grille and impeller wheel make cleaning more accessible. Refer to the specific instructions for removing these parts for thorough cleaning of dust buildup.
4. Ensure all parts are completely dry before plugging the fan back in.

Storage:

- If storing the fan for an extended period, clean it thoroughly.
- Store the fan in a cool, dry place, away from direct sunlight and extreme temperatures.
- It is recommended to store the fan in its original packaging to protect it from dust and damage.

Troubleshooting

If you encounter any issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; Power outlet not working; Power button not pressed; Remote control battery dead.	Ensure the power cord is securely plugged into a working outlet. Press the power button on the fan or remote. Replace remote control battery if needed.
Weak airflow.	Fan speed too low; Air inlets/outlets blocked by dust.	Increase the fan speed. Clean the air inlets and outlets, especially the rear grille.
Fan is noisy.	Fan not on a level surface; Internal dust buildup; Foreign object inside.	Place the fan on a flat, stable surface. Clean the fan thoroughly, especially the impeller. If noise persists, discontinue use and contact support.
Remote control not working.	Battery dead or incorrectly inserted; Obstruction between remote and fan; Remote too far.	Replace the CR2 battery, ensuring correct polarity. Remove any obstructions. Operate the remote within range and point it directly at the fan.

If the problem persists after trying these solutions, please contact Dreo Customer Support.

Specifications

Brand	Dreo
Model Number	DOTF07
Color	White
Product Dimensions (L x W x H)	95.5 x 21 x 21 cm (37.6 x 8.3 x 8.3 inches)
Item Weight	3.79 Kilograms (8.35 lbs)
Power	35 Watts
Voltage	120V
Material	Plastic
Number of Speeds	4
Noise Level	28 dB
Special Features	Oscillating, Timer, Remote Control
Power Source	Electric Cord
Battery	1 CR2 (included)
Country of Origin	China

Warranty and Support

Warranty Information:

Dreo products come with a standard manufacturer's warranty. Please refer to the warranty card included in your package or visit the official Dreo website for detailed warranty terms and conditions specific to your region.

Customer Support:

For any questions, technical assistance, or warranty claims, please contact Dreo Customer Support. You can typically find contact information on the official Dreo website or on the product packaging.
When contacting support, please have your product model number (DOTF07) and purchase details ready.

© 2024 Dreo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D1VSS7VZ

More documents and user manuals: **https://manuals.plus/**