Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

saschedross 01 (Compatible with XREXS DY-27 DY27 Speaker)

saschedross Audio Cable Replacement

Model: 01 | Brand: saschedross

Compatible with XREXS DY-27 DY27 Radio Alarm Clock Portable Wireless Bluetooth Stereo Speaker

Introduction

This manual provides instructions for the saschedross Audio Cable Replacement, designed for the XREXS DY-27 DY27 Radio Alarm Clock Portable Wireless Bluetooth Stereo Speaker. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and reliable audio transmission.

Setup

Follow these steps to connect your audio cable:

1. **Identify Ports:** Locate the auxiliary input port (typically a 3.5mm jack) on your XREXS DY-27 DY27 speaker and the corresponding audio output port on your source device (e.g., smartphone, tablet, computer).
2. **Connect Cable to Speaker:** Insert one end of the saschedross audio cable (3.5mm male jack) firmly into the auxiliary input port of the XREXS DY-27 DY27 speaker.
3. **Connect to Audio Source:** Insert the other end of the audio cable (3.5mm male jack) firmly into the audio output port of your source device.
4. **Power On Devices:** Ensure both the XREXS DY-27 DY27 speaker and your audio source device are powered on.
5. **Select Input:** On the XREXS DY-27 DY27 speaker, select the auxiliary input mode. This may be labeled as "AUX" or indicated by an icon.



Image: The saschedross Audio Cable, featuring a 3.5mm male jack connector, designed for auxiliary audio input.

Operating Instructions

Once the cable is securely connected and the correct input mode is selected:

- **Audio Playback:** Begin playing audio from your source device. Sound will now be transmitted through the saschedross audio cable to your XREXS DY-27 DY27 speaker.
- **Volume Control:** Adjust the volume levels on both your audio source device and the XREXS DY-27 DY27 speaker to achieve your desired listening volume.
- **Secure Connection:** Ensure the cable remains securely connected at both ends during use to prevent audio interruptions or static.

Maintenance

Proper care will extend the life of your audio cable:

- **Cleaning:** Gently wipe the cable with a dry, soft cloth to remove dust or dirt. Avoid using liquid cleaners directly on the connectors.
- **Storage:** Store the cable in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid sharp bends or kinks in the cable to prevent internal damage.
- **Handling:** Always grasp the connector ends when plugging or unplugging the cable. Do not pull on the cable itself, as this can damage the internal wiring.

Troubleshooting

Problem	Solution
No Sound Output	◦ Ensure both the speaker and audio source are powered on. ◦ Verify the audio cable is securely connected to both devices. ◦ Check volume levels on both devices; ensure they are not muted or set too low. ◦ Confirm the correct input mode (AUX) is selected on the XREXS DY-27 DY27 speaker. ◦ Test with another audio cable if available to rule out a faulty cable.
Intermittent Sound or Static	◦ Check for loose connections at both ends of the cable. ◦ Inspect the cable for any visible damage (e.g., kinks, cuts). ◦ Try a different audio source or speaker to isolate the issue. ◦ Keep the cable away from sources of electromagnetic interference.

Specifications

- **Brand:** saschedross
- **Model:** 01
- **Compatible Devices:** XREXS DY-27 DY27 Radio Alarm Clock Portable Wireless Stereo Speaker
- **Connector Type:** Auxiliary (3.5mm Male-to-Male)
- **Cable Length:** 3.0 feet
- **Color:** Black
- **Special Feature:** High Quality
- **Manufacturer:** Shenzhen Waweis Technology Co., Ltd

Warranty and Support

Warranty: This product is typically covered by a standard manufacturer's warranty. Please refer to your purchase documentation or contact the seller for specific warranty terms and conditions.
Support: For technical assistance or further inquiries regarding your saschedross Audio Cable Replacement, please contact the seller or manufacturer directly through your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D21YB5XG

More documents and user manuals: **https://manuals.plus/**